

# HYDRAULIC EXCAVATOR

## SHOP MANUAL

model

**SK 310**   
**SK 310Lc** 

This is the shop manual for KOBELCO hydraulic excavator. Contained is the necessary technical data concerning the maintenance and repair of this model. The manual is divided into the following four major sections; GENERAL, SYSTEMS, COMPONENTS and PROCEDURE.

### \*GENERAL

#### LC01. SPECIFICATION

- OPERATION AND CONTROLS  
(Refer to Operators Manual)

#### LC03. LOCATION AND WEIGHT OF COMPONENTS

#### LC04. MAINTENANCE STANDARD AND TEST PROCEDURE

- PREVENTIVE MAINTENANCE  
(Refer to Operators Manual)

#### LC07. WORKING STANDARD

#### LC08. STANDARD MAN-HOUR TABLE

### \*SYSTEMS

#### LC12. HYDRAULIC SYSTEM

#### LC15. SWING FRAME

#### LC18. TRAVEL SYSTEM

#### LC21. ATTACHMENTS

#### LC22. CONTROL SYSTEM

#### LC25. ELECTRICAL SYSTEM

#### LC26. AIR-CONDITIONER SYSTEM

#### LC29. TROUBLE SHOOTING

### \*COMPONENTS

#### 12. HYDRAULIC PUMP

#### 13. CONTROL VALVE

#### 14. OTHER VALVES

#### 15. HYDRAULIC MOTOR

#### 16. SWIVEL JOINT

#### 17. HYDRAULIC CYLINDER

#### 21. REDUCTION UNIT

#### 50. ENGINE

### \*PROCEDURE

When checking or repairing the machine we suggest that you refer to this manual carefully. We hope that reference to this manual will help to maintain a high level of working efficiency and reliability. For further details on maintenance and checks refer to the "OPERATORS MANUAL" which has been supplied with the machine.

Although all data was correct at the time of printing, due to continual design changes and improvements, some contents may not conform to the actual machine. Take special care to order parts only after confirming the validity of the part number in the "PARTS MANUAL".

If you notice any explanatory discrepancies, after consulting one of our representatives, please update your manual according to the latest data. However, in the event of any specification changes, we will issue revised edition.

## INDEX

---

# KOBELCO

---

Book code No. S5LC0005E

## **⚠ WARNING**

# **SAFETY**

## **⚠ WARNING**

The proper and safe lubrication and maintenance for this machine, recommended by KOBELCO are outlined in the OPERATION & MAINTENANCE GUIDE for this machine.

Improper performance of lubrication or maintenance procedures is dangerous and could result in injury or death. Read and understand the OPERATION & MAINTENANCE GUIDE before performing any lubrication or maintenance.

The serviceman or mechanic may be unfamiliar with many of the systems on this machine. This makes it important to use caution when performing service work. A knowledge of the system and/or components is important before the removal or disassembly of any component.

Because of the size of some of the machine components, the serviceman or mechanic should check the weights noted in this Manual. Use proper lifting procedures when removing any components.

Following is a list of basic precautions that should always be observed.

1. Read and understand all Warning plates and labels on the machine before operating, lubricating or repairing this product.
2. Always wear protective glasses and protective shoes when working around machines. In particular, wear protective glasses when pounding on any part of the machine or its attachments with a hammer or sledge. Use welders gloves, hood/goggles, apron and other protective clothing appropriate to the welding job being performed. Do not wear loose-fitting or torn clothing. Remove all rings from fingers when working on machinery.
3. Disconnect battery and discharge any capacitors before starting to work on machine. Hang "Do Not Operate" tag in the Operator's Compartment.
4. If possible, make all repairs with the machine parked on a level, hard surface. Block machine so it does not roll while working on or under machine.
5. Do not work on any machine that is supported only by lift jacks or a hoist. Always use blocks or jack stands to support the machine before performing any disassembly.

## **⚠ WARNING**

Do not operate this machine unless you have read and understand the instructions in the OPERATORS MANUAL. Improper machine operation is dangerous and could result in injury or death.

6. Relieve all pressure to air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure.
7. Lower the bucket, blade, ripper or other attachments to the ground before performing any work on the machine. If this cannot be done, make sure the bucket, blade, ripper or other attachments is blocked correctly to prevent it from dropping unexpectedly.
8. Use steps and grab handles when mounting or dismounting a machine. Clean any mud or debris from steps, walkways or work platforms before using. Always face machine when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
9. To avoid back injury, use a hoist when lifting components which weigh 23 kg (50 lbs) or more. Make sure all chains, hooks, slings, etc., are in good condition and are in the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
10. To avoid burns, be alert for hot parts on machines which have just been stopped and hot fluids in lines, tubes and compartments.
11. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
12. Be careful when removing filler caps, breathers and plugs on the machine. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the machine has just been stopped because fluids can be hot.

## **A WARNING**

13. Always use tools that are in good condition and be sure you understand how to use them before performing any service work.
  14. Reinstall all capscrews with same part number. Do not use a lesser quality capcrew if replacements are necessary.
  15. Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of parent metal. Always disconnect battery during welding operations to protect sensitive electric equipment.
  16. Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will it be damaged in operation by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
  17. Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution.
  18. Loose or damaged fuel, lubricant and hydraulic lines, tubes and hoses can cause fires. Do not bend or strike high pressure lines or install ones which have been bent or damaged. Inspect lines, tubes and hoses carefully. Do not check for leaks with your hands. Pin hole (very small) leaks can result in a high velocity oil stream that will be invisible close to the hose. This oil can penetrate the skin and cause personal injury. Use cardboard or paper to locate pin hole leaks.
  19. Tighten connections to the correct torque. Make sure that all heat shields, clamps and guards are installed correctly to avoid excessive heat, vibration or rubbing against other parts during operation. Shields that protect against oil spray onto hot exhaust components in event of a line, tube or seal failure must be installed correctly.
  20. Do not operate a machine if any rotating part is damaged or contacts any other part during operation. Any high speed rotating component that has been damaged or altered should be checked for balance before reusing.
  21. On track-type machines, be careful when servicing or separating tracks. Chips can fly when removing or installing a track pin. Wear safety glasses and long sleeve shirts. Track can unroll very quickly when separated. Keep away from front and rear of machine. The machine can move unexpectedly when both tracks are disengaged from the sprockets. Block the machine to prevent it from moving.
  22. Caution should be used to avoid breathing dust that may be generated when handling components containing asbestos fibers. If this dust is inhaled, it can be hazardous to your health. Components in KOBELCO products that may contain asbestos fibers are brake pads, brake band and lining assemblies, clutch plates and some gaskets. The asbestos used in these components is usually bound in a resin or sealed in some way. Normal handling is not hazardous as long as airborne dust which contains asbestos is not generated.
- If dust which may contain asbestos is present, there are several common sense guidelines that should be followed.
- a. Never use compressed air for cleaning.
  - b. Avoid brushing or grinding of asbestos containing materials.
  - c. For clean up, use wet methods or a vacuum equipped with a high efficiency particulate air (HEPA) filter.
  - d. Use exhaust ventilation on permanent machining jobs.
  - e. Wear an approved respirator if there is no other way to control the dust.
  - f. Comply with applicable rules and regulations for the work place.
  - g. Follow environmental rules and regulations for disposal of asbestos.
  - h. Avoid areas where asbestos particles may be in the air.



# SHOP MANUAL

model


**SK310**   
**SK310** **LC** 

## TABLE OF CONTENTS

1. SPECIFICATION .....	<b>LC01</b>
2. OPERATION AND CONTROLS (Refer to Operators Manual)	
3. LOCATION AND WEIGHT OF COMPONENTS .....	<b>LC03</b>
4. MAINTENANCE STANDARDS AND TEST PROCEDURES .....	<b>LC04</b>
5. ....	
6. PREVENTIVE MAINTENANCE (Refer to Operators Manual)	
7. WORKING STANDARDS .....	<b>LC07</b>
8. STANDARD MAN-HOUR TABLE .....	<b>LC08</b>

### ○How to Index each Shop Manual Section

The GENERAL of this shop manual consists of 8 headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.



# KOBELCO

# GENERAL

SK310III  
SK310LCIII List of Shop Manual GENERAL Section

Index No.	Title	Book Code No.		
		Distribution Year - Month		
LC01	SPECIFICATION	S5LC0105E 1995-03		
—	OPERATION	S2LC1012E Refer to Operators manual		
LC03	LOCATION AND WEIGHT OF COMPONENTS	S5LC0305E 1995-03		
LC04	MAINTENANCE STANDARDS AND TEST PROCEDURES	S5LC0405E 1995-03		
—	PREVENTIVE MAINTENANCE	S2LC1012E Refer to Operators manual		
LC07	WORKING STANDARDS	S5LC0705E 1995-03		
LC08	STANDARD MAN-HOUR TABLE	S5LC0802E 1995-03		
	Applicable Machines	LC03801~ YC01101~		

Book title No. S5 LC01 05E

# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

**LC01**

### SPECIFICATION

#### TABLE OF CONTENTS

1. LOCATION OF COMPONENTS .....	1
2. GENERAL DIMENSIONS .....	2
3. SPECIFICATIONS AND PERFORMANCE .....	4
4. TYPE OF SHOES .....	5
5. TYPE AND COMBINATION OF ATTACHMENTS ...	5
6. WORKING RANGES OF ATTACHMENTS .....	6
7. LIFTING-UP ABILITY DIAGRAM .....	8
8. ENGINE SPECIFICATIONS .....	14

**Applicable Machines**


LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC0105E K




# 1. LOCATION OF COMPONENTS



## 2. GENERAL DIMENSIONS



SK310Π



Unit : m (ft)

	Arm length	2.55 (8-4)	3.14 (10-4)	4.1 (13-5)
A	Overall length	10.94 (35-11)	10.85 (35-7)	10.88 (35-8)
B	Overall height (to top of boom)	3.52 (11-6)	3.25 (10-8)	3.36 (11-0)
C-1	Overall width (800mm (31.5in))	3.40 (11-2)	3.40 (11-2)	3.40 (11-2)
C-2	Overall width (600mm (23.6in))	3.20 (10-6)	3.20 (10-6)	3.20 (10-6)
D	Overall height (to top of cab)	3.06 (10-0)	3.06 (10-0)	3.06 (10-0)
E	Ground clearance of rear end*	1.17 (3-10)	1.17 (3-10)	1.17 (3-10)
F	Ground clearance*	470mm (18.5in)	470mm (18.5in)	470mm (18.5in)
G	Tail swing radius	3.20 (10-6)	3.20 (10-6)	3.20 (10-6)
H	Tumbler distance	3.705 (12-2)	3.705 (12-2)	3.705 (12-2)
I	Overall length of crawler	4.645 (15-3)	4.645 (15-3)	4.645 (15-3)
J	Track gauge	2.60 (8-6)	2.60 (8-6)	2.60 (8-6)
K-1	Shoe width	800mm (31.5in)	800mm (31.5in)	800mm (31.5in)
K-2	Shoe width	600mm (24in)	600mm (24in)	600mm (24in)
L	Overall width of upper structure	3.06 (10-0)	3.06 (10-0)	3.06 (10-0)

NOTE : Figure of asterisk (\*) apply to value without shoe lug.



Unit : m (ft)

	Arm length	2.55 (8-4)	3.14 (10-4)	4.1 (13-5)
A	Overall length	10.94 (35-11)	10.85 (35-7)	10.88 (35-8)
B	Overall height (to top of boom)	3.54 (11-7)	3.25 (10-8)	3.30 (11-1)
C-1	Overall width (800mm (31.5in))	3.40 (11-2)	3.40 (11-2)	3.40 (11-2)
C-2	Overall width (600mm (23.6in)) :	3.20 (10-6)	3.20 (10-6)	3.20 (10-6)
D	Overall height (to top of cab)	3.06 (10-0)	3.06 (10-0)	3.06 (10-0)
E	Ground clearance of rear end*	1.17 (3-10)	1.17 (3-10)	1.17 (3-10)
F	Ground clearance*	470mm (18.5in)	470mm (18.5in)	470mm (18.5in)
G	Tail swing radius	3.20 (10-6)	3.20 (10-6)	3.20 (10-6)
H	Tumbler distance	4.01 (13-2)	4.01 (13-2)	4.01 (13-2)
I	Overall length of crawler	4.95 (16-3)	4.95 (16-3)	4.95 (16-3)
J	Track gauge	2.60 (8-6)	2.60 (8-6)	2.60 (8-6)
K-1	Shoe width	800mm (31.5in)	800mm (31.5in)	800mm (31.5in)
K-2	Shoe width	600mm (24in)	600mm (24in)	600mm (24in)
L	Overall width of upper structure	3.06 (10-0)	3.06 (10-0)	3.06 (10-0)

NOTE : Figure of asterisk (\*) apply to value without shoe lug.

### 3. SPECIFICATIONS AND PERFORMANCE

#### ■ SPEED AND CLIMBING ABILITY

Item	Model	SK310III · SK310LCII
Swing speed		10.5rpm
Travel speed		5.5 / 3.7km / h (3.4 / 2.3 mph)
Gradeability		35° (70%)

#### ■ ENGINE

Model		Mitsubishi 6D22-T
Type		Water-cooled 4-cycle, direct injection type diesel engine with turbo-charger
Number of cylinder—Bore×Stroke		6—130mm(5.11in)×140mm(5.51in)
Total displacement		11,149c.c. (680cuin)
Rated output power/revolution	JISD 1005 NET	230 HP / 1,750rpm
	ISO 9249 NET	169 KW / 1,750rpm
Maximum torque/revolution	JISD 1005 NET	106 kgf-m / 1,400rpm
	ISO 9249 NET	1,040 N-m / 1,400rpm

#### ■ HYDRAULIC COMPONENTS


Hydraulic pump	Double-pump variable displacement, axial piston + gear pump
Hydraulic motor (swing)	Axial piston motor
Hydraulic motor (travel)	Axial piston motor
Control valve	6-spool multiple control valve + 1-spool control valve (swing)
Cylinders (boom, arm, and bucket)	Double acting cylinder
Return filter	Safety valve containing filter type
Oil cooler	Air-cooled type

#### ■ WEIGHT

Unit : kg (lbs)


Item	Model	SK310III		SK310LCII	
		30,100 (66,400)	31,000 (68,400)	30,700 (67,700)	31,700 (69,900)
Fully-equipped weight					
Upper machinery		13,400 (29,500)	←	←	←
Lower machinery with grouser shoe	600 (24")	11,000 (24,100)	—	11,500 (25,400)	—
	800 (32")	—	11,800 (26,100)	—	12,500 (27,600)
Attachment (6.47m(21ft.3in) boom+3.14m(10ft.4in) arm+1.2(4ft) bucket)		5,800 (12,800)	←	←	←

#### 4. TYPE OF SHOES

Shape	Model	Width of track shoe (mm(in))	Overall width of crawler (mm(ft-in))	Ground pressure (kg/cm <sup>2</sup> (psi))
Grouser(equal height) 	SK310III	600(24")	3,200( 10'6")	0.63(8.96)
		800(32")	3,400( 11'2")	0.48(6.83)
	SK310LCIII	600(24")	3,200( 10'6")	0.59(8.39)
		800(32")	3,400(11'2")	0.46(6.54)

NOTE: The 800mm (32") shoes is applied for general civil work, one is used for soft ground operation. Do not use them in rough operations, such as gravel and rock digging.

#### 5. TYPES AND COMBINATIONS OF ATTACHMENTS

HOE BUCKET 	SAE JIS Heaped capacity m <sup>3</sup> (cuyd)	Outside width of bucket mm (ft.in)		No. of teeth	Equipped with side cutter	Possibility of turnover	Weight kg (lbs)
		With side cutter	Without side cutter				
	1.20 (1.57)	1,240(4'1")	1,120(3'8")	4	Yes	Yes	950(2,090)
	1.40 (1.83)	1,430(4'8")	1,310(4'4")	5	Yes	Yes	1,070 (2,360)
	1.60 (2.09)	1,610(5'3")	1,490(4'11")	5	Yes	Yes	1,160(2,600)
	1.80 (2.35)	—	1,680(5'6")	5	Yes	Yes	1,200 (2,650)

#### ■ COMBINATIONS OF ATTACHMENTS

Type	Bucket		Applicable arm		
	SAE JIS heaped capacity m <sup>3</sup> (cuyd)	JIS-SAE struck capacity m <sup>3</sup> (cuyd)	2.55m (8ft-4in) arm	3.14m (10ft-4in) arm	4.1m (13ft-5in) arm
Hoe bucket	1.20 (1.57)	0.84 (1.10)	○	○	⊗
	1.40 (1.83)	1.00 (1.31)	○	⊗	△
	1.60 (2.09)	1.20 (1.57)	⊗	△	×
	1.80 (2.35)	1.40 (1.83)	△	×	×
	—	—	—	—	—

NOTE: ⊗ Standard combinations


- General operation: Digging and loading of sand, gravels and clay-mixed soil
- △ Light operation: Operations mainly consisting of loading of loose sand and soil (for instance, operations in paddy fields and loading of sand and gravels)
- × Not usable: Do not operate in such combinations as guarantee does not cover them.

#### ⚠ CAUTION

- If a bucket other than a hoe bucket is used to execute face shovel operation, it will cause damage to the arm and the bucket.
- The combinations other than those mentioned in the above table cannot be used in principle. For further details, contact KOBELCO.

## 6. WORKING RANGES OF ATTACHMENTS

### ■ BACKHOE ATTACHMENT




Unit ; m (ft-in)

Item		Range	Type of attachment		
			2.55m (8ft4in) arm with 1.60m <sup>3</sup> (2.09cuyd) bucket	3.14m (10ft4in) arm with 1.40m <sup>3</sup> (1.83cuyd) bucket	4.1m (13ft5in) arm with 1.20m <sup>3</sup> (1.57cuyd) bucket
A	Max digging reach		10.60 (34'9")	11.13 (36'6")	11.98 (39'4")
A'	Max. reach at ground level		10.40 (34'1")	10.94 (35'11")	11.60 (38'9")
B	Max. digging depth		6.79 (22'3")	7.38 (24'3")	8.34 (27'4")
C	Max. digging height		10.09 (33'1")	10.27 (33'8")	10.51 (34'6")
D	Max. dumping clearance		6.95 (22'10")	7.15 (23'5")	7.40 (24'3")
E	Min. dumping clearance		3.17 (10'5")	2.59 ( 8'6")	1.62 ( 5'4")
F	Max. vertical digging depth		5.39 (17'8")	6.19 (20'4")	6.98 (22'11")
G	Min. swing radius		4.61 (15'2")	4.53 (14'10")	4.54 (14'11")
H	Height at min. swing radius		8.62 (28'3")	8.43 (27'8")	8.43 (27'8")
I	Digging depth at 8'-flat bottom		6.61 (21'8")	7.22 (23'8")	8.21 (26'11")
K	Horizontal	Stroke	4.26 (14'0")	5.60 (18'4")	7.28 (23'11")
		At min.	3.64 (11'11")	2.82 ( 9'3")	2.00 ( 6'7")
L	digging stroke		3.64 (11'11")	2.82 ( 9'3")	2.00 ( 6'7")

NOTE : The figures in this table do not include the grouser or shoes (30mm (1.18in)) .

■ FACE SHOVEL ATTACHMENT



Unit, m (ft-in)

Item		Range	Type of attachment	2.55m (8ft4in) arm	3.14m (10ft4in) arm	4.1m (13ft5in) arm
				with 1.60m <sup>3</sup> (2.09cuyd) bucket	with 1.40m <sup>3</sup> (1.83cuyd) bucket	with 1.20m <sup>3</sup> (1.57cuyd) bucket
A	Max digging reach			10.74 (35'3")	11.30 (37'1")	12.12 (39'9")
A'	Max. reach at ground level			10.54 (34'7")	11.11 (36'5")	11.94 (39'2")
B	Max. digging depth			6.92 (22'8")	7.55 (24'9")	8.47 (27'9")
C	Max. digging height			10.46 (34'4")	10.70 (35'1")	10.92 (35'10")
D	Max. dumping clearance			6.91 (22'8")	7.03 (23'1")	7.34 (24'1")
D'	Max. dumping clearance (45°)			6.35 (20'10")	6.62 (21'9")	6.63 (21'9")
E	Min. dumping clearance			3.04 (10')	2.42 (7'11")	1.49 (4'11")
F	Min. swing radius			4.61 (15'1")	4.53 (14'10")	4.54 (14'11")
G	Height at min. swing radius			8.52 (27'11")	8.43 (27'8")	8.43 (27'8")
I	Digging depth at B'-flat bottom			6.75 (22'2")	7.39 (24'3")	8.35 (27'5")
K	Horizontal digging stroke	Stroke		3.01 (9'11")	4.06 (13'4")	5.43 (17'10")
		At min.		7.30 (23'11")	6.80 (22'4")	6.26 (20'6")

NOTE : The figures in this table do not include the grouser or shoes [30mm (1.18in)] .


## 7. LIFTING-UP ABILITY DIAGRAM

### (1) Calculation condition

The lifting-up ability of this drawing is indicated by pound standard. The indicated figures fall within 87% of a set pressure of the main relief valve used in the arm and the boom cylinder and 75% of static tilting load.

- 1) The load point is the fulcrum of the bucket and the bucket position is an embraced posture.
- 2) The figures on the upper stage indicate the lifting-up ability of a machine facing sideways, while the figures at the bottom stage represent a machine facing longitudinally.

**⚠** Do not use the power boost switch while lifting a load.



**⚠ WARNING**




Releasing power boost switch while lifting a load can cause unexpected lowering of load, resulting in severe injury or death. Never use power boost switch for lifting a load.

VN20T0100491

Attached to the right side of the cab interior


### (2) Lifting-up ability diagram Item No. table

Model	Pressure kgf/cm <sup>2</sup> (psid)	Arm length (M) + bucket capacity (M <sup>3</sup> )					
		2.55M+1.60M <sup>3</sup> (8ft-4in+2.09cu-yd)		3.14M+1.40M <sup>3</sup> (10ft-4in+1.83cu-yd)		4.1M+1.16M <sup>3</sup> (13ft-5in+1.52cu-yd)	
		600 (24")	800 (32")	600 (24")	800 (32")	600 (24")	800 (32")
SK310M	300 (4270)	1	5	9	13	17	19
	Heavy lift 335 (4760)	2	6	10	14	—	—
SK310LCM	300 (3270)	3	7	11	15	18	20
	Heavy lift 335 (4760)	4	8	12	16	—	—







(3) Unit: ton




(5) Unit: ton




(4) Unit: ton




(6) Unit: ton




(7) Unit : ton




(9) Unit : ton



(8) Unit : ton




(10) Unit : ton




(11)

Unit : ton




(13)

Unit : con




(12)

Unit : ton



(14)


Unit : ton






(19)

Unit : ton



(20)

Unit : ton



## 8. ENGINE SPECIFICATIONS

### SPECIFICATIONS


SK310M, SK310LM

Type	Mitsubishi 6D22-T Diesel engine		
No. of cylinders - Bore x Stroke	6 - 130mm x 140mm (5.12 in x 5.51 in)		
Total displacement	11,143cc (680 cuin)		
Compression ratio	16.0		
Output rating	230PS / 1,750 rpm (169kw / 1,750 rpm)		
Max. torque	101kgf·m (731ft·lbs) / 1,200 rpm		
High idling	1,960 ± 20 rpm		
Low idling	850 ± 30 rpm		
Injection start pressure	180kgf / cm <sup>2</sup> (2,560psi)		
Thermostat action	Opening 76.5°C Full open 90°C		
Ignition order	1-5-3-6-2-4		
Compression pressure	23kgf / cm <sup>2</sup> (336psi) at 200 rpm		
Lube oil pressure	Rating 1.5~5kgf/cm <sup>2</sup> (21.3~71.1psi)		
Fuel injection timing	17°C before the top dead point		
Valve clearance, valve action timing	Valve clearance		Open
	Intake valve	In cold state, in cold condition (1.4mm (0.055"))	18° before the top dead point
	Exhaust valve	In cold state, in cold condition (1.6mm (0.062"))	50° before the bottom dead point
			Close
			50° before the bottom dead point
			18° before the top dead point
Starter capacity	5.5kw		
Alternator capacity	800W (30A)		
Super Charging type	Turbo type		
Cooling fan drive method	Ø700 (Ø28in) suction type Belt drive pulley ratio: 0.85		
Engine oil volume	Engine body 34ℓ (8.98gal)		
Dry weight	9903g (2,180 lbs)		
Fuel consumption rate	172 ± 3% g / (ps·hr) / 1,750rpm		
Allowable tilting angles	Back and forth, right and left 35°		
Engine dimension L x W x H mm (in)	1,685 x 901 x 1,196 (66.3 x 35.5 x 47.2)		
Rotating direction	Counterclockwise as seen from flywheel side		

**ENGINE CHARACTERISTIC CURVE**

(MITSUBISHI 6D22-T)

Atmospheric condition JIS D1005-1989  
 Standard atmospheric temperature 298°K (25°C)  
 Standard dry atmospheric pressure 743mmHg (98kpa)  
 (Atmospheric pressure 750mmHg (100kpa)  
 Partial pressure of water steam 7.5mmHg (1kpa);  
 Auxiliary device Fan, air cleaner, with alternator, without silencer



$$\begin{aligned}
 \text{FUEL CONSUMPTION VOLUME} &= \frac{\text{FUEL CONSUMPTION RATE}}{0.835 \times 1000} \times \text{PS} \times \text{LOAD RATIO } (\alpha) \\
 &= \frac{172 \text{g /HP-h}}{0.835 \times 1000} \times 230 \text{ HP} \times \alpha \\
 &= 47.4 \alpha \text{ l/h}
 \end{aligned}$$





Block code No. S5LC0305E

# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### LOCATION AND WEIGHT OF COMPONENTS

TABLE OF CONTENTS

**LC03**


1. LOCATION OF COMPONENTS .....	1
2. WEIGHT OF COMPONENTS .....	2
3. TRANSPORTATION WEIGHT .....	3

 **KOBE STEEL, LTD.**

Applicable Machines  
LC03801~  
YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC0305E K

# 1. LOCATION OF COMPONENTS



## 2. WEIGHT OF COMPONENTS

Unit : kg (lbs)

Item	Model	SK310II	SK310i,ciD
Complete Machine [Std Export 600mm (24") shoe]		30,100(66,400)	30,700(67,700)
Complete Machine [Opt Export 800mm (32") shoe]		31,000(68,400)	31,700(69,900)
1	Upper Frame Assy (incl. 1.1~1.10)	13,400(29,500)	←
1.1	· Counter-weight	6,150(13,560)	←
1.2	· Cab	240(530)	←
1.3	· Boom cylinder	※ 260(570)× 2	←
1.4	· Engine	※ 990(2,180)	←
1.5	· Radiator	※ 120(260)	←
1.6	· Pump assy	175(380)	←
1.7	· Control valve	130(290)	←
1.8	· Fuel tank	※ 190(420)	←
1.9	· Hydraulic tank	※ 230(510)	←
1.10	· Swing motor & reduction unit	※ 470(1,040)	←
2	Lower frame assy (incl. 2.1~2.10)	11,000(24,100)	11,500(25,400)
2.1	· Slewing ring	570(1,260)	←
2.2	· Travel motor & reduction unit	640(1,410)× 2	←
2.3	· Idler assy	170(370)× 2	←
2.4	· Lower roller assy	60(130)× 14	60(130)× 18
2.5	· Upper roller assy	20(44)× 4	←
2.6	· Track tension assy	170(370)× 2	←
2.7	· Sprocket	80(180)× 2	←
2.8	· Swivel joint	26(57)	←
2.9	· Track guide	25(55)× 2	←
2.10	· Track link with 600mm (24") shoe assy	1,740(3,840)× 2	1,850(4,080)× 2
	· Track link with 800mm (32") shoe assy	2,190(4,830)× 2	2,320(5,120)× 2
2.10.1	· Track link	750(1,650)× 2	790(1,750)× 2
3.	Attachment (incl. 3.1~3.3)	5,800(12,800)	←
3.1	· Bucket assy [1.40 m <sup>3</sup> (1.83cu yd) STD]	1,060(2,340)	←
3.2	· Arm assy [3.14m (10ft-4in) STD] (incl. following)	1,610(3,550)	←
3.2.1	· Arm	1,070(2,360)	←
3.2.2	· Bucket cylinder	※ 250(550)	←
3.2.3	· Idler link	61(130)	←
3.2.4	· Bucket link	123(270)	←
3.2.5	· Pin (2 pcs for mounting the arm cylinder and the bucket)	110(240)	←
3.3	· Boom assy (includes the following :)	3,280(7,230)	←
3.3.1	· Boom	2,742(6,043)	←
3.3.2	· Arm cylinder	※ 500(1,100)	←
3.3.3	· Pin (mounting the arm)	38(86)	←
4.	Oil, grease, water, etc. (incl. 4.1~4.4)	900(1,980)	←
4.1	· Hydraulic oil	350(770)	←
4.2	· Fuel	480(1,060)	←
4.3	· Water	43(95)	←
4.4	· Engine oil	28(60)	←


※ Mark dry weight.

### 3. TRANSPORTATION WEIGHT

#### ● OVERALL SPECIFICATIONS OF A FULLY-ASSEMBLED MACHINE ON A TRAILER

Model	SK310D		SK310LCJ	
	Width of shoe 600mm (24")	Width of shoe 800mm (32")	Width of shoe 600mm (24")	Width of shoe 800mm (32")
Shoe of type				
Total width	3,200mm (10ft-6in)	3,400mm (11ft-2in)	3,200mm (10ft-6in)	3,400mm (11ft-2in)
Weight	30.1ton (66,400lbs)	31.0ton (68,400lbs)	30.7ton (67,700lbs)	31.7ton (69,900lbs)

NOTE : With 3.14M (10ft-4in) Arm



13-53

#### ● MACHINE LIFTING

##### ⚠ CAUTION


Improper lifting can allow load to shift and cause injury or damage.

1. Weight and instructions given herein apply to machine as manufactured by KOBELCO Inc.

#### ● LIFTING THE WEIGHT

Model	SK310D	SK310LCJ
Shoe of type	Width of shoe 600mm (24")	Width of shoe 600mm (24")
Width	3,200mm (10ft-6in)	3,200mm (10 ft-6in)
Weight	24.4 ton (53,800 lbs)	24.9ton(54,900 lbs)


2. Use proper rated cables and slings for lifting. Position crane for level machine lift.
3. Lifting cables should have sufficient length to prevent contact with machine.
4. Use the rear and front eyes on lower frame provided for lifting.



13-53


● OVERALL SPECIFICATIONS OF BOOM

	6.47m (21ft-3 in) boom
Total length × total height × total width L×H×W m (ft-in)	6.72×1.72×0.94 (22'1"×5'8"×3'1")
Weight kg (lbs)	2,970 (6,500)




● OVERALL SPECIFICATIONS OF ARM AND BUCKET

Combination	2.55m(8ft-4 in) arm + 1.60m <sup>3</sup> (2.09cuyd) bucket	3.14m(10ft-4 in) arm + 1.40m <sup>3</sup> (1.83cuyd) bucket	4.1m(13ft-5 in) arm + 1.20m <sup>3</sup> (1.57cuyd) bucket
Total length × total height × total width L×H×W m (ft-in)	5.33×1.13×1.61 (17.6"×3'8"×5'3")	5.92×1.13×1.43 (19'5"×3'8"×4'8")	6.89×1.12×1.24 (22'7"×3'8"×4'1")
Weight kg (lbs)	2,690 (5,930)	2,700 (5,950)	2,650 (5,840)




● OVERALL SPECIFICATIONS OF ARM

Length of arm	2.55m(8ft-4in)	3.14m(10ft-4 in)	4.1m(13ft-5 in)
Total length × total height × total width L×H×W m (ft-in)	3.74×1.06×0.55 (12'3"×3'6"×1'10")	4.32×0.95×0.55 (14'2"×3'1"×1'10")	5.30×0.95×0.55 (17'5"×3'1"×1'10")
Weight kg (lbs)	1,540 (3,400)	1,630 (3,590)	1,700 (3,750)



● OVERALL SPECIFICATIONS OF BUCKET

Type	Hoe bucket			
Total length × total height × total width L×H×W m (ft-in)	1.60×1.49×1.24 (5'3"×4'11"×4'1")	1.60×1.49×1.43 (5'3"×4'11"×4'8")	1.60×1.49×1.61 (5'3"×4'11"×5'3")	1.60×1.49×1.68 (5'3"×4'11"×5'6")
Weight kg (lbs)	950 (2,090)	1,070 (2,360)	1,160 (2,540)	1,200 (2,650)
SAE(JIS) Bucket capacity m <sup>3</sup> (cu yd)	1.20 (1.57)	1.40 (1.83)	1.60 (2.09)	1.80 (2.35)







# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

## MAINTENANCE STANDARDS AND TEST PROCEDURES

### TABLE OF CONTENTS

1. HOW TO USE THE MAINTENANCE STANDARD AND CAUTIONS TO BE EXERCISED .....	1
2. MEASURING HYDRAULIC PRESSURE	
2.1 Performance Inspection Standard .....	2
3. MECHATRONIC ADJUSTMENTS	
3.1 Mechatronic Adjustments .....	3
3.2 Preparation .....	3
3.3 A Adjustment Procedure .....	4
3.4 B Adjustment Procedure .....	6

**LC04**

Applicable Machines

LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC0405E K

# 1. HOW TO USE THE MAINTENANCE STANDARD AND CAUTIONS TO BE EXERCISED

## (1) Application

- 1) When the machine is new ;  
Confirm that the performances are in accordance with standard specifications as compared to the performance standards
- 2) At specific self inspection ,  
Use the data for the criterion, for the purpose of correction, adjustment and replacement
- 3) When performances are deteriorated ;  
Determine whether it is caused by a fault or end of service life after long hours of operation, to be used for safety and economical considerations.
- 4) When main components are replaced :  
For example, use data to restore performances of pumps and others.

## (2) Terminology

- 1) Standard values ;  
Values to be used to condition or assemble a new machine. Where special notes are not given, these values represent standard specifications (machine with standard attachments and standard shoes)
- 2) Reference values for remedy ;  
Values at which readjustment is required. Adjust immediately if the value is close to the service limit value.
- 3) Serviceability limit ;  
This is the limit value at which reconditioning is impossible without replacement of parts. If the value is expected to exceed the service limit before next inspection and correction are performed, replace the parts immediately. If the part is used beyond the limit, chances of trouble increase, ultimately resulting in a breakdown of the machine. Avoid operating the machine beyond this service limit.

## (3) Cautions to be Exercised at Judgment

- 1) Evaluation of measured data ;  
Disagreement of measuring conditions, variations of data peculiar to a new machine, and measuring errors are to be evaluated. Determine generally at what levels measured values are located, instead of determining whether or not values fall within or run out of the reference values.
- 2) Determining correction, adjustment or replacement ;  
Machine performances deteriorate with time as parts wear and some deteriorated performances may be restored to new levels of machine. Therefore, determine correction, adjustment or replacement, depending upon the operating hours, kind of work and circumstances in which the machine is placed, and condition the machine performances to its most desirable levels.

## (4) Other Cautions to be Exercised

- 1) Parts liable to degrade ;  
Rubber products, such as, hydraulic hoses, O rings, and oil seals deteriorate with time ; replace them at regular intervals or at overhauls.
- 2) Parts requiring regular replacement ;  
The hoses that are necessary to secure safety, we designate very important parts (V.I.P) and recommend that they should be replaced regularly.
- 3) Inspection and replacement of oils and greases :  
In performing maintenance, it is necessary for the user to familiarize himself with how to handle the machine safely, cautions to be exercised and inspection / lubrication procedures.  
Refer to the operators manuals as well.

## 2. MEASURING HYDRAULIC PRESSURE

### 2.1 PERFORMANCE INSPECTION STANDARD (SK310-III, SK310LC-III)

Table 1

(NOTE: Take measurement in the II mode, unless otherwise specified.)

(The standard tolerance shall be an allowable range in field measurements.)

Inspection item	Pressure measurement			Specification	Unit	Adjusted point	Measuring Condition, Function		
	Location	Size	Port						
Standard measuring condition	Identifiability of hydraulic oil			NAS 7-9		Class	Sampling		
	Temperature of hydraulic oil			46~66	113~131	℃	Ambient temperature		
	Coolant temperature			60~90	140~194	(°F)	-10℃~50℃ (14°F~122°F)		
	Engine revolution	Low idle			850~900		rpm	Full throttle	
		II or III mode III idle			1900~1970				
		S Mode			1650~1750				
FF mode			1350~1450						
Auto-renal			1000~1100						
Pilot circuit	Primary pressure			Gear pump	PS	50~53	(7.0~7.5)	PR1	II Mode, E/G III idle
	High pressure circuit	Main relief pressure	Travel	TRF	#1	350~355	(4850~5050)	TR1	II Mode, E/G III idle
LRF				#2					310~345
Booms			TRB		#1	300~305	(4070~4300)	MR1	
			FRONT	#2					320~315
Attachments			RII		#1	320~315	(4350~4760)	MR3	
			LII	#2					320~315
Port relief pressure		Bucket	R		#1	320~315	(4350~4760)	RV4	
			II	#2					320~315
		Booms	R		#1	320~315	(4350~4760)	RV6	
			II	#2					320~315
		Arm	R		#1	320~315	(4350~4760)	RV10	
			II	#2					320~315
Swing		RII	#2		295~325	(4030~4620)	RV12	Bucket back	
		LII		#1				350~360	(4680~5120)
Travel	RII	#2	350~360		(4680~5120)	RV14	Simultaneous RII/LII		
	LII								
Low pressure relief	Negative control pressure								
			RII	PI1	32~47	(435~670)		II Mode, E/G III idle	
			LII	PI2	17~18	(240~255)		S Mode, E/G III idle; volume switch up & low	
Proportional solenoid valve	Variable loading mode	UP	P2	11.5~12.5	(165~180)				
		LOR							
		RESS	RII	0~3	(0~45)				
	Release								
	Boost								

### 3. MECHATRONIC ADJUSTMENTS

#### 3.1 MECHATRONIC ADJUSTMENTS

If part is to be replaced	Perform	
	Adjust A	Adjust B
Mechatronic controller (KPSS)	○	○
Stepping motor	○	—
Electromagnetic proportional reducing valve for loading mode	—	○

When the above-mentioned parts have been replaced, do not fail to perform mechatronic adjustment. That is to say, adjustment A refers to the adjustment of engine revolution, while adjustment B represents the adjustment of the loading mode. These adjustments consist of adjustment procedure, adjustment timing, etc. Always observe the following procedures for adjustment.

#### 3.2 PREPARATION

- 1) Warm up the engine.
- 2) Stop the engine and place the key to "OFF" position.

**NOTE:** Confirm the E/G manual stop knob is pushed in.

**⚠** The power supply turns off four seconds after the engine key is turned to "OFF". Be careful if the engine key is set to "OFF" while performing mechatronic adjustment. If the internal adjusting switch (3 of Fig. 2) is moved over when the power is on, adjustment data may be lost.

- 3) Remove the cover from KPSS controller.
- 4) Before performing each adjustment, turn the switch on the mechatronic controller toward "TEST" with the engine key switch OFF. This is common to both the A and B adjustments.

If you turn on the engine key switch with the engine stopped and the controller switch at "TEST", the auto accel lamp (LED on the cluster gauge) lights continuously. Lighting of the lamp confirms that the switch is at "TEST".

#### A. ADJUSTMENT START CONDITIONS (1)

① Internal adjustment switch	Test
② Working mode	H mode
③ Auto accel	ON
④ Accel potentiometer	Low idling
⑤ Engine	Stop (Key ON position)




Fig. 1 Location of KPSS controller




Fig. 2 KPSS controller



- 3) With the governor lever pressed, push the adjusting harness pushbutton. (Momentary switch) on pull out IP coupler. So electric power is now supplied to the stepping motor whereby it is fixed in the high idle position.
- 4) After the lever is fixed in the high idle position, make sure of the clearance of 0.2mm (0.008in)
- 5) If the clearance is out of the clearance standard, clearance adjustment may be carried out, as follows :
  - When the clearance is large ;
    - If the auto accel switch is turned on and the buzzer stop switch is pressed one time, the clearance decreases by about 0.04mm (0.002in).
  - When the clearance is small ;
    - If the auto accel switch is turned off and the buzzer switch is pressed once, the clearance increases by about 0.04mm (0.002in).
- 6) If the adjusting harness pushbutton is pushed or IP coupler pulled out after the clearance adjustment, the stepping motor memorizes the high idle position and returns to the start position.
- 7) Memorization is complete when the indication on the multi display has changed from [CPU] to [Time].





Fig. 6 Time indication on multi display



Fig. 7 CPU indication on multi display



Fig. 8 Auto accel select switch



← BUZZER STOP

← TIME SET SWITCH

Fig. 9 Buzzer stop switch

This completes the positioning of the E/G High idle position.

\* The adjust harness switch is of momentary type with a normally closed contact; it is opened if the switch is pressed and it is shorted if the switch is let free.

Where there is no adjust harness provided, disjoint the IP coupler, instead of pressing the switch. Joint the IP coupler instead of turning off the switch.

3) Setting (matching) the engine revolutions.

- 1) Run the engine until, the E/G coolant temperature rises to the standard  $75 \pm 15^\circ\text{C}$  ( $167 \pm 27^\circ\text{F}$ ).
- 2) Reset the adjustment A start condition (2).
- 3) Depress the adjustment harness pushbutton and release it after 3 to 5 seconds when CPU is displayed.
- 4) It takes about three minutes for the stepping motor to increase from a speed range lower than low idle to the high idle automatically. The controller reads the change in revolution and stores it.
  - [CPU] is indicated on the multi display when the stepping motor is running itself. If [Time] is indicated, the adjustment condition may be wrong or the pushbutton adjustment timing is out of standard. Repeat the engine revolution setting procedure once again.
- 5) This completes adjustment A. Turn the engine key to OFF, disconnect the 1P coupler for the adjusting harness and reconnect the 1P coupler for the controller.
- 6) Last return the internal adjustment switch in the controller to the "RUN" side without fail and refit controller cap (2) (Fig. 2).

3.4 B ADJUSTMENT PROCEDURE

- (1) Procedure for setting the secondary pressure of loading mode electromagnetic proportional reducing valve.
  - 1) Raise the temperature of the hydraulic oil to  $50 \pm 5^\circ\text{C}$  ( $122 \pm 9^\circ\text{F}$ ).
  - 2) Remove plug  $\phi 4$  at the secondary pressure port PZ of the loading mode electromagnetic proportional reducing valve attached to the main pump. Then install a  $70\text{kgf/cm}^2$  ( $1000\text{psi}$ ) pressure gauge. (Fig.15)
  - 3) After making sure that the engine key is "OFF", pull out the 1P coupler of the KPSS controller and connect the 1P coupler for the adjusting harness.
  - 4) Set the internal adjusting switch of the KPSS controller to the test side. (Fig. 2)
  - 5) Set the adjustment B start condition.
  - 6) Depress the adjustment harness pushbutton and release it after 3 to 5 seconds.
    - If [CPU] is indicated on the multi display, it means that the ADJ. mode has been entered. If [Time] is indicated instead of [CPU], the adjustment condition is wrong or pushbutton adjustment timing is off. Repeat the adjustment procedure once again.

A. Adjustment start conditions (2)

Internal adjustment switch	Test
Working mode	II mode
Auto accel	OFF
Accel potentiometer	Low idle
Engine	Running

Self run (about three minutes)




Fig. 10 Self running of stepping motor

B. Adjustment start conditions

Internal adjustment switch	Test
Work mode	S mode
Auto accel	OFF
Accel potentiometer	Hi idle
Engine	Running



Fig. 11 Secondary port PZ of electromagnetic proportional reducing valve for loading mode




Fig. 12 Loading mode switch



- 7) Raise the boom fully and hold in this position (operating lever at full stroke).
- 8) Turn the loading mode switch from the upper limit to the lower limit (little by little) and read on the pressure gauge, the change in the secondary pressure of the electromagnetic proportional reducing valve. (Pressure decreases by clockwise turning and increases by counter-clockwise turning).
- 9) When the secondary pressure has reached the upper standard set value (close to the black mark of the upper limit), press the adjusting harness pushbutton. The upper limit value is stored now.
- 10) Then, turn the loading mode switch close to the lower limit black mark and when the secondary pressure arrives at the standard lower limit set value, push the adjusting harness pushbutton.

This stores the lower limit value.

- The indication on the multi display changes from [CPI] to [Time].

- 11) This completes adjustment B. Turn the engine key to [OFF]. Disconnect the 1P coupler for the adjusting harness and reconnect the 1P coupler for the controller.
- 12) Lastly, pull the internal adjusting switch in the controller to this side (RUN) and refit the controller cap (2) back in place with the key in the off position. (Fig. 2)

Set standard pressure of  
electromagnetic proportional reducing valve

Model	Set pressure ①	Set pressure ②
SK310II	17.5(249)	12.0(171)
SK430III	19.0(270)	14.0(199)

Units : kg/cm<sup>2</sup> (psi)



**KOBELCO****SHOP MANUAL****SK310**  
**SK310<sup>LC</sup>****WORKING STANDARD****TABLE OF CONTENTS**

1. TIGHTENING TORQUES FOR CAPSCREWS AND NUTS	1
2. TIGHTENING TORQUES FOR NUTS AND SLEEVES	2
3. SPECIAL SPANNER FOR TUBE	3
4. SCREW SIZE AND TIGHTENING TOOL SIZE	4
5. INTERNATIONAL UNIT SYSTEM	5
6. DETAILS OF SUCTION STOPPER	6
7. TABLE OF THREAD LOCK AND SEALANT	7
8. SPECIAL TOOL FOR BUCKET TOOTH	7

**LC07****KOBE STEEL, LTD.**

Applicable Machines  
LC03801~  
YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC0705E K

# 1. TIGHTENING TORQUES FOR CAPSCREWS AND NUTS

Tables 1 and 2 indicate tightening torques applicable to cases where no special note is given.

Overtightening of bolts may result in a twist-off

and a fracture under load.

Undertightening may lead to a loosening or loss of bolts. Always tighten bolts to proper torques.

Table 1 Standard tightening torques for metric coarse screw threads kgf-m (ft-lbs)

Classification	4		7		10	
	No lubrication	Oil lubrication	No lubrication	Oil lubrication	No lubrication	Oil lubrication
M 6 P=1	0.45±0.05 (3.3±0.4)	0.38±0.04 (2.7±0.3)	0.98±0.1 (7.1±0.7)	0.83±0.06 (6.0±0.6)	1.77±0.18 (13±1)	1.5±0.15 (11±1)
M 8 P=1.25	1.09±0.11 (7.9±0.8)	0.92±0.09 (6.7±0.7)	2.4±0.2 (17±1)	2.0±0.2 (14±1)	4.3±0.4 (32±3)	3.6±0.4 (26±3)
M10 P=1.5	2.2±0.2 (16±1)	1.88±0.18 (13±1)	4.7±0.5 (34±4)	4.0±0.4 (29±3)	8.5±0.9 (61±7)	7.2±0.7 (52±5)
M12 P=1.75	3.7±0.4 (27±3)	3.2±0.3 (23±2)	6.1±0.8 (45±6)	6.6±0.7 (49±5)	14.6±1.5 (110±11)	12.3±1.2 (89±9)
M14 P=2	5.9±0.6 (43±4)	5.0±0.5 (36±4)	12.8±1.3 (93±9)	10.8±1.1 (78±8)	23±2 (170±14)	19.5±1.9 (140±14)
M16 P=2	9.0±0.9 (66±7)	7.6±0.7 (65±5)	19.5±2.0 (140±14)	16.4±1.6 (120±12)	35±4 (250±29)	29±3 (210±22)
M18 P=2.5	12.4±1.2 (90±9)	10.5±1.0 (76±7)	27±3 (200±22)	23±2 (170±14)	49±5 (350±36)	41±4 (300±29)
M20 P=2.5	17.5±1.7 (130±12)	14.7±1.4 (110±10)	38±4 (270±28)	32±3 (230±22)	68±7 (490±51)	57±6 (410±43)
M22 P=2.5	23±2 (170±14)	19.6±2.0 (140±14)	51±5 (370±36)	43±4 (310±28)	92±9 (670±65)	77±8 (560±58)
M24 P=3	30±3 (220±22)	24±3 (170±22)	65±7 (470±51)	63±5 (380±36)	118±12 (850±87)	96±10 (690±72)
M27 P=3	44±4 (320±29)	36±3 (260±22)	96±10 (690±72)	78±8 (560±58)	173±17 (1200±120)	140±14 (1000±100)
M30 P=3.5	60±6 (430±43)	50±5 (360±36)	131±13 (950±94)	110±11 (800±80)	235±24 (1700±170)	196±20 (1400±140)
M33 P=3.5	81±8 (590±58)	68±7 (490±51)	176±16 (1300±130)	145±15 (1100±110)	317±32 (2300±230)	266±27 (1900±200)
M36 P=4	105±10 (760±72)	88±9 (640±65)	227±25 (1600±170)	190±19 (1400±140)	408±41 (3000±300)	343±34 (2500±250)

Table 2 Standard tightening torques for metric fine screw threads kgf-m (ft-lbs)

Classification	4		7		10	
	No lubrication	Oil lubrication	No lubrication	Oil lubrication	No lubrication	Oil lubrication
M 8 P=1	1.15±0.11 (8.3±0.8)	0.97±0.1 (7.0±0.7)	2.5±0.2 (18±1)	2.1±0.2 (15±1)	4.5±0.4 (33±3)	3.8±0.4 (27±3)
M10 P=1.25	2.3±0.2 (17±1)	1.91±0.19 (14±1)	4.9±0.5 (35±4)	4.2±0.4 (30±3)	8.9±0.9 (64±7)	7.5±0.7 (54±5)
M12 P=1.25	4.0±0.4 (29±3)	3.4±0.3 (25±2)	8.7±0.9 (63±7)	7.3±0.7 (53±5)	15.7±1.6 (110±12)	13.2±1.3 (95±9)
M16 P=1.5	9.4±0.9 (68±7)	7.9±0.8 (57±6)	20±2 (140±14)	17.2±1.7 (120±12)	37±4 (270±29)	31±3 (220±22)
M20 P=1.5	19±1.9 (140±14)	15.8±1.6 (110±12)	41±4 (300±29)	34±3 (250±22)	74±7 (540±51)	62±6 (450±43)
M24 P=2	32±3 (230±22)	27±3 (200±22)	70±7 (510±51)	58±6 (420±43)	126±12 (910±87)	105±10 (760±72)
M30 P=2	65±6 (470±43)	54±5 (390±30)	142±14 (1000±100)	118±12 (850±87)	255±26 (1800±190)	212±21 (1500±150)
M36 P=3	109±11 (790±80)	91±9 (660±65)	238±23 (1700±170)	198±20 (1400±140)	428±43 (3100±310)	357±36 (2600±260)

## 2. TIGHTENING TORQUES FOR NUTS AND SLEEVES

Table 3 indicates standard tightening torques applicable to cases where no particular note is given.



Overtightening or undertightening of nuts and

sleeves in bite type tube fittings may develop oil leaks through pipe connections. Always tighten nuts and sleeves to proper torques.

Table 3

Manufacturer's name	Working pressure kgf/cm <sup>2</sup> (psi)	Tube size OD×thickness mm (in)	Opposing flats	Tightening torque kgf-m (ft-lbs)
Nippon A.M.C.	300 (4270)	10×1.5 (0.394×0.059)	19	5±1 (36±7)
		15×2.0 (0.591×0.079)	27	12±1.2 (87±9)
		18×2.5 (0.709×0.098)	32	15±1.5 (108±11)
		22×3.0 (0.866×0.118)	36	22±2.2 (159±16)
		28×4.0 (1.10×0.157)	41	28±2.8 (203±20)
Ihara Koutu	300 (4270)	35×5.0 (1.38×0.197)	55	45±4.5 (325±33)

Table 4

SLEEVE			NUT			
						
Tube size Ød	Parts No.		Tube size Ød	Opposing flats B	Parts No.	
	Ihara Koutu	Nippon A.M.C.			Ihara Koutu	Nippon A.M.C.
6	ZF93S06000	-	6	14	ZF93N06000	-
8	ZF93S08000	-	8	17	ZF93N08000	-
10	ZF93S10000	ZA93S10000	10	19	ZF93N10000	ZA93N10000
12	ZF93S12000	-	12	22	ZF93N12000	-
15	ZF93S15000	ZA93S15000	15	27	ZF93N15000	ZA93N15000
18	ZF93S18000	ZA93S18000	18	32	ZF93N18000	ZA93N18000
22	ZF93S22000	ZA93S22000	22	36	ZF93N22000	ZA93N22000
28	ZF93S28000	ZA93S28000	28	41	ZF93N28000	ZA93N28000
32	ZF93S32000	-	32	50	ZF93N32000	-
35	ZF93S35000	ZA93S35000	35	55	ZF93N35000	ZA93N35000
38	ZF93S38000	-	38	60	ZF93N38000	-


### 3. SPECIAL SPANNER FOR TUBE

Table 5

Applicable tube diameter mm (in)	Part No	Opposing flats of a hex- agon nut mm	Drawing of a special spanner mm (in)
15 (0.591)	2421T160	27	<p>70 (2.76) 6 (0.236) 16 (0.630) PART-No. 40 (1.57) HEX27 22 (0.866) <math>\varnothing 12.7^{+0.1}_{-0.1}</math> (0.500 <math>\pm 0.004</math>)</p>
18 (0.709)	2421T136	32	<p>70 (2.76) 22 (0.866) 19 (0.748) PART-No. 42 (1.65) HEX32 22 (0.866) <math>\varnothing 12.7^{+0.1}_{-0.1}</math> (0.500 <math>\pm 0.004</math>)</p>
22 (0.866)	2421T130	36	<p>70 (2.76) 48 (1.89) 23 (0.906) PART-No. 11.5 (0.453) HEX36 22 (0.866) <math>\varnothing 12.7^{+0.1}_{-0.1}</math> (0.500 <math>\pm 0.004</math>)</p>
28 (1.10)	2421T115	41	<p>109 (4.29) 60 (2.36) 29 (1.14) PART-No. 14.5 (0.571) HEX41 22 (0.866) <math>\varnothing 12.7^{+0.1}_{-0.1}</math> (0.500 <math>\pm 0.004</math>)</p>
36 (1.38)	2421T314	55	<p>90 (3.54) 81 (3.19) 41 (1.61) PART No. 20 (0.787) HEX55 <math>\varnothing 20</math> (0.787)</p>

## 4. SCREW SIZE AND TIGHTENING TOOL SIZE

(1) Hexagon bolt



(2) Socket bolt




Table 6-1

NOMINAL SCREW SIZE	B mm
(d)	STANDARD DIMENSION
M6	10
M8	13
M10	17
M12	19
(M14)	(22)
M16	24
(M18)	(27)
M20	30
(M22)	32
M24	36
(M27)	(41)
M30	48
M36	55
M42	65
M45	70

Table 6-2

NOMINAL SCREW SIZE	B mm
(d)	STANDARD DIMENSION
M48	75
M56	85
(M60)	90
M64	95
(M68)	100
M72	105
M76	110
M80	115

Table 7

NOMINAL SCREW SIZE	B mm
(d)	STANDARD DIMENSION
M6	5
M8	6
M10	8
M12	10
M14	12
M16	14
(M18)	14
M20	17
M24	19
M30	22
M36	27
M42	32
M48	36

(3) Plug

T SCREW






Table 8

T SCREW	B mm
PT 1/8	5
PT 1/4	6
PT 3/8	8
PT 1/2	10
PT 3/4	14
PT 1	17
PT1 1/4	22
PT1 1/2	22

Table 9

T SCREW	B mm	O RING PART NO
PF 1/4	19	ZD12P01100
PF 3/8	22	ZD12P01400
PF 1/2	27	ZD12P01800
PY 3/4	36	ZD12P02400
PF 1	41	ZD12P02900



## 5. INTERNATIONAL UNIT SYSTEM

### Introduction


Although this manual uses the JIS unit system, we will introduce the international unit system in the following as there are Iron and Steel Association and other organizations which adopted the international unit system. Given here in under are an except of the units that are related to this manual :

#### 1. Etymology of SI Units

French : Le Systeme International d' Unites

English : International System of Units

#### 2. Construction of SI Unit System



#### (1) Basic Units

Table 10

QUANTITY	DESIGNATION	SIGN
Length	Meter	m
Mass	Kilogram	kg
Time	Second	s
Current	Ampere	A
Thermodynamic temperature	Kelvin	K
Gram molecule	Mol	mol
Luminous intensity	Candela	cd

#### (2) Supplementary Units

Table 11

QUANTITY	DESIGNATION	SIGN
Plane angle	Radian	rad
Solid angle	Steradian	sr

#### (3) Derived Units of Basic Units

Table 12

QUANTITY	DESIGNATION	SIGN
Area	Square meter	m <sup>2</sup>
Volume	Cubic meter	m <sup>3</sup>
Velocity	Meter per second	m/s
Acceleration	Meter per second / second	m/s <sup>2</sup>
Density	Kilogram per cubic meter	kg/m <sup>3</sup>

#### (4) Derived Units bearing Peculiar Designations

Table 13

QUANTITY	DESIGNATION	SIGN	DERIVED UNIT
Frequency	hertz	Hz	1 Hz = 1 s <sup>-1</sup>
Force	newton	N	1 N = 1 kgf/m/s <sup>2</sup>
Pressure, Stress	pascal	Pa	1 Pa = 1 N/m <sup>2</sup>
Energy, Work, Quantity of heat	joule	J	1 J = 1 N·m
Power, Motive power, Electric power	watt	W	1 W = 1 J/s
Charge, Quantity of electricity	coulomb	C	1 C = 1 A·s
Potential, Voltage, Electromotive force	volt	V	1 V = 1 J/C (1 W/A)
Quantity of static electricity, Capacitance	farad	F	1 F = 1 C/V
Electric resistance	ohm	Ω	1 Ω = 1 V/A
Celsius temperature	celsius degree or degree	°C	
Illuminance	lux	lx	1 lx = 1 lumen/m <sup>2</sup>

#### (5) Prefixes of SI

Table 14

PREFIX		POWER
DESIGNATION	SIGN	
Giga-	G	10 <sup>9</sup>
Mega-	M	10 <sup>6</sup>
Kilo-	k	10 <sup>3</sup>
Hecto-	h	10 <sup>2</sup>
Deca-	da	10
Deci-	d	10 <sup>-1</sup>
Centi-	c	10 <sup>-2</sup>
Milli-	m	10 <sup>-3</sup>
Microm-	μ	10 <sup>-6</sup>
Nano-	n	10 <sup>-9</sup>
Pico-	p	10 <sup>-12</sup>

#### 5. Unit Conversion Table

Table 15

QUANTITY	JIS	SI	REMARKS
Mass	kgf	kg	
Force	kgf	10N	9.807N
Torque	kgf·m	10N·m	9.807N·m
Pressure	kgf/cm <sup>2</sup>	0.1MPa	0.098MPa
Motive power	PS	0.7355kw	
Revolution	rpm	min <sup>-1</sup>	r/min

## 6. DETAILS OF SUCTION STOPPER

### 6.1 COMPONENTS OF SUCTION STOPPER

No.	NAME	PARTS No.	Q'ty
	SUCTION STOPPER ASSY	24100P973F3	
1	ROD	2420T4660D1	1
2	NUT	ZN15C08007	1
3	COVER	2414T2123D3	1
4	O RING	46Z01D7	1




Fig. 20 Components of suction stopper





Fig. 25 Dimension of suction stopper

### 6.2 MACHINE MODELS TO WHICH SUCTION STOPPER IS APPLICABLE

Table 16

Part No. of suction stopper	Applicable model
	SK Series
24100P973F3	SK300, SK400 SK300-2, SK400-2 SK310M, SK430M

## 7. TABLE OF THREAD LOCK AND SEALANT

Table 17

SERVICE	MANUFACTURER		FEATURES
	LOCKTITE	THREE-BOND	
Screw locking compound	#242	1350K	Low strength
	#271	1306	High strength
Sealing compound	#515	1215	Sealing

## 8. SPECIAL TOOL FOR BUCKET TOOTH

Table 18

Applicable	Part No.	Special Tool
Tooth S18 over	2421N225	



# KOBELCO

## SHOP MANUAL

# SK310<sub>III</sub>

# SK310<sub>LC</sub><sub>III</sub>

### — STANDARD MAN-HOUR TABLE —

#### TABLE OF CONTENTS

1. STANDARD MAN-HOUR TABLE	
1.00 Upper .....	1
1.01 Cab & guard .....	1
1.02 Control .....	2
1.03 Hydraulic line .....	2
1.04 Power Plant .....	3
1.05 Electric .....	3
1.06 Lower .....	4
1.07 Attachment .....	5
2. STANDARD WORKING TIME TABLE FOR THE MAINTENANCE OF ENGINE	
2.1 Cooling System .....	8
2.2 Electrical System .....	9
2.3 Engine .....	11
2.4 Exhaust System .....	16
2.5 Fuel System .....	17
2.6 Auxiliary Equipment (Compressor) .....	18

**LC08**

## Applicable Machines

LC03801~

YC01101~

### (1) Standard Man-Hour

- 1) The standard man-hour apply where the serviceman with about five year's experience with general construction machinery performs maintenance operation at normal speed, using an appropriate number of personnel and jigs/tools.
- 2) The standard man-hour does not include the setup time for repair, the time necessary to explain to the customer and painting, but those times may be added depending upon the contents of work.

### (2) How to Look at Man-Hour Table

- 1) Units of working time  
The working time is indicated in decimal numbers; 6min. = 0.1hour.
- 2) Formula for calculating man-hour  
 $\text{Man-hour} = \text{working hour} \times \text{the number of workers}$ , ( $\text{working time} = \text{man-hour} \div \text{the number of workers}$ )
- 3) Where more than one operation is performed at the same time, the standard man-hour for each of the operations shall be added.

Revision	Date of Issue	Remarks
First edition	March, 1996	SGLC0802E K

# 1. STANDARD MAN-HOUR TABLE

No.	TIPPER	LOCATION	WORK TO BE DONE	UNIT	REMARK	SK310III SK410c:III	SK450.II SK450c:II
	1	Swing motor (reduction gear) ASS'Y	Detach/attach	1 pc.		7.0	9.0
	- 2	Swing reduction gear	O/H	1 pc.	Incl. removal.	6.0	9.0
	- 3	Swing motor (single)	O/H	1 pc.	Incl. removal.	5.0	6.0
	- 4	Swing bearing	Detach/attach	1 pc.		12.0	39.0
	- 5	Counterweight	Detach/attach	1 pc.	lifting jig and tool required.	3.0	4.0
	- 6	Under cover	Detach/attach	1 pc.		0.8	0.9
	- 7	Left side cover	Detach/attach	1 pc.		0.5	0.6
	- 8	Fuel tank ASS'Y	Detach/attach	1 pc.	Incl. emptying fuel.	5.0	4.0
00	- 9	Water separator	Replace	1		0.3	-
	- 10	Sending unit	Replace	1		0.6	+
	- 11	Hydraulic oil tank ASS'Y	Detach/attach	1 pc.	Incl. emptying Hydraulic oil.	5.0	6.0
	- 12	Suction strainer	Replace	1		0.3	-
	- 13	Return filter element	Replace	1		0.5	+
	- 14	Hydraulic oil	Replace	1 pc.	Incl. cleaning in tank	3.0	4.0
	- 15	Level gauge	Replace	1		0.8	+
	- 16	Drum plug	Replace	1		0.3	-
	- 17	Upper frame ASS'Y	Detach/attach	1 pc.		26.0	30.0
	- 18	Engine oil	Replace	1 pc.		0.5	+
No.	CAB & GUARD						
	- 1	Cab ASS'Y	Detach/attach	1 pc.	Fix with eight bolts.	4.0	-
	- 2	Door	Detach/attach	1 pc.		1.0	+
	- 3	Door lock	Replace	1		1.0	+
	- 4	Window washer tank	Replace	1		0.5	+
01	- 5	Operator seat	Detach/attach	1		1.0	-
	- 6	Guard ASS'Y	Detach/attach	1 set	10,11,12,13	5.0	4.0
	- 7	Engine guard (rear cover)	Detach/attach	1		0.8	0.5
	- 8	Front guard (Incl. battery cover)	Detach/attach	1		0.8	0.9
	- 9	Right side cover	Detach/attach	1		0.8	0.9

No.	CONTROL	LOCATION	WORK TO BE DONE	UNITS	REMARK	SK3100 SK3100r III	SK4000 SK4000r III
02	- 1	Operating lever stand	Detach/attach	1/pc side		2.0	+
	- 2	Pilot valve (ATT swing)	Detach/attach	1		1.5	+
	- 3	Travel pilot valve	Detach/attach	1		1.0	+
	- 4	Operating lever	Replace	1		0.3	+
	- 5	Travel lever	Replace	1		0.3	+
	- 6	Solenoid valve	Detach/attach	1	Lever lock, FC, Travel 2-speed, Travel deflection, ATT boost pressure, Swing P/B	1.0	+
	- 7	Proportionate valve	Replace	1	QMIN, Travel straight valve, QMAX, cut valve P1, Cut valve P2	1.0	+
	- 8	Accumulator/pilot relief manifold	Adjust	1 set		0.5	+
	- 9	Multi control valve	Detach/attach	1 pc.		3.0	+
	- 10	Multi control valve	Oil	1 set	Excl.detachment/attachment	2.0	+
	- 11	Controller	Detach/attach	1 pc.	Top stage (for mechatronic control) Middle stage (for cluster gauge) Bottom stage (for power window)	0.5 1.0	+
No.	HYDRAULIC LINE						
03	- 1	Hydraulic pump ASS'Y	Detach/attach	1 pc		6.0	+
	- 2	Pump coupling	Replace	1 set		1.5	+
	- 3	Suction hose	Replace	1		2.0	+
	- 4	Delivery hose	Replace	1		1.0	+
	- 5	Pilot valve	Detach/attach	1 pc.		1.0	+
	- 6	Filter element (line filter)	Replace	1	SK60 is direct coupled with return filter.	0.5	+
	- 7	Main control valve	Detach/attach	1 pc		10.0	11.0
	- 8	Main relief valve	Replace	1		1.0	+
	- 9	Overload relief valve	Replace	1		1.0	+
	- 10	Option valve	Detach/attach	1 pc		3.0	+
	- 11	Main relief valve	Replace	1		1.0	+
	- 12	Overload relief valve	Replace	1		1.0	+



No.	POWER PLANT	LOCATION	WORK TO BE DONE	UNIT	REMARK	S5310W SK310rM	SK436L SK430rL
04	- 1	Engine ASS'Y	Detach/attach	1 pc.		12.0	←
	- 2	Injection pump	Detach/attach	1 pc.		3.0	←
	- 3	Valve clearance	Adjust	1 pc.		2.0	←
	- 4	Nozzle	Replace	1		1.5	←
	- 5	Fuel hose	Replace	1		1.0	←
	- 6	Radiator ASS'Y	Detach/attach	1 pc.		6.0	*
	- 7	Radiator hose (upper)	Replace	1		0.8	←
	- 8	Radiator hose (lower)	Replace	1		1.5	←
	- 9	Sub tank	Replace	1		0.6	←
	- 10	Pan belt	Replace	1 pc.		2.0	←
	- 11	Radiator fan	Replace	1		1.5	←
	- 12	Radiator cooling water	Replace	1 pc.		0.8	←
	- 13	Oil cooler	Detach/attach	1 pc.		3.0	←
	- 14	Muffler	Replace	1		3.0	←
	- 15	Air cleaner	Replace	1		1.5	←
	- 16	Fuel element	Replace	1		0.5	*
	- 17	Oil element	Replace	1		0.6	←
	- 19	Turbocharger	Detach/attach	1 pc.		1.6	←
	05	Electrical					
- 1		Battery	Replace	1		0.5	←
- 2		Battery cable	Replace	1		0.2	←
- 3		Battery relay	Replace	1		0.6	←
- 4		Relay ASS'Y	Replace	1 pc.	Head, work lamps (front, rear), Swing flasher	0.6	←
- 5		Relay	Replace	1	Heater, starter, Key switch, Safety relay	0.5	*
- 6		Water temp. sensor	Replace	1		0.6	←
- 7		Oil pressure switch	Replace	1		0.5	←
- 8		Swing flasher	Replace	1		0.5	←
- 9		Boom work lamp	Replace	1		0.8	←
- 10		Upper frame work lamp	Replace	1		0.6	←
- 11		Oilstar gauge	Detach/attach	1 pc.		1.0	←
- 12		Flour	Detach/attach	1 pc.		2.0	*
- 13		Governor motor	Replace	1 pc.		1.0	←
- 14		Alternator	Detach/attach	1 pc.		1.0	←
- 15		Starter motor	Detach/attach	1 pc.		1.0	←
- 16		Air-conditioner ASS'Y	Detach/attach	1 pc.		6.0	←
- 17		Compressor	Detach/attach	1 pc.		1.0	←
- 18		Condenser	Detach/attach	1 pc.		1.0	←
- 19	Evaporator	Detach/attach	1 pc.		2.0	←	

N <sup>o</sup>	LOWER	LOCATION	WORK TO BE DONE	UNIT	REMARK	SK310 III SK310L III	SK450 III SK450L III
	- 1	Track link ASSY (with shoe)	Detach/attach	One side	Incl. adjustment of tension	2.0	3.0
	- 2	Track link ASSY	Replace	One side	Disassembly and assembly of shoe and link	4.0	5.0
	- 3	Master pin	Replace	One side		0.8	1.0
	- 4	Track link	Replace	1 link		2.5	3.0
	- 5	Shoe plate	Replace	1 pc	Incl. cutting off of shoe bolts	0.5	←
	- 6	Upper roller	Detach/attach	1		0.0	1.0
	- 7	Upper roller	O/H	1	Where upper roller is removed.	1.5	←
	- 8	Lower roller	Detach/attach	1		1.0	←
	- 9	Lower roller	O/H	1	Where upper roller is removed.	1.0	←
	- 10	Front idler	Detach/attach	One side		4.0	4.5
	- 11	Front idler	O/H	One side	Where upper roller is removed.	2.0	2.5
08	- 12	Track spring ASSY	Detach/attach	One side		4.0	4.5
	- 13	Grease cylinder	O/E	One side	Where upper roller is removed.	0.5	1.0
	- 14	Spring	Replace	One side	Where upper roller is removed.	3.0	3.5
	- 15	Travel motor Reduction gear ASSY	Detach/attach	One side	Incl. detaching and attaching pipings and cover	5.0	7.0
	- 16	Reduction gear ASSY	O/H	1	Incl. detaching and attaching pipings	4.0	4.0
	- 17	Drive sprocket	Replace	One side		3.0	3.0
	- 18	Travel motor (single) ASSY	Detach/attach	One side		3.0	3.5
	- 19	Travel motor	O/H	1	Incl. detaching and attaching pipings	5.0	6.5
	- 20	Swivel joint	Detach/attach	1 pc.		5.0	5.5
	- 21	Swivel joint	O/H	1	Incl. detaching and attaching pipings	5.0	3.0
	- 22	Lower piping (tube)	Replace	1	Incl. detaching and attaching cover	1.5	2.0

Nr.	ATTACHMENT	LOCATION	WORK TO BE DONE	UNIT	REMARK	SK130II SK310rII	SK190II SK410rII
- 1	Bucket ASSY		Detach/attach	1 pc.		1.5	2.0
- 2	Bucket mounting pin		Replace	1		0.8	1.0
- 3	Aide cutter		Replace	One side		0.8	1.0
- 4	Teeth		Replace	1		0.5	-
- 5	Arm ASSY		Detach/attach	1 set	Incl bucket cylinder and link	3.0	4.0
- 6	Arm (angle)		Replace	1 pc		4.0	5.0
- 7	Arm bushing		Replace	1	Single arm condition	1.6	2.0
- 8	Bucket cylinder ASSY		Detach/attach	1		1.6	2.0
- 9	Bucket cylinder		O/H	1	Not incl. replacement of bushing	5.0	6.0
- 10	Bucket link		Replace	1 set		0.8	1.0
- 11	Bucket link bushing		Replace	1	Incl idler link	1.6	2.0
- 12	Idler link		Replace	1		0.8	1.0
- 13	Arm cylinder ASSY		Detach/attach	1		3.0	4.0
- 14	Arm cylinder		O/H	1	Not incl. replacement of bushing	6.0	6.0
- 15	Arm ASSY		Detach/attach	1 pc	Incl arm cylinder	6.0	7.0
- 16	Boom foot pin		Replace	1	Draw out SKGN by sliding the seal towards from the cul side.	2.0	3.0
- 17	Boom cylinder ASSY		Detach/attach	1		3.0	4.0
- 18	Boom cylinder		O/H	1	Not incl. replacement of bushing	6.0	6.0
- 19	Boom cylinder bushing		Replace	1		0.8	1.0
- 20	Boom cylinder hose		Replace	1		0.8	1.0
- 21	Arm cylinder hose		Replace	1		1.5	2.0
- 22	Bucket cylinder hose		Replace	1		1.5	2.0

417



## 2. STANDARD WORKING TIME TABLE FOR THE MAINTENANCE OF ENGINE

### Introduction

This standard working time table provides time required for maintenance (if the work is carefully carried out) under the following condition :

- Tools designated by us are used.
- Genuine parts are prepared.
- Correct working procedures are observed.
- The engine is mounted correctly to the machine.

However, construction machines of different manufacturers vary in construction, as follows :

1. The working hours given in this table can not be applied because of special machine construction.
2. Special equipments not listed in this table may be used for operation.

If such operations are performed, fill out reasons in the Claim Application Sheet in detail and submit it to us.

#### (Note 1) Unit of working time

The working time is given in 6 minutes=0.1 hour in the decimal system.

#### (Note 2) Contents

The group numbers and the titles are in common with the Standard Working Time for Trucks and Buses, and only those items applicable to industrial engines are stated.

#### (Note 3) Applicable models :

6D31-T .....SK200V, SK200LCV  
6D15-T .....SK220V, SK220LCV  
6D22-T .....SK300Z, SK300LCZ  
6D22-TC .....SK400Z, SK400LCZ  
6D22-T .....SK310II, SK310LCII  
6D22-TC .....SK430II, SK430LCII

## 2.1 COOLING SYSTEM

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
<b>Cooling system 01-00</b>				
Cleaning of cooling system.	Cooling water of cooling system is rusty.	1.0	1.0	1.3
Replacing water outlet pipe and packings.	Water leaks from water pipe. Rupture of water pipe or other fault.	1.0	1.0	1.3
Replacing bypass hose.	Water hose is attached improperly. Rupture of water hose or other fault.	0.4	0.4	0.4
Replacing radiator upper (inlet) hose.	Water hose is attached improperly. Rupture of water hose or other fault.	0.3	0.3	0.4
Replacing radiator lower (outlet) hose.	Water hose is attached improperly. Rupture of water hose or other fault.	0.7	0.7	0.8
Replacing radiator hose clip. (1 pc.)	Water hose is installed improperly. Radiator hose system in general is faulty.	0.3	0.3	0.3
<b>Cooling fan 01-20</b>				
Attaching and detaching or replacing fan.	Cooling fan is broken. Cooling fan makes an abnormal sound. Cooling fan parts are defective.	0.6	0.6	0.8
Replacing belts (2 pcs.) Note: Where two or more belts are used, increase 0.3hr. for each belt increased.	Fan belt is damaged. Fan belt squeaks.	0.3	0.3	0.5
Adjusting belts.		0.2	0.2	0.3
Idler pulley overhaul Incl.: detaching and attaching it.	Refer to Fault-finding table.	—	—	—
Detaching and attaching or replacing fan coupling.		0.7	0.7	1.0
<b>Radiator 01-30</b>				
Replacing radiator core	Radiator is broken. Radiator is clogged up. Water leaks from radiator. Radiator system in general is out of order.	3.5	3.5	4.5
Replacing radiator drain cock	Water leaks from drain cock.	0.2	0.3	0.3
Replacing pressure valve.	Radiator cap does not work properly.	—	—	—
Replacing surge tank	Surge tank parts are faulty.	—	—	—
Replacing radiator shroud	Radiator shroud parts are defective.	0.8	0.6	0.8
Replacing radiator support, inner side	Radiator support stay parts are defective.	—	—	—
Detaching and attaching or replacing protector and bracket. Note: Add 0.4hr. for auto pressure with distributor.	Radiator support stay part parts are defective.	—	—	—
Replacing radiator mounting rubber (inner side)	Radiator support cushion parts are faulty.	—	—	—
Detaching and attaching or replacing condensation tank.	Condensation tank parts are faulty.	—	—	—
Detaching and attaching or replacing radiator filler set.	Radiator in general are out of order.	—	—	—
<b>Thermostat 01-40</b>				
Inspecting or replacing thermostat. (JH one)	Thermostat functions incorrectly. Thermostat remains open. Thermostat remains closed. Thermostat system in general is out of order.	0.6	0.6	0.6
Inspecting or replacing thermostat. (RH one)	Thermostat functions improperly. Thermostat remains open. Thermostat remains closed. Thermostat system in general is out of order.	—	—	—
Inspecting or replacing thermostat. (LH one)	Thermostat functions improperly. Thermostat remains open. Thermostat remains closed. Thermostat system in general is out of order.	—	—	—

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
<b>Water pump 01-50</b>				
Replacing water pump that is mounted to the machine. Incl.: (1) Detaching and attaching V-belt. (2) Detaching and attaching the pulley ass'y.	Water pump squeaks. Water leaks from water pump. Pump bearing is broken. Pump shaft is damaged. Water pump parts are faulty. Water pump in general are out of order.	2.0	2.3	3.0
Water pump overhaul. Excl.: detaching and attaching.	Water pump squeaks. Water leaks from water pump. Pump bearings are damaged. Pump shaft is damaged. Water pump parts are faulty. Water pump in general is out of order.	0.9	0.8	1.0
<b>Engine oil cooler 01-70</b>				
Replacing oil cooler.	Oil cooler parts are faulty. Oil cooler in general is out of order.	3.0	5.0	5.0

## 2.2 ELECTRICAL SYSTEM

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
<b>Battery 02-03</b>				
Replacing battery (mount)	Battery is cracked. Battery is distorted by heat. Battery is discharged. Battery in general is out of order.	0.4	0.4	0.5
Replacing battery box.	Battery support parts are faulty. Battery in general is out of order.	1.0	1.0	1.0
Detaching and attaching battery cover.	Battery in general is out of order.	—	—	—
<b>Generator 02-05</b>				
Replacing generator ass'y	Generator functions improperly. Generator makes an abnormal sound. Generator is burnt. Generator bearing parts are faulty. Generator pulley is broken. Generator mounting bracket is broken.	1.0	1.0	1.0
Overhaul of generator Incl.: Detaching and attaching generator.	Generator functions improperly. Generator makes an abnormal sound. Generator burnt out. Generator bearing parts are faulty. Generator pulley are broken. Generator mounting bracket is broken.	—	—	—
Overhaul of generator (single)	Generator functions improperly. Generator makes an unusual sound. Generator burnt out. Generator bearing parts are defective. Generator pulley is broken. Generator mounting bracket is broken.	—	—	—
<b>Starter motor 02-10</b>				
Replacing starter.	Starter motor malfunctions. Starter motor rusts from inside. Pinion is broken. Overrunning clutch slips. Overrunning clutch parts are defective. Pinion engagement is no good. Starter motor system in general is out of order.	0.9	0.6	1.0

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D3-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
Overhaul of starter. Incl. : detaching and attaching starter	Starter motor malfunctions. Starter motor rusts from inside. Pinion is broken. Overrunning clutch slips. Overrunning clutch parts are faulty. Pinion meshing is no good Starter motor system in general is out of order.	—	—	—
Overhaul of starter	Starter motor malfunctions. Starter motor rusts from inside. Pinion is broken. Overrunning clutch slips. Overrunning clutch parts are faulty. Pinion meshing is no good Starter motor system in general is out of order.	—	—	—
Replacing starter switch ass'y	Magnetic switch contacts are no good. Magnetic switch burnt out. Starter motor system as a whole is out of order	1.0	1.3	1.3
Safety (starter) relay 02-12				
Detaching/attaching or replacing starter relay.	Relay malfunctions Relay system as a whole is out of order	0.4	0.4	0.4
Voltage regulator 02-20				
Replacing relay (regulator) ass'y	Voltage regulator malfunctions Voltage regulator system as a whole is out of order.	0.5	0.5	0.5
Glow plug 02-33				
Inspecting and replacing glow plugs. (all)	Glow plug parts are faulty. Glow plug system as a whole is out of order.	1.0	1.2	1.2
Intake air heater 02-34				
Detaching/attaching or replacing intake air heater ass'y. (one side)	Intake heater parts are faulty Intake heater system as a whole is out of order.	—	—	—
Replacing resistor	Resistor parts are faulty.	—	—	—
Detaching/attaching or replacing magnet valve.	Magnet valve parts are faulty.	—	—	—
Switch (unit) 02-35				
Replacing starter switch	Starter switch does not return well Starter switch is broken or developed other fault.	0.1	0.1	0.1
Replacing starter switch. (in switch box)	Starter switch does not return well. Starter switch is broken or developed other fault.	—	—	—
Replacing water temperature gauge unit	Water temperature gauge unit malfunctions.	0.3	0.3	0.3
Detaching/attaching or replacing fuel tank gauge unit	Fuel gauge unit malfunctions.	—	—	—
Replacing oil bypass alarm.	Oil leaks from oil bypass alarm Oil bypass alarm is broken or developed other fault.	0.3	0.3	0.3
Replacing battery switch.	Battery switch malfunctions.	0.1	0.1	0.1
Replacing turn signal and dimmer switch.	Turn signal switch malfunctions. Dimmer switch malfunctions.	—	—	—
Meters 02-50				
Replacing speedometer ass'y.	Speedometer malfunctions.	0.1	0.1	0.1
Replacing tachometer cable. (unit)	Speedometer cable is broken Tachograph cable is broken. Tachometer cable is broken.	0.5	0.5	0.5
Replacing temperature gauge.	Temperature gauge gives incorrect readings.	0.5	0.5	0.5
Replacing fuel gauge	Fuel gauge gives incorrect readings.	0.5	0.5	0.5
Replacing oil pressure gauge.	Oil pressure gauge gives incorrect readings.	0.5	0.5	0.5
Replacing air pressure gauge	Air pressure gauge gives incorrect readings.	—	—	0.1
Replacing ammeter	Ammeter gives incorrect readings.	0.5	0.5	0.5



## 2.3 ENGINE

NAME OF WORK	NAME OF TROUBLE	M.I./PT.		
		BD1 (6D31-T)	GD1 (6D15-T)	BD2 (6D27-T) (6D22-TC)
Replacing tachograph assy.	Tachograph malfunctions.	—	—	—
Engine 03-00				
Detaching/attaching or replacing engine assy.	Refer to fault code table.	14.0	15.0	18.0
Overhaul of engine assy. Incl. : (1) Detaching/attaching engine. (2) Running-in of engine. (3) Conditioning engine. (B) Excl. : (1) Overhauling starter, dynamo and injection pump. (2) Grinding crankshaft. (3) Boring and honing of cylinder liners.	Refer to fault code table.	68.0	73.0	89.0
Semi overhaul of engine. Incl. : (1) Semi overhaul of cylinder head (2) Replacing piston and piston ring. (3) Replacing cylinder liners. (4) Adjusting engine. (A) (5) Adjusting nozzle.	Refer to fault code table. For each set of piston liners decreased 1.9hr. Each time one line decreases 0.8hr. Each time one piston decreases 0.5hr	28.0	30.0	35.0
Adjusting engine. (A) Incl. : (1) Adjusting valve clearance. (2) Inspecting nozzle. (3) Adjusting injection timing. (4) Cleaning air cleaner element. (5) Cleaning fuel filter element. (6) Inspecting cooling water hose. (7) Adjusting fan belt. (8) Retightening all parts.		3.0	3.2	3.5
Adjusting engine (present vehicle). (B) Incl. : (1) Retightening cylinder head. (2) Cleaning air cleaner. (3) Measuring compressive pressure. (4) Inspecting cooling water hose. (5) Inspecting fan belt for slackening and adjusting it. (6) Checking the max. and min. revalutions. (7) Inspecting glow plug. (8) Inspecting and adjusting nozzle. (9) Adjusting injection timing. (10) Cleaning oil and fuel filter elements. (11) Adjusting valve clearance. (12) Retightening other parts.		6.5	6.8	7.5
Measuring compressive pressure.		2.0	2.0	2.3
Adjusting injection timing.	Climbing power of vehicle is deficient. Max. speed of vehicle is deficient. Accelerating power of vehicle is deficient. Engine starting is faulty. Engine output is deficient. Engine fuel is no good.	0.8	0.8	0.8
Adjusting valve clearance		1.0	1.0	1.2
Measuring black exhaust		0.6	0.6	0.6
Cylinder head 03-10				
Replacing cylinder head assy. (1 unit) Incl. : (1) Adjusting engine (A) (2) Adjusting nozzle.	Cylinder head cracked. Cylinder head is distorted. Cylinder head is eroded. Cylinder head is porous. Area between cylinder head and valve is cracked. Cylinder head system in general is out of order.	9.0	9.0	10.5

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
Overhauling cylinder head ass'y. (1 set.) Incl. : 1) Detaching/attaching cylinder head. 2) Replacing combustion chamber. 3) Correcting valve seat ring 4) Replacing valve guide. 5) Lapping valve. 6) Adjusting engine (A). 7) Adjusting nozzle.	Cylinder head is cracked. Cylinder head is distorted. Cylinder head is corroded. Cylinder head is porous. Area between cylinder head and valve is cracked. Cylinder head system in general is out of order.	10.5	11.5	13.5
Replacing cylinder head ass'y. (one side.) Incl. : 1) Adjusting engine (A). 2) Adjusting nozzle.	Cylinder head is cracked. Cylinder head is distorted. Cylinder head is corroded. Cylinder head is porous. Area between cylinder head and valve is cracked. Cylinder head system in general is out of order.	—	—	—
Overhauling cylinder head ass'y. (1 set.) Incl. : 1) Detaching/attaching cylinder head 2) Correcting seat face 3) Replacing valve guide. 4) Replacing combustion chamber 5) Lapping valve 6) Adjusting engine (A). 7) Adjusting nozzle.	Cylinder head is cracked. Cylinder head is distorted. Cylinder head is corroded. Cylinder head is porous. Area between cylinder head and valve is cracked. Cylinder head system in general is out of order.	—	—	—
Hydrostatic test of cylinder head (1 set) (single)	Cylinder head is cracked. Cylinder head is porous. Cylinder head system in general is out of order.	1.5	1.5	1.5
Replacing cylinder gasket (1 pc.) (present machine) Incl. Adjusting engine (A).	Water leaks from cylinder head Oil leaks from cylinder head Gas leaks from cylinder head. Cylinder head system in general is out of order.	6.5	7.0	8.0
Replacing cylinder head gasket Kore side (present machine) Incl. Adjusting engine (A).	Water leaks from cylinder head gasket. Oil leaks from cylinder head gasket. Gas leaks from cylinder head gasket.	—	—	—
Rightening cylinder head bolts. (1 unit) (present machine) Incl. Adjusting valve clearance.		2.0	2.3	2.5
Replacing pre-combustion chamber, (1 pc.) Excl. : Detaching/attaching head. Incl. : 1) Detaching/adjusting and cleaning glow plug (1 pc.) 2) Adjusting nozzle (1 pc.) for each nozzle increased : Medium size 0.4hr. Large size 0.5hr.	Pre-combustion chamber is broken. Water leaks from pre-combustion chamber gasket.	1.0	1.0	1.5
<b>Locker cover 03-15</b>				
Replacing locker cover packing (1 pc.) Increase 0.1hr. as one direct injection increases.	Locker cover packing is cracked. Oil leaks from locker cover packing.	0.5	0.6	0.5
Replacing locker casing packing (1 unit) Incl. : 1) Adjusting valve clearance. 2) Detaching/attaching locker casing	Oil leaks from locker casing packing.	—	—	—
<b>Cylinder block 03-20</b>				
Replacing cylinder block Incl. : 1) Detaching and attaching engine. 2) Conditioning engine (B) and travel test Excl. : Replacing associated parts.	Refer to fault code table.	50.0	53.0	55.0
Replacing cylinder liners (all Q's on present vehicle) Incl. : 1) Conditioning engine (A). 2) Adjusting nozzle.	Refer to fault code table.	25.0	27.0	31.0
Replacing side cover packing, (front side)	Oil leaks from side cover gasket.	—	0.4	0.4
Replacing side cover packing, (left)	Oil leaks from side cover gasket.	—	—	—

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
Replacing side cover packing (right) Increase 2.0hr. where injection pump is tilted.	Oil leaks from side cover gasket.	—	—	—
Replacing side cover packing (rear side)	Oil leaks from side cover gasket.	—	0.5	0.4
Detaching/attaching or replacing rear plate.	Rear plate is cracked.	—	—	—
<b>Cam shaft 03-31</b>				
Detaching/attaching or replacing cam shaft. Incl. : Detaching and attaching engine. (2) Conditioning engine (3) Travel test.	Cam shaft is worn. Cam shaft is broken. Cam shaft bushing is worn. Cam shaft bushing seized. Cam shaft system in general is out of order.	16.0	23.0	24.0
Replacing cam shaft bushing Incl. : (1) Detaching/attaching engine. (2) Conditioning engine	Cam shaft bushing worn. Cam shaft bushing seized.	19.0	26.0	25.0
<b>Push rod 03-32</b>				
Detaching/attaching or replacing push rod (all present machines) Incl. : Adjusting valve clearance.	Push rod is broken. Push rod is bent. Push rod system in general is out of order.	2.5	2.5	3.5
Detaching/attaching or replacing push rod. (1-5,1-8) (present machine) Incl. : Adjusting valve clearance.	Push rod is broken. Push rod is bent. Push rod system in general is out of order.	—	—	—
<b>Locker arm 03-33</b>				
Detaching/attaching or replacing valve locker assy. (all) Incl. : Adjusting valve clearance.	Locker arm is worn. Locker arm is broken. Bushing is worn. Locker arm system in general is out of order. Locker arm ball makes an unusual sound.	2.5	2.5	3.3
Detaching, attaching and disassembling locker arm and shaft. (1 shaft) Incl. : Adjusting valve clearance	Locker arm is worn. Locker arm is broken. Bushing is worn. Locker arm system in general is out of order. Locker arm ball makes an unusual sound.	—	—	—
Detaching, attaching and disassembling locker assy. (one side) Incl. : Adjusting valve clearance	Locker arm is worn. Locker arm is broken. Bushing is worn. Locker arm system in general is out of order. Locker arm ball makes an unusual sound.	—	—	—
Detaching, attaching and disassembling valve locker and shaft (one shaft) Incl. : Adjusting valve clearance.	Locker arm is worn. Locker arm is broken. Bushing is worn. Locker arm system in general is out of order.	—	—	—
Replacing valve locker adjusting screws (all) Incl. : Adjusting valve clearance.	Locker arm system in general is out of order.	2.0	2.0	3.3
Replacing valve locker adjusting screws. (one side) Incl. : Adjusting valve clearance.	Locker arm system in general is out of order.	—	—	—
<b>Tappet 03-34</b>				
Replacing tappet (all) Incl. : (1) Detaching and attaching engine (6D5). (2) Conditioning engine. Increase 10.0hr. for old tappets (1K).	Tappet wear. Tappet is broken. Tappet system in general is out of order.	16.5	9.0	4.0
<b>Valve 03-35</b>				
Replacing valves (all) (present machines) Incl. : (1) Detaching and attaching cylinder head. (2) Correcting and lapping valve seat. (3) Conditioning engine (A).	Inlet valve is broken. Exhaust valve is broken.	10.0	11.0	12.5
Lapping valve seat surface (all) Incl. : (1) Detaching and attaching cylinder head. (2) Conditioning engine (A)	Valve seat worn. Contact of valve seat with valve is no good. Valve seat fell off.	—	—	—

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 6D22-T 6D22-TC
Replacing valves 16 or 8 pcs. Incl. : (1) Detaching and attaching cylinder head. (2) Correcting and lapping valve seat. (3) Conditioning engine (A).	Inlet valve is broken. Exhaust valve is broken.	—	—	—
Replacing valve guides (all) Incl. : (1) Detaching and attaching cylinder head. (2) Conditioning engine (A). (3) Correcting and lapping valve seat.	Valve guide is worn. Valve is seized. Oil level on valve guide full. Valve guide fell off.	10.8	11.7	13.3
Replacing valve guides (one side) Incl. : (1) Detaching and attaching cylinder head. (2) Conditioning engine (A). (3) Correcting and lapping valve seat.	Valve guide is worn. Valve guide is seized. Oil level on valve guide full. Valve guide fell off.	—	—	—
Replacing valve springs (all) Incl. : Adjusting valve clearance. Excl. : Detaching and attaching cylinder head.	Valve spring is broken. Valve spring is fatigued.	3.4	3.8	4.8
Replace valve spring (1 cylinder) (present machine) Incl. : Adjusting valve clearance. Excl. : Detaching and attaching cylinder head Add 0.3hr. for medium size and 0.6hr. for large size as one cylinder increases.	Valve spring is broken. Valve spring is fatigued.	—	—	—
Timing gear (chain) casing 03-40				
Detaching/attaching or replacing timing gear casing	Timing gear (chain) casing makes an unusual sound. Timing gear (chain) casing parts are faulty. Oil leaks from gasket. Timing gear casing system in general is out of order.	6.5	—	—
Replacing timing gear casing packing.	Oil leaks from gasket.	4.5	—	—
Detaching, attaching and regreasing timing gear casing cover.	Timing gear casing in general is out of order.	—	—	—
Replacing cam shaft gear and idle gear.	Idle gear parts are defective. Cam shaft gear is installed incorrectly. Cam shaft gear parts are defective.	5.5	—	—
Replacing idle gear bushing Note : Flywheel bearing is dismantled.	Timing gear casing in general is out of order.	—	0.8	0.8
Crank shaft 03-51				
Detaching/attaching or replacing crank shaft. Incl. : (1) Detaching/attaching engine. (2) Adjusting idling.	Refer to Fault Code Table.	24.0	30.0	35.0
Replacing crank shaft rear oil seal. (present machine) Incl. : Detaching and attaching transmission and flywheel.	Oil leaks from rear oil seal.	7.0	7.5	8.5
Detaching/attaching or replacing crank pulley. (present machine) Incl. : Detaching and attaching radiator shroud and fan.	Crank shaft pulley parts are faulty. Crank shaft pulley nuts are slackened.	3.0	3.5	4.0
Detaching/attaching or replacing flywheel Incl. : Detaching and attaching transmission.	Flywheel mounting bolts are broken. (nut loosening)	6.5	7.0	8.0
Detaching/attaching or replacing flywheel ring gear. (inertia body)	Flywheel ring gear is worn. Flywheel ring gear is broken.	0.5	0.5	0.6
Replacing flywheel pilot bearing. (single)	Flywheel pilot bearing parts are faulty.	0.2	0.2	0.2
Replacing crank shaft front oil seal. (present machine) Incl. : (1) Detaching and attaching fan and front cover. (2) Detaching and attaching radiator shroud driver.	Oil leaks from front oil seal.	5.0	4.5	4.8

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
Replacing crank shaft gear. (present vehicle)	Crank shaft gear is worn. Crank shaft gear is broken.	—	—	—
Connecting rod 05-82				
Correcting curvature of connecting rod. (1 pt. angle)	Connecting rod is bent.	—	—	—
Replacing connecting rod bearings (all)	Bearings are worn. Bearings are seized	4.8	5.0	6.3
Replacing connecting rod bearings (1 set) Add 0.4hr. at one pt. Increases.	Bearing is worn. Bearing is seized	—	—	—
Replacing cone drop bushing. (set by set)	Small end bushing is worn. Small end bushing is seized.	—	—	—
Piston 09-68				
Detaching/attaching or replacing pistons. (all) (present vehicle) Incl. : (1) Conditioning engine (A). (2) Adjust nozzle. Add 0.5hr. each time one pt. decreases	Piston is broken. Piston is seized. Oil consumption of engine is large Piston system in general is out of order. Piston and piston pin make abnormal sound	17.0	18.0	19.0
Detaching/attaching or replacing piston rings. (all) (present vehicle) Incl. : (1) Detaching/attaching cylinder head (1) part. (2) Checking and reworking etc. (3) Scraping off carbon. (4) Conditioning engine (A) (5) Adjusting nozzle.	Engine consumes much oil. Piston rings wore off Piston rings is broken. Oil dried out of piston ring. Piston system in general is out of order.	16.0	18.0	17.0
Intake manifold 03-60				
Detaching/attaching or replacing inlet manifold. (1 pt) Incl. : Replacing gasket.	Intake manifold is broken. Intake manifold is porous. Gas leaks from intake manifold gasket. Intake manifold system in general is out of order.	1.5	1.5	2.0
Detaching/attaching or replacing inlet manifold. (one side) Incl. : Replacing gasket	Intake manifold is broken. Intake manifold is porous. Gas leaks from intake manifold gasket Intake manifold system in general is out of order.	—	—	—
Air cleaner 03-61				
Replacing and cleaning air cleaner.	Air cleaner bracket is broken Air cleaner casing parts are defective. Air cleaner system in general is out of order.	—	—	—
Cleaning or replacing air cleaner element.	Element is fouled. Element is in trouble or other fault is the cause	—	—	—
Relightening hose clamps. (7 places)	Air cleaner system in general is out of order.	—	—	—
Exhaust manifold 03-65				
Detaching/attaching or replacing exhaust manifold. Incl. : Replacing gasket.	Exhaust manifold is broken. Gas leaks from exhaust manifold gasket. Exhaust manifold system in general is out of order.	1.2	1.6	1.5
Detaching/attaching or replacing exhaust manifold. (one side) Incl. : Replacing gasket.	Exhaust manifold is broken. Gas leaks from exhaust manifold gasket. Exhaust manifold system in general is out of order.	—	—	—
Oil 03-70				
Replacing engine oil.		0.5	4.6	0.6
Oil filter 03-71				
Replacing oil filter ass'y	Oil leaks from oil filter. Oil filter casing is damaged. Oil filter head is scored. Oil filter system in general is out of order.	1.0	1.0	1.0
Cleaning or replacing oil filter ass'y. (1 set)		0.5	0.5	0.5

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
Inspecting or replacing relief valve. Excl. : Detaching and attaching oil filter ass'y.	Relief valve parts are faulty.	0.4	0.4	0.4
<b>Turbocharger 03-02</b>				
Detaching/attaching or replacing turbocharger ass'y.		—	2.7	2.8
Overhauling turbocharger. (1 staple) Incl. : Cleaning (1 pc.).		—	1.3	1.3
Detaching/attaching or replacing 2-stack oil filter ass'y.	Oil leaks from oil filter. Oil filter housing is damaged. Oil filter head is damaged. Oil filter system in general is out of order.	—	—	—
<b>Oil pan 03-72</b>				
Detaching and attaching oil pan and replacing gasket.	Oil leaks from oil pan gasket. Oil pan parts are faulty. Oil pan system in general is out of order.	2.5	2.8	2.3
Retightening oil pan fastening bolts.		0.5	0.5	0.7
Replacing oil level gauge guide or packing.	Oil level gauge parts are defective.	—	—	—
<b>Oil piping 03-74</b>				
Replacing oil piping. (between filter and cooler)	Oil leaks from oil piping. Oil piping system in general is out of order.	0.3	—	—
Replacing breather pipes. (2 pcs.)	Oil piping system in general is out of order.	0.3	0.3	0.3
<b>Oil pump 03-75</b>				
Detaching/attaching or replacing oil pump.	Refer to fault code table.	1.0	4.2	4.5
Overhauling oil pump ass'y. Incl. : Detaching/attaching oil pump.	Refer to fault code table.	—	—	—
Overhauling oil pump. Excl. : Detaching and attaching oil pump.	Refer to fault code table.	1.0	1.0	1.0
Detaching/attaching or replacing oil strainer	Oil screen is installed incorrectly. Oil screen is broken. Oil screen is clogged. Oil screen stay is broken. Oil pump system in general is out of order.	2.3	2.5	2.8
<b>Engine support 03-80</b>				
Replacing front cushion rubber. (one side)	Front mount bracket rubber is broken. Engine support in general is out of order.	0.7	0.7	1.2
Replacing rear cushion rubber. (one side)	Rear mount bracket rubber is broken. Engine support in general is out of order.	0.9	0.9	1.5

## 2.4 EXHAUST SYSTEM

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
<b>Main muffler 04-23</b>				
Replacing muffler ass'y.	Main muffler (rear muffler) is broken. Main muffler or other part is in trouble.	—	—	—
<b>Tail pipe 04-40</b>				
Detaching/attaching or replacing rear exhaust pipe.	Gas leaks from pipe flange gasket. Tail pipe parts are faulty.	—	—	—
<b>Support 04-50</b>				
Replacing pipe stay.	Muffler hanger parts are faulty. Pipe hanger parts are faulty. Support system in general is out of order.	—	—	—
Replacing pipe bracket.	Muffler hanger parts are faulty. Pipe hanger parts are faulty. Support system in general is out of order.	—	—	—

## 2.5 FUEL SYSTEM

NAMES OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (6D15-T)	6D2 (6D22-T) (6D22-TC)
<b>Engine control 05-10</b>				
Replacing return spring.	Engine control system in general is out of order.	—	—	—
Replacing flexible wire.	Aerial wire parts are faulty. Engine control system in general is out of order.	—	—	—
Replacing fuel button.	Fuel button (choke) wire parts are defective. Engine control system in general is out of order.	—	—	—
Replacing engine stop wire & button.	Fuel stop wire parts are faulty. Engine control system in general is out of order.	—	—	—
Replacing detamp lever ass'y.	Engine control system in general is out of order.	—	—	—
Detaching/attaching or replacing decomp shaft.	Engine control system in general is out of order.	—	—	—
Replacing return spring.	Engine control system in general is out of order.	—	—	—
<b>Fuel injection pump 05-30</b>				
Detaching and attaching or replacing injection pump. Incl. : (1) Adjusting injection timing. (2) Adjusting idling.	Fuel injection pump malfunctions. Fuel injection pump develops leakage. Fuel injection pump system in general is out of order.	4.0	2.5	2.5
Overhauling injection pump. (single) Incl. : Disassembling fuel feed pump Excl. : Disassembling auto timer.	Fuel injection pump malfunctions. Fuel injection pump develops leakage. Fuel injection system in general is out of order.	—	—	—
Injection pump test	Refer to Fault Code Table.	—	—	—
Overhauling auto timer ass'y. (single)		—	—	—
Replacing injection pump coupling. Incl. : Detaching/attaching injection pump	Pump coupling parts are faulty.	—	—	—
Detaching/attaching or replacing injection pump.	Fuel injection pump malfunctions.	—	—	—
Replacing delivery valve gaskets (all)	Oil leaks from fuel injection pump	—	—	—
<b>Fuel injection pipe 05-35</b>				
Replacing injection pipe. (1 pt.) Add 0.2hr. each time one pt. increases.	Injection pipe is cracked. Injection pipe system in general is out of order.	0.5	0.5	0.5
<b>Nozzle holder 05-40</b>				
Detaching/attaching or replacing nozzle holders. (all) Incl. : Nozzle test.	Nozzle malfunctions. Nozzle holder system in general is out of order.	1.8	2.1	2.5
Detaching/attaching or replacing nozzle holder. (1 pt.) 0.2hr. for medium and 0.3hr. for large size each time one pt. increases. Incl. : Nozzle test.	Nozzle malfunctions. Nozzle holder system in general is out of order.	11.5	1.1	1.3
Detaching/attaching or replacing nozzles. (all) Incl. : Nozzle test.	Nozzle malfunctions. Nozzle holder system in general is out of order.	—	—	—
Replacing nozzle. (1 pt.) Add 0.3hr. and 0.4hr. for large size each time one pt. increases. Incl. : Nozzle test.	Nozzle malfunctions. Nozzle holder system in general is out of order.	—	—	—
Detaching/attaching or replacing nozzle tube. Excl. : Detaching and attaching head. Incl. : Detaching and attaching nozzle. Add 0.2hr. for an increase of size pt.	Nozzle tube is damaged. Water leaks from nozzle tube. Nozzle holder system in general is out of order.	—	—	—
<b>Fuel pump 05-45</b>				
Replacing fuel feed pump. Incl. : Venting air.	Fuel pump makes an unusual sound. Fuel leaks from fuel pump. Oil leaks from fuel pump. Fuel pump parts are faulty. Fuel pump system in general is out of order.	0.8	0.8	11.5

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (5D15-T)	6D2 (6D22-T) (6D22-TC)
Overhauling fuel feed pump (angle)	Fuel pump makes an unusual sound. Fuel leaks from fuel pump. Oil leaks from fuel pump. Fuel pump parts are faulty. Fuel pump system in general is out of order.	1.0	1.0	1.0
Cleaning fuel pump gauge filter.		0.4	0.4	0.4
Fuel filter 05-50				
Replacing fuel filter ass'y.	Fuel filter is broken. Fuel filter is clogged. Fuel filter system in general is out of order.	0.8	0.8	0.8
Replacing or cleaning fuel filter element.	Fuel filter broken. Fuel filter is clogged. Fuel filter system in general is out of order.	0.5	0.6	0.5
Fuel piping 05-55				
Replacing engine fuel pipe (1 pc.)	Sections related to fuel pipe (incl. hose) and angles are damaged. Leakage occurs on sections related to fuel pipe (incl. hose) and engine. General trouble with fuel pump (incl. hose) and engine.	0.5	0.5	0.5

## 2.6 AUXILIARY EQUIPMENT (COMPRESSOR)

NAME OF WORK	NAME OF TROUBLE	MODEL		
		6D5 (6D31-T)	6D1 (5D15-T)	6D2 (6D22-T) (6D22-TC)
Compressor 06-10				
Detaching/attaching or replacing air compressor ass'y.	Refer to inlet code table.	—	—	4.0
Overhauling air compressor ass'y. Excl. : Detaching and attaching. Add 1.2hr for 2-cycle use	Compressor related trouble in general.	—	—	2.0
Replacing air compressor valve.	Compressor related trouble in general.	—	—	1.0
Replacing air compressor unloader valve.	Air leaks from compressor. Compressor related trouble in general.	—	—	0.6
Replacing oil seal of air compressor crank shaft.	Compressor related trouble in general.	—	—	3.6
Replacing air compressor bearing	Compressor related trouble in general.	—	—	5.0



# SHOP MANUAL

model


**SK310**   
**SK310** **LC** 

## TABLE OF CONTENTS

1. HYDRAULIC SYSTEM .....	<b>LC12</b>
2. SWING FRAME .....	<b>LC15</b>
3. TRAVEL SYSTEM .....	<b>LC18</b>
4. ATTACHMENTS .....	<b>LC21</b>
5. CONTROL SYSTEM .....	<b>LC22</b>
6. ELECTRICAL SYSTEM .....	<b>LC25</b>
7. AIR-CONDITIONER SYSTEM .....	<b>LC26</b>
8. ....	
9. TROUBLE SHOOTING .....	<b>LC29</b>

○How to Index each Shop Manual Section

The SYSTEMS of this shop manual consists of 9 headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.



# KOBELCO

# SYSTEMS

Book code No. S5LC1005E

SK310Ⅱ  
SK310LCⅢ List of Shop Manual SYSTEMS Section

Index No.	Title	Book Code No.		
		Distribution Year - Month		
LC12	HYDRAULIC SYSTEM	S5LC1205E 1995-03		
LC15	SWING FRAME	S5LC1505E 1995-03		
LC18	TRAVEL SYSTEM	S5LC1805E 1995-03		
LC21	ATTACHMENTS	S5LC2105E 1995-03		
LC22	CONTROL SYSTEM	S5LC2205E 1995-03		
LC25	ELECTRICAL SYSTEM	S5LC2505E 1995-03		
LC26	AIR-CONDITIONER SYSTEM	S5LC2605E 1995-03		
LC29	TROUBLE SHOOTING	S5LC2901E 1995-03		
	Applicable Machines	LC03801~ YC01101~		

Book code No. S5LC1205E

# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### HYDRAULIC SYSTEM

**LC12**

#### TABLE OF CONTENTS

1. SUMMARY .....	1
2. HYDRAULIC CIRCUIT DIAGRAM AND DESCRIPTION OF COMPONENTS .....	3
3. FUNCTIONAL EXPLANATION OF HYDRAULIC CIRCUIT .....	4
4. NEUTRAL CIRCUIT .....	5
5. TRAVEL CIRCUIT .....	6
6. SWING CIRCUIT .....	7
7. BUCKET CIRCUIT .....	8
8. BOOM CIRCUIT .....	9
9. ARM CIRCUIT .....	11
10. SIMULTANEOUS OPERATION .....	14
11. PILOT PIPING .....	18
12. MAIN PIPING .....	21

 **KOBE STEEL, LTD.**

Applicable Machines

LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S3LC1205E K

# 1. SUMMARY

This machine is featured by the following functions embodied in its hydraulic circuits, aiming at easy operation, safety, handling of


large masses of material and reduced fuel consumption.

Table 1

Performance	Device	Function	Features
Easy operation and safety	Travel	<ul style="list-style-type: none"> <li>• Travel straight</li> <li>• Boost pressure for travel</li> <li>• Travel pilot operation</li> <li>• Automatic parking brake</li> </ul>	<ul style="list-style-type: none"> <li>• Straight travel at composite operation</li> <li>• Maximum travel relief pressure attainable</li> <li>• Lever stopper adjustment not required</li> <li>• Mechanical brake built in the travel motor</li> </ul>
	Swing	<ul style="list-style-type: none"> <li>• Swing flasher lights</li> <li>• Swing control valve provided separately</li> <li>• Swing priority circuit (at simultaneous operation of arm digging/swing motions)</li> <li>• Automatic swing parking brake</li> <li>• Delay brake operated by reducing valve</li> <li>• Anti-turnover function by swing-reactionless valve</li> </ul>	<ul style="list-style-type: none"> <li>• Warns the people around the machine at swing motion</li> <li>• Promotes operability in swing motion</li> <li>• Ease in oblique pulling by the arm and in digging by pressing force of the swing unit</li> <li>• Prevents drift in the swing motion on a slope</li> <li>• Delays the action of the parking brake when swing inertia force occurs</li> <li>• Ease in positioning the machine by preventing swing-reaction that occurs when swing inertia slips</li> </ul>
	Attachment	<ul style="list-style-type: none"> <li>• Pilot control method</li> <li>• Variable loading mode</li> <li>• Holding valve (Boom lock)</li> <li>• ATT boost pressure</li> <li>• Operation patterns changeable</li> </ul>	<ul style="list-style-type: none"> <li>• Only minimal force required in manipulation</li> <li>• Boom and swing speeds variable according to loading condition</li> <li>• Prevents natural fall resulting from internal leakage of the boom cylinder when the attachment stops</li> <li>• Creates power when you need extra power</li> <li>• Operating pattern which may be selected by terminal connection</li> </ul>
	Other	<ul style="list-style-type: none"> <li>• Enclosed semi-automatic pressurized hydraulic oil tank</li> <li>• Suction side : suction strainer</li> <li>• Return side : filter element and drain filter</li> <li>• Pilot circuit : line filter in manifold block</li> <li>• Cooling of hydraulic oil by oil cooler</li> </ul>	<ul style="list-style-type: none"> <li>• Prevents contamination of hydraulic oil and promotes self-suction capacity of the pump</li> <li>• Prevents hydraulic components from failing</li> <li>• Prevents contamination of hydraulic oil</li> <li>• Prevents malfunctioning of pilot operating circuit</li> <li>• Prevents deterioration of hydraulic oil</li> </ul>
Handling of large masses of material	Pump	<ul style="list-style-type: none"> <li>• Full horsepower control</li> </ul>	<ul style="list-style-type: none"> <li>• Effective use of engine power by two variable displacement pumps</li> </ul>
	Travel	<ul style="list-style-type: none"> <li>• 2-speed travel</li> </ul>	<ul style="list-style-type: none"> <li>• Travel speed as fast as 5.5km/hr (3.4MPH)</li> </ul>
	Attachment	<ul style="list-style-type: none"> <li>• Conflux for boom raising</li> <li>• Fixed re-circulation circuit for boom lowering</li> <li>• Conflux circuit at heavy-duty arm digging</li> <li>• Variable re-circulation circuit at light-duty arm digging</li> <li>• Conflux circuit for arm extending</li> <li>• Bucket conflux circuit</li> </ul>	<ul style="list-style-type: none"> <li>• Speed increase for boom raising</li> <li>• Bucket manipulation is positive in combined operation with bucket</li> <li>• Speed increase at heavy-duty arm digging</li> <li>• Speed increase at light-duty arm digging</li> <li>• Speed increase at arm extending</li> <li>• Speed increase at arm extending</li> <li>• Speed increase at bucket digging and extending</li> </ul>
Low fuel consumption	Pump	<ul style="list-style-type: none"> <li>• Negative flow control</li> <li>• Negative control relief cut</li> <li>• Max. flow cut</li> </ul>	<ul style="list-style-type: none"> <li>• Minimum flow at neutral</li> <li>• Minimum flow by relieving the main relief valve</li> <li>• Maximum flow cut of pump in EC mode</li> </ul>
	Micro-computer	<ul style="list-style-type: none"> <li>• Selection of KPSS work mode switch</li> <li>• Automatic accel</li> </ul>	<ul style="list-style-type: none"> <li>• An engine revolution suited for an work mode</li> <li>• Repeated changes in the engine revolution during waiting for a dump truck and reduction in fuel consumption and noise levels</li> </ul>



## 2. HYDRAULIC CIRCUIT DIAGRAM AND DESCRIPTION OF COMPONENTS



No.	NAME	TYPE
1	PUMP	2437U502F3
2	GEAR PUMP	2437U469F1
3	CONTROL VALVE	2436U2885F1
4	MOTOR ASSY (SWING)	2441U947F2
5	MOTOR (TRAVEL)	2441U787F3
7	CYLINDER (BOOM)	KYB $\phi$ 150x $\phi$ 100-1515
8	CYLINDER (ARM)	KYB $\phi$ 170x $\phi$ 120-1835
9	CYLINDER (BUCKET)	KYB $\phi$ 150x $\phi$ 100-1204
10	SWIVEL JOINT	2410U15939F1
11	PILOT VALVE (O/P)	LE30V00002F1
12	OIL COOLER	—
13	CHECK VALVE	2436R39454
14	MANIFOLD BLOCK	2436R914F2
16	FILTER ELEMENT (RETURN)	YN50V00001P1
19	SUCTION STRAINER	2446R347F2
20	HYDRAULIC TANK ASSY	—
21	ENGINE ASSY	6D22-T
22	HYDRO VALVE	2436U2675F1
23	SOLENOID VALVE (ATT:B)	YN35V00010F1
24	HOLDING VALVE (LOCK)	2436U2623F4
25	CHECK VALVE	2436U1171D31
26	SHUTTLE VALVE	2436U2887F2
27	AIR-BREATHER	2446U260F1
28	SOLENOID VALVE (LEVER LOCK)	YN35V00009F1
29	ACCUMULATOR	2445R373F1
30	RESTRICTOR VALVE	2436U1282D210B
31	REDUCING VALVE	—
34	SHUTTLE VALVE	2444R1111F7
35	PRESSURE SWITCH a, b, c	2437U137B
37	PILOT VALVE (TRAVEL)	2436U2888F1
38	SOLENOID VALVE	2436U1314F2
39	HYD OIL INDICATOR	24100U1436F1

### 3. FUNCTIONAL EXPLANATION OF HYDRAULIC CIRCUIT

#### (1) Color Coding Standard for Hydraulic Circuits


Bold black	.....	6kgf/cm <sup>2</sup> (85 psi) or below	Toned black	.....	Valve changed over
Green	.....	7~32kgf/cm <sup>2</sup> (100~455 psi)	Red valve	.....	Pressure acting
Red	.....	32~50kgf/cm <sup>2</sup> (455~711 psi)	Red		
Orange	.....	50kgf/cm <sup>2</sup> (711 psi) or over	solenoid valve	.....	Solenoid valve electrified

---

#### NOTE :

The only flow and standby circuit were displayed with coloring.





#### 4. NEUTRAL CIRCUIT

We will explain the following functions here:

- 1) Negative flow control circuit (negative control circuit)
- 2) Relief cut circuit
- 3) ATT boost pressure circuit
- 4) FC mode circuit (max. flow cut)

##### 4.1 NEGATIVE FLOW CONTROL CIRCUIT (HEREUNDER CALLED NEGA-CON)

Objective; To save unwanted power consumption in neutral operation

Principle; At neutral operation, the flow of the main pump passes through the control valve (hereunder shorten as C/V) and then the low pressure relief valve in the lowermost stream.

This makes the pressure upstream of the low pressure relief valve more than 32kgf/cm<sup>2</sup> (455 psi), it is judged to be neutral.

Function; 32kgf/cm<sup>2</sup>:455 psi pressurized oil enters from the Pi1 and Pi2 ports of C/V to the Pi1 and Pi2 ports of the pump and pushes the pilot piston (643). Then it compresses the pilot spring (646) which causes the lever to press the spool (652) and compresses the return spring (654). The discharge pressure P1 is then admitted to the larger diameter part of the servo piston via port C1. The areal difference of the piston actuates the pump (tilting pin(531)) so as to decrease the delivery rate of the pump.

##### 4.2 RELIEF CUT CIRCUIT

Objective; To save energy at relief action

Principle; The flow at main relief action enters the negative control circuit.

Function; The same function as para. 4.1 Nega-Con is displayed.

##### 4.3 ATT BOOST PRESSURE CIRCUIT

Objective; To exert extra power when needed.

Principle; The main relief pressure increase by about 10%.

Function; The circuit is activated electrically if the button switch in the bucket operating lever grip is kept pressed. This causes the primary pilot pressure to enter ports PL1, PL2 of C/V from the A3 port of the solenoid selector valve (23) and to raise the relief pressure.


##### 4.4 FC MODE CIRCUIT (MAX-FLOW CUT CONTROL)

Objective; If the button switch is changed over, the speed is decreased to 65% of normal speed when fine delicate operation is needed.

Principle; The max. flow of the pump is cut to 65%.

Function; If the FC mode is selected, the primary pilot pressure enters ports Pm1, Pm2 of the pump through port A3 of the solenoid valve (28), pushes the piston (648) and reduces the flow the same way as Nega-Con.

Fig. 2 Neutral circuit, lever lock release, ATT boost or heavy lift, FC mode (MAX FLOW CUT)



**5. TRAVEL CIRCUIT**

The following are explained in this section:

- 1) Travel pilot circuit
- 2) Travel (AUTO) 2-speed selection
- 3) Auto accel
- 4) Travel speed 5.5km/h
- 5.1 TRAVEL PILOT CIRCUIT

**Objective ;** For slow start, slow stop.  
**Principle ;** To operate the travel spool of C/V by the secondary proportionate pilot pressure of the travel pilot valve.

**Function ;** <Pilot circuit>  
 The travel lever and the travel pedal actuate the

pilot valve (37) directly. For instance, if advance action is performed, secondary proportionate pilot pressure PAL, PAR come out of the pilot valve (37), enter parts PAL, PAR of C/V, and actuate the travel spool (30).

<Main circuit>  
 The hydraulic pressure of the No.1 pump (engine side) actuates the RH travel motor via the RH travel spool (301), while the hydraulic pressure of the No.2 pump operates the LH travel motor by way of the LH travel spool.

**5.2 TRAVEL 2-SPEED SELECTION**

**Objective ;** To select a low-speed high-torque mode or a high-speed low-torque mode by the switch.

**Principle ;** The primary pilot pressure alter the tilting angle of the swash plate of the variable displacement 2-speed motor.

**Function ;** If you depress the momentary switch with a rabbit and tortoise mark the solenoid the primary pilot pressure goes out of part A2, enters part PS of both the RH and LH travel motors (5) and changes over the variable displacement motors to the 2nd speed.

**5.3 AUTO ACCEL**

**Objective ;** If the travel and the ATT actions are performed with the auto accel select switch on, the engine takes decel action.

**Principle ;** If the secondary pilot pressure takes up the auto accel.  
**Function ;** If the auto accel select switch is depressed (E/G mark), the secondary select pressure goes out of the travel pilot valve (37) and the pilot valve (11) and turns on the pressure switch PSWC of the shuttle valve (26). If the pressure switch on, takes up the auto accel.


**5.4 TRAVEL SPEED 5.5km/h**

**Objective ;** Travel speed as fast as 5.5km/h.

**Principle ;** The secondary pressure that selects travel operation turns off the PSW B (normally on), releases the solenoid valve (38) and permits the machine to travel in the FC mode.

**Function ;** The solenoid valve (38) is normally on except at travel :  
 The secondary pilot pressure is blocked at the inlet of the valve. Therefore, the solenoid valve operates in the select mode during ATT operation.

Fig. 3 Travel (forward) circuit at 2-speed selected



- ### 6. SWING CIRCUIT
- The following are explained in this section:
- 1) Swing pilot circuit
  - 2) Parking auto brake for swing
  - 3) Delay brake by reducing valve
  - 4) Anti-cavitation circuit to dampen inertia force in swing action
  - 5) Swing flasher lights in swing action
  - 6) Prevention of reaction by the swing-reactionless valve
- #### 6.1 SWING PILOT CIRCUIT
- Function: If swing action is taken, the secondary proportionate pilot pressure PA4 or PB4 comes out of the pilot valve (11) and actuates the swing spool.

#### 6.2 AUTO SWING PARKING BRAKE

Objective: To prevent swing drift when operation is neutral.  
 Principle: When swing action is performed, the spring action is released by primary pilot pressure.  
 Function: In both the swing action and the arm digging, the secondary pilot pressure enters port SH of the reducing valve and changes over the spool. Then the primary pilot pressure releases the parking brake by way of port PG1.

#### 6.3 DELAY BRAKE BY REDUCING VALVE

Objective: To prevent the parking brake when swing inertia occurs.  
 Principle: The release oil is throttled to delay braking.  
 Function: If operation is brought to neutral, the oil returned from the brake release cylinder is delayed 5-8 seconds afterwards.

#### 6.4 ANTI-CAVITATION CIRCUIT WHEN SWING INERTIA OCCURS

Objective: To prevent anti-cavitation when swing action is decelerated or stopped.  
 Principle: If the operating lever is at deceleration or at neutral when swing inertia occurs, the relieved pilot pump oil is replenished to prevent anti-cavitation.  
 Function: The boost oil of 7kgf/cm<sup>2</sup> (100 psi) comes out of port A3 of the manifold block, passes through the check valve (25) and enters port C of the swing control valve to replenish oil.


#### 6.5 LIGHTING OF SWING FLASHER AT SWING ACTION

Objective: To warn around the swing action is being performed.  
 Principle: The selected secondary proportionate pilot pressure causes the swing flasher to flash alternately during swing action.  
 Function: If the pressure switch PSW<sub>A</sub> is turned on by secondary swing proportionate pilot pressure, the oscillator in the flasher unit is turned on which turns on the swing flasher.

#### 6.6 PREVENTION OF SWING REACTION BY SWING-REACTIONLESS VALVE

Objective: To prevent swing reaction within 1 time after swing action stops.  
 Principle: While the motor is being reversed, high pressure oil is bypassed from A to B and visa versa, thereby preventing reversing pressure from occurring.  
 Function: Reversing prevention is performed in the swing-reactionless valve of the swing motor.

Fig. 4 Swing (LH) circuit, at preventing swing reaction



## 7. BUCKET CIRCUIT

The following are explained in this section:

- 1) Pilot circuit for bucket digging
- 2) Bucket digging
- 3) Pump flow increase action
- 4) Power shift control (reduced power control)
- 5) Pilot circuit for bucket discharge
- 6) At bucket discharge
- 7) Simultaneous full-power control (overload prevention)

### 7.1 BUCKET DIGGING

<Pilot circuit>

If bucket digging operation is performed, the pilot secondary proportionate pressure PA2 comes out of the pilot valve (11), enters port PBC of CV and controls the bucket spool.

### 7.2 CONFLUX 2-PUMP IN VALVE AT BUCKET DIGGING

Objective: To speed up the bucket digging motion

Principle: The secondary proportionate pilot pressure switches over the hydro valve (22), causes the primary pilot pressure to enter the side bypass circuit in the control valve, changes over the travel priority valve in the control valve, thereby combining oil streams of the two pumps.

Function: <Pilot circuit>

The secondary proportionate pilot pressure PA2 enters port P11 the hydro valve (22) and changes it over. The primary pilot pressure flows to P1 and P2, in that order, passes through port P10 of the control valve and then the side bypass circuit (63), and changes over the travel priority valve (305) and the neutral cut valve (306).

<Main circuit>

Pressure oil which enters P1 and P2 of the control valve is combined with the oil in the control valve, comes out of port BC, and is supplied to port H of the cylinder.

### 7.3 PUMP FLOW INCREASE ACTION

Objective: To increase the pump flow in operation.

Principle: If the oil of the No.1 and No.2 pumps stop to flow to the low-pressure relief valve and when the negative control pressure falls below  $6\text{kg/cm}^2$  (85psi), the controller judges that operation is underway.

Function: If port P11 and P12 of the pump falls below  $6\text{kg/cm}^2$  (85psi), the pilot spring (646) extends. This pushes back the spool (652) by the action of the return spring (654). The pressured oil of the larger diameter part of the servo piston (532) returns to tank from port C1. The servo piston (532) is pushed to the larger diameter side by the pressure on the smaller diameter part. This causes the tilting pin (531) of the pump to increase the tilting angle of the pump, in order to increase the delivery rate of the pump.


### 7.4 POWER SHIFT CONTROL (REDUCED POWER CONTROL)

Objective: To control the pump power so the engine does not stall by overriding the engine power.

Principle: Secondary proportionate pressure Pf for solenoid (power shift pressure) by commands current enters the compensation piston to perform reduced power control.

Function: In the H, S or FC mode, the electromagnetic proportionate valve attached to the No.1 pump controls the electromagnetic proportionate secondary pressure Pf by command current from the KPSS controller. Then the secondary pressure Pf enters the compensation piston (621) decreases the delivery rate of the pump to perform reduced power control.

Fig. 5 Bucket circuit at digging conflux



**7.5 BUCKET DISCHARGE**  
 <Pilot circuit>  
 If bucket operation is performed, the pilot secondary proportionate pressure PB2 comes out of the pilot valve (11), enters port PAC of C/V and controls the bucket spool.

**7.6 CONFLUX 2-PUMP IN VALVE AT BUCKET DISCHARGE**  
 Objective: To speed up the bucket discharge motion  
 Principle: The secondary proportionate pilot pressure switches over the hydro valve (22), causes the primary pilot pressure to enter the side bypass circuit

in the control valve, changes over the travel priority valve in the control valve, thereby combining oil streams of the two pumps


Function: <Pilot circuit>  
 The secondary proportionate pilot pressure PB2 enters port P11 the hydro valve (22) and changes it over. The primary pilot pressure flows to P1 and P2, in that order, passes through port P10 of the control valve and then the side bypass circuit (63), and changes over the travel priority valve (305) and the neutral cut valve (306).

<Main circuit>  
 Pressure oil which enters P1 and P2 of the control valve is combined with the oil in the control valve, comes out of port AC, and is supplied to port R of the cylinder.

**7.7 SIMULTANEOUS FULL-POWER CONTROL (OVERLOAD PREVENTION)**  
 Objective: To prevent the engine from being stopped due to overloads.  
 Principle: The tilting angles of two pumps are controlled to the same value by  $\frac{P1}{P2} \cdot q$

Function: If the discharge pressure Pd (P1) of the self pump or the discharge pressure P2 of the mating pump rises, P1 and P2 act upon the stepped part of the compensating piston (621). The compensating rod is thus pushed and moves till the outer spring (625) and the inner spring (626) balance with the hydraulic pressure. The compensating rod then pushes the spool (652) via the lever and compresses the return spring (654). The discharge pressure P1 is admitted to the larger diameter part of the serve piston by way of port C1, actuates the tilting pin (581) of the pump due to the areal difference of the piston and reduces the delivery rate of the pump.

Fig. 6 Bucket circuit at discharge conflux



### 8. BOOM CIRCUIT

The following are explained in this section:

- 1) Pilot pressure for boom raising
  - 2) 2-pump conflux for boom raising (at max. boom raising)
  - 3) Simultaneous full-power control (overload prevention)
  - 4) Pilot operation for boom lowering
  - 5) Boom stop by holding valve, prevention of natural fall at neutral position
  - 6) Fixed recycle circuit for boom lowering
- 8.1 PILOT CIRCUIT FOR BOOM RAISING**

Function: If boom raising operation is performed, secondary proportionate pilot pressure

PA1 goes out of the pilot valve (11), enters port PAh of C/V and controls the boom spool.

**8.2 2-PUMP VALVE OUTSIDE CONFLUX FOR BOOM RAISING (AT MAX BOOM UP)**

Objective: To speed up the boom raising motion.  
 Principle: The secondary pressure of the electromagnetic proportionate valve changes over the boom conflux spool (307) and allows oil streams to be combined outside the valve.


Function: <Pilot circuit>  
 The secondary proportionate pilot pressure PA1 enters port P2 of the solenoid proportionate valve attached to the No.2 pump as pressure source. The solenoid proportionate valve is controlled as the voltage of the potentiometer for the loading mode varies. With the boom raising at MAX, the amperage from the controller is maximized which also maximizes the secondary proportionate pressure (for the solenoid valve) to ports P2→PZ. The pressure then enters port PB1 of the control valve, changes over the boom conflux spool (307) to combine oil streams. At the same time, the pressure changes over the neutral cut valve (306).

<Main circuit>  
 The oil discharged by the No.1 pump goes out of port Ab. The oil discharged by the No.2 pump goes out of port PB. Both streams are combined outside the valve and fed to the boom cylinder H via the holding valve (24).

**8.3 LOADING MODE (FOR FUNCTIONS, REFER TO THE COMPOSITE CIRCUIT UNDER SWING/BOOM RAISING.)**

Objective: To adjust the timing for loading onto dump trucks  
 Principle: Adjusts the amount of oil streams combined outside two pumps at boom raising action.  
 Function: <Pilot circuit>  
 If the loading mode switch is turned clockwise under para. 8.2, the voltage of the potentiometer falls. This decreases the secondary proportionate valve (for solenoid) to ports P2→PZ which in turn decreases the stroke of the boom conflux spool (307). This decreases the amount of oil combined in the main circuit for boom action.

Fig 7 Boom circuit at boom up conflux



#### 8.4 PILOT CIRCUIT FOR BOOM LOWERING

Function ; If boom lowering operation is performed, secondary proportionate pilot pressure PB1 goes out of the pilot valve (11), enters port PFB of C/V and controls the boom lowering.

#### 8.5 PREVENTION OF NATURAL FALL OF BOOM AT STOP OR NEUTRAL POSITION

Objective ; To prevent natural fall when operation is neutral.

Principle ; Fall of the cylinder is prevented at neutral position by the valve seat of the holding valve.



#### Function ; <Pilot circuit>

Secondary proportionate pilot pressure for boom lowering enters port PL of holding valve (24), pushes the piston (634), changes over the spool (611) and removes the back pressure of the plunger (631).

#### <Main circuit>

The oil discharged by the No.1 pump is supplied to port R of the boom cylinder from port Bb of C/V. The returned oil enters port B of the holding valve (24) from port H of the cylinder. If the back pressure is let off from the plunger (631), the oil returns to port Ab of C/V past B and A in that order.


#### 8.6 FIXED RECIRCULATION CIRCUIT FOR BOOM LOWERING

Objective ; To prevent cavitation when lowering the boom.

Principle ; Boom lowering action tends to speed up as oil is supplied by the weight of the attachment. The pressure on the return side of the cylinder is sufficiently high by the weight of the attachment, whereas the pressure on the feed side of it tends to be negative. Therefore, the returned oil is recirculated to the feed side within C/V.

Function ; Oil recirculation to port R of the boom cylinder is performed as follows ; The returned oil which enters port Ab of C/V pushes open the plunger (D) in the boom spool and is recirculated to port Bb. Recirculation stops as the pressure on the port R side of the boom cylinder becomes higher than that on the H side.

Fig. 8 Boom circuit at boom down recirculation



## 9. ARM CIRCUIT

The following are explained in this section:

- 1) Pilot circuit for arm digging
- 2) Variable recirculation circuit for light-duty arm digging
- 3) Sequence conflux circuit for heavy-duty arm digging
- 4) Pilot circuit for arm extending
- 5) 2-pump valve outside conflux circuit for arm digging

### 9.1 PILOT CIRCUIT FOR ARM DIGGING

Function; If arm digging operation is performed, secondary proportionate pilot pressure PA3 goes out of the pilot



valve (11), enters port PAa of C/V and actuates the arm spool

### 9.2 VARIABLE RECIRCULATION CIRCUIT AT LIGHT DUTY ARM DIGGING

Objective; To prevent cavitation at light duty operation and to speed up the digging operation.

Principle; In light-duty arm digging operation in the air and on the ground, the pressure on the R side of the cylinder is sufficiently higher while that on the feed side is lower. The sub spool (recycle spool) in the arm spool throttles the returned oil to execute variable recirculation

Function; <Pilot circuit>


7kg/cm<sup>2</sup> (100 psi) pressure which enters port Pis of C/V acts on the sub spool of the arm spool, throttles the returned oil that enters port Ba of C/V from port R of the cylinder and reduces the opening area of (A).

<Main circuit>

The oil returned from port E of the cylinder is throttled by the 7kg/cm<sup>2</sup> (100 psi) pilot pressure in the arm spool of C/V. The oil is variably recirculated to port Aa of C/V to decrease the oil returning to the tank.

Fig. 9 Arm circuit at light duty arm digging variable recirculation






### 9.3 SEQUENCE CONFLUX CIRCUIT IN HEAVY DUTY ARM DIGGING

**Objective:** To speed up the heavy duty arm digging operation, and to increase digging power.

**Principle:** The combination of a rise in the arm digging circuit pressure and the secondary proportionate pilot pressure for arm digging changes over the sequence valve. When the valve is changed over, oil streams by the two pumps are combined in the valve.

**Function:** Sequence conflux action  
When the pump P2 circuit



pressure rises about  $147\text{kgf/cm}^2$  (2090 psi), it pushes the sequence spool (308), overcomes the spring force and changes over the sequence valve spool (308). The changing over of the spool connects port P1ga with port P1gc that is subject to secondary proportionate pilot pressure PA3 re-enters port P1gb through the piping. The pilot pressure which enters port P1gb changes over the bypass cut spool (306) and the travel straight spool (305), and causes the oil streams of pumps P1 and P2 to combine in order to speed up the action.

<Variable Recirculation Cut Function>  
When sequence spool (308) is changed over, port P1sd gets through drain part Dr. Consequently, the oil pressure of the variable recycle command circuit flows to P1s of CV→P1sd→Dr2→tank, in that order, to decrease the hydraulic pressure. This ceases to press sub spool (312) in arm spool (302) which disables the variable recycle function. All the oil returned from the arm cylinder head returns to the tank. This decreases the return circuit pressure and increases the digging power.


### 9.4 BUCKET CONFLUX CUT CIRCUIT AT ARM DIGGING

**Objective:** Since the travel straight valve (305) has been changed over at arm digging, it is not necessary to change over the travel straight valve for conflux at bucket digging.

**Principle:** Secondary proportionate pilot pressure for arm digging prevents the hydro valve (22) from being changed over and thus prevents bucket conflux by bucket conflux circuit command pressure.

**Function:** Secondary proportionate pilot pressure PA3 for arm digging is admitted to port P12 of the hydro valve (22) and performs bucket digging conflux cut and bucket discharge conflux cut functions.

Fig. 10 Arm circuit at heavy duty digging sequence conflux



### 9.5 PILOT CIRCUIT FOR ARM EXTENDING

Function: If arm extending operation is executed, secondary proportionate pilot pressure PB3 goes out of the pilot valve (11), enters port PB3a and PB3b of C/V and actuates the arm spool and arm spool 2.

### 9.6 2-PUMP VALVE OUTSIDE CONFLUX CIRCUIT FOR ARM EXTENDING

Objective: To speed up the arm extending motion

Principle: The secondary proportionate pilot pressure for arm extending changes over the

arm conflux spool and combines the oil streams by the two pump outside of the valve.

Function: <pilot circuit>

Secondary proportionate pilot pressure PB3 enters port PA1 of C/V and changes over the arm conflux spool (391) and the bypass cut spool (306).

<Main circuit>

Oil pressure is supplied in the R side of the arm cylinder, as follows: The oil from the P1 pump gets out of port PA, and enters the R side of the cylinder directly. Meanwhile, the oil from the P2 pump comes out of port Ba combines with the oil from the P1 pump, and enters the R side of the cylinder.

The oil returned from the H side of the arm cylinder branches off to Aa→T and T2, and to Aa2→T and T2. The oil returns to the tank via two spools.


### 9.7 BUCKET CONFLUX CUT CIRCUIT AT ARM DISCHARGE

Objective: Bucket conflux is unnecessary at arm discharge.

Principle: The secondary proportionate pilot pressure for arm discharge prevents hydro valve (22) from being changed over, while the command pressure of the bucket conflux circuit ceases to be combined with other oil.

Function: The secondary proportionate pilot pressure for arm discharge is admitted to port Pi2 of hydro valve (22), and cuts off the bucket digging conflux and the bucket discharge conflux.

Fig. 11 Arm circuit at arm extend valve outside conflux



### 10. SIMULTANEOUS OPERATION

The following are explained in this section:

- 1) Travel straight circuit at travel/boom raising action
- 2) Travel/ATT boost pressure circuit
- 3) Difference between composite operation and independent operation at travel/boom raising action
- 4) Swing priority circuit at swing/arm digging
- 5) Difference between composite operation and independent operation at swing/arm digging action
- 5) Swing/Boom raise; loading mode circuit

#### 10.1 TRAVEL STRAIGHT CIRCUIT AT TRAVEL/BOOM RAISING ACTION

**Objective:** At travel action, the circuit enables the machine to travel straight even during attachment operation.

**Principle:** Travel and attachment motions may be operated by separate pumps.

**Function:** <Pilot circuit>

The primary pilot pressure which enters port PS of C/V enters the side bypass circuit (63), passes through the travel spool, is shut off by the boom spool. As the shut off bypass circuit pressure rises, the travel straight spool (305) and the bypass cut spool (310) are changed over. Secondary pressure for boom raising operation enters port PBI of C/V and changes over the boom conflux spool (307).

<Main circuit>

If the travel straight spool is changed over, the oil pressure flowing from pump P1 into the main circuit (51) is shut off, but enters the parallel circuit (53) to perform the boom raising action. The oil pressure from pump P2 enters both of the RH and LH main circuits (51, 54) and is fed to the travel motor.

#### 10.2 TRAVEL/ATT BOOST PRESSURE CIRCUIT

**Objective:** The travel motor moves to the fast at composite operation combined with travel action.


**Principle:** The attachment relief pressure is higher than the travel relief pressure.

**Function:** Attachment relief: 500kgf/cm<sup>2</sup> (4270psi), travel: 350kgf/cm<sup>2</sup> (4950psi)

#### 10.3 DIFFERENCE BETWEEN COMPOSITE OPERATION AND INDEPENDENT OPERATION AT TRAVEL/BOOM RAISING ACTION

Travel	Independent	Simultaneous
		<ul style="list-style-type: none"> <li>• Travel spool control</li> <li>• PSW a ON for auto accel</li> <li>• PSW b OFF for travel 5.5km/h</li> </ul>
Pilot circuit		<ul style="list-style-type: none"> <li>• Travel straight spool (305) changed over</li> <li>• Bypass cut spool (310) changed over</li> </ul>
Main circuit	<ul style="list-style-type: none"> <li>• P1 pump drives RH motor.</li> <li>• P2 pump drives LH motor.</li> </ul>	<ul style="list-style-type: none"> <li>• P1 pump drives RH and LH motor.</li> </ul>

Fig. 12 Simultaneous operation circuit at boom raising/travel (forward 1-speed), travel straight



10.4 SWING PRIORITY CIRCUIT AT SWING/ARM DIGGING

Objective: To stabilize the swing speed.  
 Principle: The oil flow for arm digging is reduced and fed preferentially to the swing side.

Function: <Pilot circuit>  
 In the swing operation and in the arm digging operation, the secondary proportionate pilot pressure enters port P1A or P1B of the swing control valve and actuates the swing spool. At the same time, the pressure goes out of the P1


port and turns on the swing pressure switch PSW. a. At the same time, the pressure re-enters port SH of the reducing valve for the swing parking brake, then enters port P13 of CV, changes over the bypass cut valve (310), and acts upon the back pressure of the logic valve (312) and the sub spool in the arm spool. When the pressure acts upon the sub spool, it is restricted more as it is higher than the servo pressure 7kg/cm<sup>2</sup> (100psi) that comes from PIS.

<Main circuit>  
 Pressurized oil for the swing motor and the arm digging motion is supplied by the No.2 pump i.e. by a parallel circuit. when arm digging and swing motions are operated at the same time, the pressure flows toward the lower load pressure. Since the oil returned from the cylinder is restricted by the above-mentioned sub-spool, the load pressure fed to the cylinder rises. Therefore, the oil is fed preferentially to the swing motor to stabilize the swing speed.

10.5 DIFFERENCE BETWEEN SIMULTANEOUS OPERATION AND INDEPENDENT OPERATION AT SWING/ARM DIGGING

	Independent	Simultaneous
Swing		
Pilot circuit	<ul style="list-style-type: none"> <li>Control of swing control valve</li> <li>Auto accel pressure PSW.b ON</li> <li>Swing pressure switch PSW.a ON</li> <li>Swing parking brake release</li> <li>Bypass cut spool (310) changed over</li> <li>Bucket conflux cut</li> </ul>	<ul style="list-style-type: none"> <li>Arm sub spool restrictor forced</li> </ul>
Main circuit	<ul style="list-style-type: none"> <li>Swing motor is driven by P2 pump.</li> </ul>	<ul style="list-style-type: none"> <li>Swing and arm digging by P2 pump</li> </ul>
Arm digging		
Pilot circuit	<ul style="list-style-type: none"> <li>Arm spool control</li> <li>Swing parking brake release</li> <li>Variable recirculation at light load</li> </ul>	<ul style="list-style-type: none"> <li>Forced recirculation at light load</li> </ul>
Main circuit	<ul style="list-style-type: none"> <li>Variable arm digging recirculation at light load</li> </ul>	<ul style="list-style-type: none"> <li>Forced arm digging recirculation at light load</li> </ul>

Fig. 13 Simultaneous circuit, swing priority at swing (LH) & arm digging



**10.6 LOADING MODE CIRCUIT AT SWING BOOM RAISING**

**Objective:** To adjust the dump leading timing.

**Principle:** The circuit changes the boom raising conflux flow (reduction from the max flow) and adjusts (increases) the swing flow.

**Function:** <Pilot circuit>  
If the loading potentiometer on the control board is turned clockwise, the voltage falls. This decreases the current reading of the electromagnetic proportionate valve attached

to the No.2 pump which in turn decreases the electromagnetic proportionate secondary pressure at port PZ.

If the PZ port pressure falls, the PE1 port pressure of C/V falls. The spring action of boom conflux spool (307) then overcomes the pressure and decreases the stroke of the spool for boom conflux. If the loading mode switch is turned to the right end, the boom conflux pressure becomes 0kg/cm<sup>2</sup>. This makes the boom conflux spool unable to change over.

<Main circuit>  
Since the No.2 pump circuit has the boom raising circuit and the swing motor drive circuit connected in parallel, the pressure flows toward a lower pressure side. Usually since the pressure on the swing motor side is lower, more oil flows to the swing motor. Speed of the swing motor in composite operation does not vary much. The more the loading mode switch is turned to the right end, the less the amount of conflux by the No.2 pump becomes. This makes the operating speed of the single boom raising motion slow.

DETAIL C

**10.7 DIFFERENCE BETWEEN COMPOSITE OPERATION AND SINGLE OPERATIONS IN SWING / BOOM RAISING MOTION**

	Independent	Simultaneous
Swing		
Pilot circuit	<ul style="list-style-type: none"> <li>• Swing control valve operation</li> <li>• Auto accel pressure SW.C, ON</li> <li>• Swing pressure SW.A, ON</li> <li>• Swing parking brake release</li> <li>• Neutral cut spool (310) select</li> </ul>	<ul style="list-style-type: none"> <li>←</li> <li>←</li> <li>←</li> <li>←</li> </ul>
Main circuit	<ul style="list-style-type: none"> <li>• Swing motor is driven by P2 pump</li> </ul>	<ul style="list-style-type: none"> <li>←</li> </ul>
Boom raising		
Pilot circuit	<ul style="list-style-type: none"> <li>• Boom spool operation</li> <li>• Auto decel pressure SW.C, ON</li> <li>• Neutral cut spool (310) changeover</li> <li>• Boom conflux spool (307) change-over variable</li> </ul>	<ul style="list-style-type: none"> <li>←</li> <li>←</li> <li>←</li> <li>←</li> </ul>
Main circuit	<ul style="list-style-type: none"> <li>• Conflux flow by P2 pump is much</li> </ul>	<ul style="list-style-type: none"> <li>• Conflux flow by P2 pump is few</li> </ul>

Fig. 14 Simultaneous circuit at slewing (LH) / boom up, loading mode

# 11. PILOT PIPING

No.	COMPONENT NAME	No.	COMPONENT NAME	No.	COMPONENT NAME
1	MAIN PUMP ASSY	22	HYDRO VALVE	33	TERMINAL BRACKET (T/B)
2	GEAR PUMP ASSY	23	SOLENOID VALVE (S/V)	34	SHUTTLE VALVE
3	CONTROL VALVE (C/V)	24	HOLDING VALVE	35	PRESSURE SWITCH (A,B,C)
4	SLEWING (SWING) MOTOR (SM)	25	CHECK VALVE	36	PT BLOCK
5	TRAVEL MOTOR (TM)	26	SHUTTLE VALVE	37	TRAVEL PILOT VALVE (T.PV)
10	SWIVEL JOINT	28	SOLENOID VALVE	38	SOLENOID VALVE (S/V)
11	OPERATING PILOT VALVE (O.PV)	29	ACCUMULATOR	39	INDICATOR
14	MANIFOLD BLOCK	30	RESTRICTOR VALVE		
20	HYDRAULIC TANK	31	REDUCING VALVE		

Piping No. and pressure class	COMPONENT No. & CONNECTING PORT		REMARKS
	FROM	TO	
50	2-OCT	14-P1	Primary pilot pressure delivery
51	14-P6	31-PG1	For automatic slewing parking release pressure source
52-1	31-PG1	23-P	For solenoid valve (23)
52-2	28-P	23-P	For solenoid valve (23)
53-1	28-A1	36-P	For block (36)
53-2	36-P	35-P	For solenoid valve (35)
54-1	36-P	11-P	For RH operating pilot valve (11)
54-2	36-P	11-P	For LH operating pilot valve (11)
55	36-P	37-P	For travel pilot valve (37)
56	31-PG1	22-P1	For hydro valve (22)
57	22-P2	3-Pgd	Bucket conflux command
58	14-A2	1-P1	For power shift solenoid valve at pump (1)
59	28-A2	10-F	Traveling motor 2-speed changeover
60	25-A3	3-Pm	Force re-circulation in FC mode Arm digging
61	3-Pis	1-Pm1	Max. flow cut for No.1 pump in FC mode
62	1-Pm1	1-Pm2	Max. flow cut for No.2 pump in FC mode
63	23-A	3-PL2	Attachment boost pressure command
64	3-PL2	3-PL1	Attachment boost pressure command
65	36-P	3-PS	Servo pressure for side bypass
66	38-A	3-Pis	Max. flow cut for No.1 and No.2 pump in Travel
71	37-1	3-PAL	Travel LH Advance
72	37-2	3-PBL	Travel LH Retract
73	37-3	3-PAR	Travel RH Advance
74	37-4	3-PBR	Travel RH Retract
75	37-Pi	26-PiT	Auto accel PSW C on and 5.5km/h PSW B ON
81-1	11-1	33-1	Bucket digging (PA2)
81-2	33-①	3-PBC	Bucket digging
82-1	11-2	33-2	Bucket discharge (PB2)
82-2	33-②	3-PAC	Bucket discharge
83-1	11-3	33-3	Boom up (PA1)
83-2	33-③	3-PAB	Boom up

Piping No. and pressure class	COMPONENT No. & CONNECTING PORT		REMARKS
	FROM	TO	
84-1	11-4	33-4	Boom down (PB1)
84-2	33-④	3-PBb	Boom down
85-1	11-5	33-5	Slewing LH (PA4)
85-2	33-⑤	4-PiB	Slewing LH
86-1	11-6	33-6	Slewing RH (PB4)
86-2	33-⑥	4-PiA	Slewing RH
87-1	11-7	33-7	Arm digging (PA3)
87-2	33-⑦	3-PAa	Arm digging
88-1	11-8	33-8	Arm extending (PB3)
88-2	33-⑧	3-PBa	Arm extending
90	3-Pi1	1-Pi1	Negative control for No.1 pump
92	3-Pi2	1-Pi2	Negative control for No.2 pump
94	37-Pi	26-PiT	Auto accel and travel alarm pressure sw. cir. on Travel
95	11-API	26-PLAL	Auto accel pressure sw. cir. in Arm and Slewing
96	11-APR	26-PLAR	Auto accel pressure sw. cir. on Boom and Bucket
100	3-PAC	22-Pi1	Bucket extending conflux in hydro valve
101	3-PBC	22-Pi1	Bucket digging conflux in hydro valve
103	3-PBb	24-PL	Release holding valve in Boom down
104	3-PAb	1-P2	Variable loading mode for proportionate solenoid valve
105	1-P2	3-PB1	Variable loading mode command
106	3-PAa	3-Piga	Changeover sequence valve in Arm heavy digging
107	3-Pigc	3-Pigb	Sequence confluent in Arm heavy digging
108	3-PAa	3-PBa	Bucket conflux cut in Arm digging
109	3-PBa	22-Pi2	Bucket conflux cut in Arm digging or extending
110	4-Pi	31-SH	Release slewing parking brake in Slewing
111	3-PAa	31-SH	Release slewing parking brake in Arm digging
112	31-SH	22-Pi2	Bucket conflux cut in Slewing
113	4-Pi	3-Pi3	Slewing priority & Slewing pressure switch A circuit
120	30	2-IN	To gear pump
121	14-A3	4-C	For slewing motor boost pressure
122	4-C	3-Pis	For arm variable recirculation boost pressure
123	37-T	36-T	From Travel pilot valve (37)
124	11-T	36-T	From RH operating pilot valve (11)
125	11-T	36-T	From LH operating pilot valve (11)
126	24-Dr	20-T	From holding valve (24)
127	22-T	20-T	From hydro valve (22)
128	20-T	39	Filter element indicator circuit
129	3-Dr3	20-T	From arm spool 3
130	14-T1	Pump	From manifold block (14)
131	23-T	28-T	From solenoid valve (23)
132	28-T	36-T	From solenoid valve (28)
133	36-T	3-Dr2	From PT block (36)
134	3-Dr2	3-Dr1	From Control valve (3)
135	3-Dr1	20-T	From Control valve (3)
136	3-Pi3	20-T	From arm variable recirculation boost pressure drain
137	3-Pis	3-Pisd	Variable recirculation cut in Arm heavy digging
138	36-T	36-T	From solenoid valve (38)




Fig. 15 Pilot piping (1/2)






12. MAIN PIPING

ITEM	NAME OF PARTS	QTY	REMARKS	ITEM	NAME OF PARTS	QTY	REMARKS	ITEM	NAME OF PARTS	QTY	REMARKS	ITEM	NAME OF PARTS	QTY	REMARKS
1	HOSE	1	SUCTION	30	CLAMP	2		58	CAPSCREW	4	M13×110	87	SPACER	4	
2	CLIP	4		31	BUSHING	2		59	CLIP	2		88	BRACKET	1	
3	TUBE	1		32	CAPSCREW	3	M12×100	60	NUT	4	M8	89	U-BOLT	1	M8
4	O RING	1	G85, 1B	33	ELBOW	1	PF3/4, HEX.30	61	WASHER	1		90	TUBE	1	LH TRAVEL FORWARD
5	CAPSCREW	4	M16×40	34	CAPSCREW	3	M12×45	62	TUBE	4	M12×25	91	TUBE	1	LH TRAVEL BACKWARD
6	LOCK WASHER	4		35	TEE	1	PF1, HEX.41	63	CAPSCREW	2	M12×85	92	TUBE	1	
7	HALF CLAMP	8		36	LOCK WASHER	8		64	CAPSCREW	2	M12×80	93	NUT	1	M10
8	O RING	4	P34, 1B	37	WASHER	5		65	BRACKET	1		94	HOSE	4	L=1400 (55.1')
9	CAPSCREW	8	M12×45	38	HOSE	1	L=1090 (39.4')	66	CAPSCREW	6	M16×50	96	CLAMP	2	
10	LOCK WASHER	8		40	ELBOW	1	PF1, HEX.41, 55	67	WASHER	6		97	CLAMP	2	
11	HOSE	1	DELIVERY L=570 (26.4')	41	CONNECTOR	1	PF1, HEX.46	68	CAPSCREW	3		98	CAPSCREW	4	M10×60
12	HOSE	1	DELIVERY L=730 (28.7')	42	CONNECTOR	4	PF1, HEX.46	69	NUT	20	M12	99	CAPSCREW	2	M12×90
13	TUBE	1	DELIVERY No.1	43	CONNECTOR	2	PF3/4, HEX.41	70	CAPSCREW	4	M12×35	103	CLAMP	2	
14	TUBE	1	DELIVERY No.2	44	BRACKET	1		71	TUBE	1	BOOM (R)	104	TUBE	1	RH TRAVEL FORWARD
15	CONNECTOR	10	PF1, HEX.46, 55	45	ELBOW	1	PF1, HEX.41	72	TUBE	1	BOOM (H)	107	CLAMP	2	
16	O RING	17	P29, 1B	46	HOSE	1	SWING L=1210 (47.6')	73	TUBE	1	ARM (H)	108	COUPLING	1	
17	TUBE	1	RETURN	47	ELBOW	1	PF3/4, HEX.35, 41	74	TUBE	1	ARM (R)	109	TUBE	1	
18	O RING	1	G80, 1A	48	CAPSCREW	1	M10×25	75	WASHER	2		112	TUBE	1	RH TRAVEL BACKWARD
19	CAPSCREW	4	M10×30	49	ELBOW	2	PF1, HEX.41	76	BRACKET	1		113	O RING	1	P24, 1B
20	LOCK WASHER	4		50	HOSE	1	SWING L=1400 (55.1')	77	BRACKET	1		115	PLUG	1	PF1 1/4, HEX 50
21	TUBE	1		51	CAPSCREW	4	M12×60	79	WASHER			117	CLAMP	2	
22	TUBE	1		52	CLIP	2		80	CLAMP	39		118	CLAMP	2	
23	COUPLING	2		53	HOSE	1	TRAVEL DRAIN L=1460 (55.1')	81	BRACKET	2		119	CLAMP	1	
24	COUPLING	3		54	TEE	1	PF1/2, HEX.27	82	TUBE	1	BUCKET (H)	122	CLIP	1	
25	BRACKET	1		55	HOSE	1	DRAIN L=1200 (47.2')	83	TUBE	1	BUCKET (R)				
26	BRACKET	1		56	TUBE	1		84	CONTROL VALVE	1					
29	BYPASS VALVE	1		57	O RING	1	P18, 1B	85	HOLDING VALVE	1					







List of tightening torque for connector and elbow

ITEM	CONNECTION	JOINT
19	5 ± 1 kgf-m (36 ± 7 ft.-lbs)	9.7 ± 0.2 kgf-m (27 ± 1 ft.-lbs)
18	22 ± 2.2 kgf-m (159 ± 16 ft.-lbs)	11 ± 1 kgf-m (80 ± 7 ft.-lbs)
17, 20	45 ± 4.5 kgf-m (325 ± 33 ft.-lbs)	25 ± 2.5 kgf-m (181 ± 17 ft.-lbs)
22	45 ± 4.5 kgf-m (325 ± 33 ft.-lbs)	
23	22 ± 2.2 kgf-m (159 ± 16 ft.-lbs)	

No.	NAME	Q'TY	REMARKS
1	TUBE	1	
2	TUBE	1	
3	TUBE	1	
4	TUBE	1	
5	TUBE	1	
6	TUBE	1	
7	TUBE	1	
8	TUBE	1	
9	TUBE	1	
10	TUBE	1	
11	TUBE	1	
12	TUBE	1	
13	TUBE	1	
14	TUBE	1	
15	CLIP	16	
16	HOSE	2	
17	CONNECTOR	6	PF1, HEX.46×54
18	CONNECTOR	3	PF1/2, HEX.32×36
19	CONNECTOR	3	PF1/4, HEX.19×19
20	CONNECTOR	2	PF1, HEX.46
22	CONNECTOR	4	Ø35, HEX.46×55
23	CONNECTOR	2	Ø22, HEX.32×36
24	TEE	1	Ø22, HEX.32×36
25	TEE	1	Ø10, HEX.17×19
26	O RING	8	P29, 1B
27	O RING	3	P18, 1B
28	O RING	3	P11, 1B
29	CLAMP	2	
30	CLAMP	2	
31	CLAMP	2	
32	CLAMP	2	
33	CAPSCREW	6	M12×40
34	LOCK WASHER	6	M12
35	TUBE	1	
36	TUBE	1	
37	RUBBER	2	
38	HOSE GUARD	2	

Fig. 19 Main piping (3/3)

# KOBELCO

## SHOP MANUAL

Book code No. S5LC1505E

# SK310 SK310LC

### SWING FRAME

#### TABLE OF CONTENTS

**LC15**

1. CAB .....	1
2. FLOOR PLATE .....	3
3. GUARD .....	6
4. COUNTERWEIGHT .....	10
5. FUEL TANK .....	11
6. HYDRAULIC TANK .....	12
7. HYDRAULIC PIPING .....	13
8. AIR CLEANER .....	14
9. POWER TAKEOFF ASSY .....	15
10. AIR CONDITIONER DISMANTLING AND INSTALLING .....	17
11. AIR CONDITIONER PIPING .....	16
12. RADIATOR .....	19
13. FUEL LINE .....	20
14. ENGINE .....	21
15. SWING REDUCTION GEAR .....	23
16. UPPER FRAME .....	24

Applicable Machines  
LC03801~  
YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1996	S6LC1603E K

## 1. CAB

### 1.1 PREPARATION FOR MOUNTING AND DISMANTLING CAB

#### (1) Removing floor mat

#### (2) Removing instrument panel

In order to prepare for removing the instrument panel cover (14) at the back of the Conditioner cover, remove six fasteners (37). Then remove the instrument panel cover (14).




Fig. 1 Removing cover (14)

#### (3) Removing cover assy (32)

Remove the fastener (23), loosen and take off screws (32-4), (32-5), and remove the cover assy (32).

⊕ Screwdriver

#### (4) Removing cover (29)

Loosen and remove capscrews (14) and separate cover (29).

⊕ : 13mm




Fig. 2 Removing cover (29) (32)

#### (5) Removing cover (10), (11)

Remove fastener (23). Loosen and take off semi bolts (30) and remove covers (10), (11).

⊕ Screwdriver




Fig. 3 Removing cover (10)(11)

#### (6) Removing cover assy (3)

Loosen and take off capscrew (14). Then remove cover assy (3).

⊕ : 13mm




Fig. 4 Removing cover assy (3)

- (7) Removing cab harness connector  
Remove the 6P coupler for the wiper.




Fig. 5 Removing cab harness connector

- (8) Removing under cover  
Loosen and remove 18 semi bolts (9). Then remove cover (1), (2).  
⑨ : 19mm

- (9) Pulling out washer hose  
Pull out the window washer hose on the washer tank side.




Fig. 6 Removing under cover

1.2 MOUNTING AND DISMANTLING CAB

- (1) Removing cab-mounting bolts  
Remove cab-mounting capscrow (1)×8 pcs, semi bolt (2)×1 pcs, and nuts (8)×2 pcs.  
① : 17mm, 24mm

- (2) Lifting up cab  
Place a wire sling in two lifting hooks at the top of the cab and lift it up slowly so it does not interfere with the control unit.  
Weight of cab : about 250 kg (550 lbs)

- (3) Mounting cab  
Mounting is done in the reverse order of dismantling.

① : 19mm, 24mm

Tightening torque :

Capscrow (1) : 11±1.5kgf·m (80±11ft·lbs)

Semi bolt (2) : 11±1.5kgf·m (80±11ft·lbs)

Nut (8) : 19±1.2kgf·m (137±14ft·lbs)

Apply Locktite #242.




Fig. 7 Mounting and dismantling cab



## 2. FLOOR PLATE

The floor plate consists of the following devices:  
 Travel lever assy & travel pilot valve,  
 Control box assy,  
 Operator seat assy,  
 Controller & relay assy,  
 Filial piping block (at the bottom face of floor),  
 Washer tank for window wiper (at the bottom face of floor)

The following explains how to dismantle and install the floor plate assy.

### 2.1 PREPARATION FOR DISMANTLING AND MOUNTING FLOOR PLATE

- (1) Removing cap and under cover (1, 2)  
 (Refer to Sect. 1 Cab.)
- (2) Removing cover assy (66), guard assy (12) and air cleaner.  
 (Refer to Sect. 3 Guard and Sect. 8 Air Cleaner.)
- (3) Disconnecting pilot piping.  
 Arrange pilot piping so it is divided on the floor plate side and on the upper frame side, in order to enable lifting it as a floor plate assy.
- 1) Disconnecting pilot piping for operating lever  
 Disconnect the hoses (1) ~ (8) on the pilot valve side of operation changeover terminal bracket.




Fig. 8 Floor plate assy

- 2) Disconnecting travel pilot valve piping  
 Disconnect the hoses for travel operation pilot piping on the pilot valve side of ports 1, 2, 3, 4.




Fig. 9 Disconnecting pilot piping for operating lever (at bracket)




Fig. 10 Removing travel pilot valve piping

3) Disconnecting pipes for 3-spool solenoid valve (5)  
 Disconnect the pilot pipe hose at port A1, A2 and A3.

4) Disconnecting pipe for 1-spool solenoid valve (7)  
 Disconnect the pilot pipe hose at port A.

5) Disconnecting piping for block (4)  
 Disconnect the pilot pipe hose at port T of the block side.




Fig. 11 Disconnecting 3-spool solenoid valve piping




Fig. 12 Disconnecting piping for block (119)

(4) Disconnecting harnesses

- 1) Separate the harnesses under the floor.  
 2P coupler for decal pressure switch  
 2P coupler for washer tank
- 2) Separate the connector for harnesses running from under the floor to the top of the floor. Separate them at the jointed part of the connector (Refer to Instrument Panel for Electric System)




Fig. 13 Separating harness connectors

15) Disconnecting air conditioner piping  
 Disconnect two pipes on the air conditioner side.




Fig. 14 Disconnecting air conditioner pipes

- (6) Disconnecting cable (3) for the emergency stop of engine

Disconnect the E/G emergency stop cable (3) at rod end (11) of the engine stop lever.




Fig. 15 Disconnecting the engine emergency stop cable

## 2.2 DISMANTLING AND INSTALLING FLOOR PLATE ASSY

- (1) Removing rubber cushion mounting capcrews  
Remove four capcrews (28) that mount rubber cushion (10) to the bottom face of the floor plate.

② : 24mm




Fig. 16 Lifting floor plate assy

- (2) Dismantling floor plate

Put an eye bolt M12 into each of the four cab mounting holes (※2) and lift them with the air conditioner assy.

- (3) Installation

Installation of the floor plate is performed in the reverse order of dismantling

Rubber cushion mounting capcrew (28)

② : 24mm,

Tightening torque :  $19 \pm 2 \text{ kgf}\cdot\text{m}$   
( $137 \pm 14 \text{ ft}\cdot\text{lbs}$ )

Apply Locktite #242.





Fig. 17 Dismantling floor plate

### 3. GUARD

#### 3.1 PREPARATION FOR DISMANTLING AND INSTALLING GUARDS

- (1) Removing engine cover assy (60)  
Unlock catches (28, 29), open cover assy (60), remove nut (36) and separate cover (60) from bracket (91).  
Remove capscrew (33) and take off spring assy (23).  
 : 19mm
- (2) Separate the harnesses for the swing flasher and the back light.
- (3) Dismantle the counterweight.  
(Refer to para. 4. Counterweight.)




Fig. 18 Cover assy and guard assy






Fig. 19 Removing engine cover assy (60)

#### 3.2 REMOVING COVER ASSY AND GUARD ASSY

- (1) Removing cover assy (95)  
Unlock lock (95-1H), open cover (95), remove nut (37) and dismantle cover assy (95).  
 : 17mm
- (2) Removing cover assy (66)  
Open cover assy (66), remove capscrew (63) for hinge (66-1C) and separate cover assy.  
 : 17mm




Fig. 20 Removing cover assy (95)





Fig. 21 Separating cover assy (66)

(3) Removing cover assy (94)

Unlock lock (94-1F), open cover (94), remove nut (37) and separate cover assy (94).

 : 17mm





Fig. 22 Removing cover assy (94)

(4) Removing guard (14)

Remove semi bolt (31) and separate guard (14) with catches (28, 29).

 : 19mm





Fig. 23 Removing guard (14)

(5) Removing guard assy (12)

Remove semi bolt (31) and separate guard assy (12).

 : 19mm





Fig. 24 Removing guard assy (12)

(6) Removing cover assy (15)

Open cover assy (15) by hinge (15-1D), remove nut (37) and separate cover assy (15) from bracket (4).

 : 17mm





Fig. 25 Removing cover assy (15)

- (7) Removing bracket (13)  
Remove semi bolt (30) and separate bracket (13).

 : 19mm





Fig. 26 Removing bracket (13)

- (8) Removing handrail (22)  
Remove semi bolt (31) and separate the handrail.

 : 19mm





Fig. 27 Removing handrail (22)

- (9) Removing box assy (21)  
Unlock lock (21-2H), open cover (21-2) by hinge (21-2E), remove semi bolt (30) and separate box assy (21).

 : 19mm






Fig. 28 Removing box assy (20)


- (10) Remove bracket (91) (See Fig. 29.)  
Remove semi bolt (30) and separate bracket (91).

 : 19mm

- (11) Removing guard assy (10)  
Remove semi bolt (31) and separate guard assy (10).

 : 19mm

- (12) Removing guard assy (57)  
Remove semi bolt (31) and separate guard assy (57).

 : 19mm




Fig. 29 Guard assy and brackets

(13) Removing brackets (90), (2)

Remove semi bolt (30) and dismantle brackets (90), (2).

$\varnothing$  : 19mm

### 3.3 MOUNTING

When attaching the brackets, cover assy, guard assy, etc, use capscrews, semi bolt or parts of the same part numbers and tighten them to the torques given in Table 1

Table 1

Tightening torque		Unit kgf-cm (ft-lbs)	
Size	Semi bolts	Cup screw	Machine screw
M5	-	-	0.81 ± 0.08 (5.86 ± 0.58)
M8	-	3.6 ± 0.4 (26 ± 2.9)	2 ± 0.2 (14.47 ± 1.45)
M10	5.0 $\pm_{-0}^{+0.5}$ (36 $\pm_{-0}^{+1.6}$ )	7.2 ± 0.7 (52.1 ± 5.1)	-
M12	8.5 ± 0.5 (61 ± 3.6)	11 ± 1 (80 ± 7.2)	-

## 4. COUNTERWEIGHT

### 4.1 PREPARATION FOR DISMANTLING AND INSTALLING COUNTERWEIGHT:

To prepare to dismantle the counterweight assy, remove the engine cover assy at the back of the upper swing body and the cover assy (4), and separate the harness connector of the rear work light.

### 4.2 DISMANTLING AND INSTALLING COUNTERWEIGHT

#### (1) Dismantling

- 1) Remove plug (5) on the top face of the counterweight assy. Attach a lifting jig to the tapped holes (M48) and lift the assy so it is tensioned slightly.
- 2) Adjust the tension of the wire sling by loosening four capscrews (M36×240), (9) that fasten the counterweight assy from its bottom side and draw out the capscrews

⑨ : 55mm

- 3) Separate the counterweight assy from the swing frame by means of the wire sling that was used to lift the assy.

Weight of counterweight assy :

about 6.12 tons (13,460 lbs)




Fig. 30 Counterweight assy

- ⚠** Make sure that the insulation is plastered securely and that protectors (2, 3) are fixed firmly.

Note that adjusting shims (6, 7, 8) are placed on the mount. Take a record of these locations when removing the shims.

#### (2) Mounting

- 1) Mounting is performed in the reverse order of dismantling. Prepare the shims (6, 7, 8) that were recorded before.
- 2) Place a wire sling in the lifting jig that was attached to the counterweight assy, and lift and bring the assy close to a fixed place.
- 3) Insert shims (6, 7, 8). Put capscrews (9) coated with Loctite #242 and washers (13) in place, and temporarily fasten.
- 4) Check that the counterweight assy is placed in correct position. Then fasten the screws to a torque of  $300 \pm 30$  kgf·m ( $2170 \pm 217$  ft·lbs). Remove the lifting jig and attach plug (5).

⑨ : 55mm

- ⚠** The clearance between the guard and the counterweight shall be 10mm (0.39"), and the vertical difference shall be within 6mm (0.24")




Fig. 31 Detaching and attaching counterweight



## 5. FUEL TANK


### 5.1 PREPARATION FOR DISMANTLING AND INSTALLING FUEL TANK

Before dismantling or installing the fuel tank, take off the surrounding covers and guards in order to facilitate the operation.

### 5.2 DISMANTLING AND INSTALLING FUEL TANK

#### (1) Dismantling


- 1) Loosen the cock (9) under the fuel tank to discharge the remaining oil. Disconnect the hoses on the feed and return sides of the fuel pipe and plug the openings of the pipe so as not to allow entry of dust and other foreign matter.
- 2) Disconnect the wiring on the connector side of sending unit (5).
- 3) Loosen six mounting capscrews (10) at the bottom of fuel tank (1) and remove them with washers (11).

 : 30mm

- 4) Place a wire sling in fuel tank (1).  
Weight of fuel tank assy . 210kg (465 lbs)

#### (2) Mounting

- 1) Mounting is performed in the reverse order of dismantling. Place a wire sling in fuel tank (1) and lift it onto a fixed position.
- 2) Coat capscrews (10) with Loctite #271 and tighten them with washers (11).

 : 30mm,

Tightening torque :  $55 \pm 5 \text{ kgf}\cdot\text{m}$   
( $398 \pm 36 \text{ ft}\cdot\text{lbs}$ )

- 3) Refit the removed fuel pipes back in place.
- 4) Connect the connector for the wiring for sending unit (5).
- 5) Attach the removed covers and guards.
- 6) Close cock (9), remove filler cap (3), fill in fuel and check the fuel level on the fuel gauge of the gauge cluster.




Fig. 32 Fuel Tank

### 5.3 COMPONENT PARTS

Item	NAME	Q'ty	Item	NAME	Q'ty
1	FUEL TANK	1	10	CAPSCREW	6
2	STRAINER	1		(M20×45)	
3	FILLER CAP	1	11	WASHER	6
4	KEY	1	12	SHIM (L=1.0)	5
5	SENDING UNIT	1	13	FLANGE	1
6	PACKING	1	14	ORING	1
7	MACHINESCREW	5	15	CAPSCREW	4
	(M5×12)			(M10×25)	
8	LOCK WASHER	5	16	LOCK WASHER	4
9	COCK	1	17	PLUG (PT 1/2)	1

## 6. HYDRAULIC TANK

### 6.1 PREPARATION FOR DISMANTLING AND MOUNTING HYDRAULIC TANK

- Before dismantling or mounting the hydraulic tank, take off the surrounding guards and disjoint brackets.
- Since the hydraulic tank is pressurized, remove the cap nut at the top of air breather (22) on top of tank (28) and press the plunger in the center.
- After venting, remove plunger (4).

### 6.2 DISMANTLING AND MOUNTING HYDRAULIC TANK

#### (1) Dismantling

- Place a clean container of more than 300 ℓ (80 gal) capacity under the hydraulic tank, take off plug (19) with O ring, and discharge hydraulic oil. Disconnect the suction hose, return hose and drain hose and cover the connections with a proper means to prevent entry of dust and other foreign matters.

④ : 86mm

- Separate the connector of level switch (10) and the manifold block.

④ : 10mm, 17mm

- Loosen four capscrews (12) located at the bottom of hydraulic tank and remove them with washers (13).

④ : 30mm

- Lift up hydraulic tank (28) by crane.

Weight of hydraulic tank assy :  
about 240kg (528 lbs)

#### (2) Installation

- Installation is performed in the reverse order of dismantling; Place a wire sling in hydraulic tank (28) and lift it onto a fixed position.

- Make sure that plug (19) with O ring is fastened tight.

④ : 36mm.

Tightening torque  $16.5 \pm 1.5 \text{ kgf}\cdot\text{m}$   
( $119 \pm 11 \text{ ft}\cdot\text{lbs}$ )

- Adjust the gap using shim in case of the gap between the tank mount and the frame is more than 1mm (0.04").

- Screw in capscrews (12) coated with Locktite #271, and washers (13) into the tapped holes in the bottom of hydraulic tank (28).

④ : 30mm,

Tightening torque  $55 \pm 5 \text{ kgf}\cdot\text{m}$   
( $398 \pm 36 \text{ ft}\cdot\text{lbs}$ )

- Reconnect the disconnected suction hose, return hose and drain hose back in position.

- Fit the connector and manifold block of the level switch.

④ : 10mm.

Tightening torque  $0.45 \pm 0.05 \text{ kgf}\cdot\text{m}$   
( $3.3 \pm 0.4 \text{ ft}\cdot\text{lbs}$ )

- Connect the tank with brackets and attach the surrounding guards.

- Fill in a designated hydraulic oil from flange (4) (Flange (4) is already removed under 6.1 (3)), and confirm the oil level on level gauge (11).

- Attach flange (4).




Fig. 33 Hydraulic tank

### 6.3 COMPONENT PARTS

Item	NAME	Q'ty	Item	NAME	Q'ty
2	SUCTION STRAINER	1	17	CAPSCREW (M6×10)	3
3	FLANGE	2	18	LOCK WASHER	7
4	FLANGE	1	19	PLUG (PF 3/4)	1
5	O RING	1	20	PLUG	2
6	BYPASS VALVE	2	21	O RING	2
7	RETURN FILTER	2	22	BREATHER	1
8	BYPASS VALVE	2	23	CAPSCREW (M6×60)	4
9	SPRING	2	24	CAPSCREW (M12×22)	6
10	LEVEL SWITCH	1	25	CLIP	1
11	LEVEL GAUGE	1	26	CAPSCREW (M8×16)	1
12	CAPSCREW (M20×45)	4	27	LOCK WASHER	1
13	WASHER	4	28	HYDRAULIC TANK	1
14	SHIM	3			
15	CAPSCREW (M12×30)	6			
16	LOCK WASHER	14			

## 7. HYDRAULIC PIPING

### 7.1 GENERAL PRECAUTIONS TO BE EXERCISED WHEN DETACHING AND ATTACHING HYDRAULIC PIPING.


- (1) Before detaching and attaching the hydraulic piping, bleed off the pressure of the hydraulic oil tank and drain out all hydraulic oil through the drain plug.
- (2) When disconnecting the tubes and hoses from the joints, make sure that they are not internally pressurized and then loosen the nuts of the joints.
- (3) Prepare an oil container in order to receive hydraulic oil flowing out of the tubes and hoses when joints are removed.

- ⚠** It becomes a public nuisance to pour hydraulic oil onto the ground. Take care so as not to let oil out.
- (4) Always put a blind plug to both ends of the removed joints so as to prevent entry of foreign matter. Further, when temporarily placing tubes, hoses and joints independently, place them on a clean stand and put a cover on them to protect them from foreign matter.
  - (5) When removing them, put a tag or something to each of them, considering re-installation.
  - (6) Always tighten the joints to a specified torque.

Joints come in the following three types. Different tightening torques are produced even if spanners of the same size are used. Therefore, refer to the graph and the Tables in the following : Regarding the main piping and the pilot piping, refer to Hydraulic System.


#### • ORS joint (O ring seal type)

	SIZE	SPANNER USED mm	TIGHTENING TORQUE kgf-m (ft-lbs)
	HOSE AND JOINT	1-14	30 32
1-3/16-12		36 41	$18 \pm 1.8$ ( $130 \pm 13$ )
1-7/16-12		41 46	$21 \pm 2.1$ ( $152 \pm 15$ )



YK-874

Fig. 34 Kinds of Joints and Tightening torques



YK-874

#### Construction

1. Joint
2. O ring
3. Union nut
4. Hose and tube

Fig. 35 ORS joint

#### • Flareless joint:

Tube size O.D. × Thickness mm	SPANNER USED mm	TIGHTENING TORQUE kgf-m (ft-lbs)
10 × 1.5	19	$5 \pm 1$ ( $36 \pm 7$ )
15 × 2.0	27	$12 \pm 1.2$ ( $87 \pm 9$ )
18 × 2.5	32	$15 \pm 1.5$ ( $108 \pm 11$ )
22 × 3.0	36	$22 \pm 2.2$ ( $159 \pm 16$ )
28 × 4.0	41	$26 \pm 2.6$ ( $202 \pm 20$ )
35 × 5.0	55	$45 \pm 4.5$ ( $325 \pm 33$ )

#### • O ring type joint

SCREW DIA. (PF)	SPANNER USED mm	TIGHTENING TORQUE kgf-m (ft-lbs)
1/8	14	$1.7 \pm 0.2$ ( $12 \pm 1$ )
1/4	19	$3.7 \pm 0.2$ ( $27 \pm 1$ )
3/8	22	$7.5 \pm 0.5$ ( $54 \pm 4$ )
1/2	27	$11 \pm 1$ ( $80 \pm 7$ )
3/4	36	$10.5 \pm 1.5$ ( $119 \pm 11$ )
1	41	$26 \pm 1$ ( $188 \pm 7$ )

## 8. AIR CLEANER

The intake air sucked from the side and top of the radiator is purified by the air cleaner element and used for the intake air of the engine via hoses (25), (29). Switch Assy (7-11) is installed to the air cleaner and warns of clogging of the element on the multi display of the operator's cab.

### 8.1 DISMANTLING AND MOUNTING AIR CLEANER

#### (1) Dismantling

**⚠** Arcs heated hot exist nearby while the engine is running. Proceed to disassembly operation after the engine has cooled off sufficiently.

- 1) Separate the engine cover Assy and the cover Assy in the neighborhood of the air cleaner.
- 2) Remove clip (16), (17) and separate hose (25) from air cleaner (7).
- 3) Remove semi bolt (47) and separate air cleaner (7) from the guard. On that occasion, make sure that the insulation is plastered securely to the box.

 : 19mm


- 4) Remove clip (17), (18) and separate hose (29) from the turbo and tube (30).
- 5) Remove cap screw (59) and separate tube (30) from the guard.

 : 17mm


#### (2) Mounting

The mounting of the air cleaner is performed in the reverse order of dismantling.

- 1) Install air cleaner (7) to the guard, using semi bolt (47).

 : 19mm

- 2) Install tube (30) to the guard by means of cap screws (59).

 : 12mm

- 3) Inserting dimension into the both side of hose (25) and tube (30) side of hose (29) are  $40 \pm 5\text{mm}$  ( $1.575 \pm 0.2$ ).

Inserting dimension into turbo side of hose (29) is  $30 \pm 5\text{mm}$  ( $1.181 \pm 0.2$ )

- 4) Switch Assy (7-11) is screwed on the air cleaner. When replacing or removing switch Assy, beforehand tighten it by the specified torque.

Tightening torque:  $0.1 \sim 0.2\text{kgf}\cdot\text{m}$

( $0.72 \sim 1.45\text{ft}\cdot\text{lbs}$ )





Fig. 36 Air cleaner

### 8.2 COMPONENT PARTS

Item	NAME	Q'ty	Item	NAME	Q'ty
7	AIR CLEANER	1	30	TUBE	1
7-11	SWITCH ASSY	1	47	SEMS BOLT (M12×30)	8
16	CLIP	1	55	WASHER	4
17	CLIP	2	59	CAPSCREW (M10×20)	4
18	CLIP	1	65	FILTER ELEMENT	1
25	HOSE	1			
29	HOSE	1			

## 9. POWER TAKEOFF ASSY

The power takeoff assy consists of hydraulic pump (1), gear pump (11), bracket (3) and coupling (12). The power takeoff assy is fixed to the engine flywheel housing via bracket (3). The drive shaft (input shaft) is connected with the flywheel of the engine by means of coupling assy (12) so as to absorb jerky load variations between the engine and the hydraulic pump.

### 9.1 PREPARATION FOR DISMANTLING AND INSTALLATION OF POWER TAKEOFF ASSY

#### (1) Removing covers

After the engine stops, remove the engine cover assy, guards and muffler so the pump can be drawn out.

#### (2) Mounting hydraulic suction stopper

Vent air through air breather (22) on the hydraulic tank, separate flange (4), and draw out suction strainer (2). After drawing out the suction strainer, install the suction stopper to prevent the hydraulic oil from flowing out.

### 9.2 DISMANTLING AND INSTALLATION OF POWER TAKEOFF ASSY

#### (1) Installation

- 1) Place a wire sling in the eye bolt at the top center of the hydraulic pump, give it slight tension, and remove capscrews (9).

⑨ : 17mm, weight : 219 kg (482 lbs)

However, when separating the bracket from pump (1), loosen capscrew (4) about half turn before loosening capscrews (9).

- 2) Draw out the power takeoff assy from the flywheel housing assy slowly, while adjusting the tension of the wire sling.

On that occasion, coupling (12) is separated, insert (12-2) and hub (12-9) are on the hydraulic pump, insert (12-3) and flange (13) are on the flywheel side, and element (12-1) is fixed on either side.

- 3) Remove capscrews (12-4) attached insert (12-3) and flange (13) to the flywheel.

Then take off insert (12-3), flange (13) and four spring pin (12-7).

⑦ : 17mm




Fig. 37 Power takeoff assy




Fig. 38 Installing suction stopper




Fig. 39 Detaching and attaching coupling

4) When removing insert (12-2), remove capscrews (12-5) attached to hub (12-9). Then take off four inserts (12-2) and eight spring pins (12-6).

← : 17mm

5) Loosen setscrew (12-8) and draw out hub (12-9) from the shaft of the hydraulic pump.

← : 10mm

6) When replacing the pump, remove capscrews (4,5) and separate bracket (3) from hydraulic pump (1).

← : 17mm

(2) Installation

1) Coat capscrews (4,5) with Loctite #242 and install bracket (3) to the hydraulic pump. On that occasion, coat the mounting face of the pump with Loctite #515

← : 17mm,

Tightening torque:  $44 \pm 3$  kgf·m  
( $318 \pm 22$  ft·lbs)

2) Insert hub (12-9) in the shaft of the hydraulic pump, protrude the end of shaft 5mm (0.2") from the face of the hub (12-9) and fix the assy to the shaft by means of setscrew (12-8) coated with Loctite #242.

← : 10mm,

Tightening torque:  $21 \pm 1$  kgf·m  
( $152 \pm 7$  ft·lbs)

3) Drive eight spring pins (12-6) into hub (12-9), and fix four inserts (12-2) to hub (12-9) by means of capscrews (12-5).

← : 20mm,

Tightening torque:  $46 \pm 3$  kgf·m  
( $333 \pm 22$  ft·lbs)

4) Drive four spring pins (12-7) into flange (13), and fix inserts (12-3) to flange (13).

5) Fix flange (13) and inserts (12-3) assembled in the foregoing paragraph to the flywheel.

← : 17mm,

Tightening torque:  $40 \pm 3$  kgf·m  
( $300 \pm 23$  ft·lbs)

6) Assemble element (12-1) to insert (12-3) on the engine side.

7) Lift the hydraulic pump assy horizontally, engage insert (12-2) on the hydraulic pump with element (12-1) on the flywheel side, and push in the hydraulic pump assy

8) Install bracket (3) to the flywheel housing and fasten them with capscrews (4) coated with Loctite #242.

On that occasion, apply Loctite #515 to the mating faces between the flywheel housing and bracket (3)

← : 8mm,

Tightening torque:  $7 \pm 0.7$  kgf·m  
( $51 \pm 5$  ft·lbs)  
 $5 \pm 0.5$  ( $0.2 \pm 0.02$ )




Fig. 40 Power Takeoff assy

9.3 COMPONENT PARTS

Item	NAME	Q'ty	Item	NAME	Q'ty
1	HYDRAULIC PUMP	1	12-3	INSERT	4
2	LOCK WASHER	1	12-4	CAPSCREW	4
3	BRACKET	1		(M20×60)	
4	CAPSCREW	1	12-5	CAPSCREW	4
				(M20×85)	
5	CAPSCREW	3	12-6	SPRING PIN	8
				(M20×60)	
6	O RING	1	12-7	SPRING PIN	4
7	CAPSCREW	2	12-8	SET SCREW	2
				(M20×25)	
8	WASHER	2	12-9	COUPLING HUB	1
9	CAPSCREW	12	13	FLANGE	1
				(M10×30)	
10	LOCK WASHER	2	14	NUT	2
11	GEAR PUMP	1	15	BRACKET	1
12	COUPLING	1	16	CAPSCREW	2
12-1	ELEMENT	4		(M20×100)	
12-2	INSERT	4	17	WASHER	4
			18	WASHER	1

## 10. AIR CONDITIONER

The structure, operation, disassembly, assembly, etc of the air-conditioning system are described fully in a separate volume. This section describes how to remove and install the air-conditioning system in the cab.

- ▲ The new refrigerant R134a is used for the air conditioner of this machine. The specification differs from the conventional fluorine-gas-used air conditioner.
- Electric fittings including a controller are mounted on the air-conditioner and electric fittings.

### 10.1 PREPARATORY ARRANGEMENTS FOR REMOVING AND INSTALLING AIR-CONDITIONING UNIT

- (1) Remove 18 fasteners (28) to remove cover (10).
- (2) Remove cab. (Refer to para. 1 cab.)

### 10.2 REMOVING AND INSTALLING AIR-CONDITIONING UNIT

#### (1) Removing

- 1) Draw out the grill hose band from part A on the air-conditioner side.
- 2) A controller and other electric fittings are placed on the air-conditioner. Separate the connectors connecting the instrument panel harness with other harnesses from parts D, E, F, G, H, I, J, K, L, M and N.
- 3) Remove the cooler hose and the heater hose from the air-conditioner unit.
- 4) Loosen and remove six capscrews (17) that fasten the air-conditioner, and lift up the air-conditioner unit.

● : 17mm, weight of air-conditioning unit : 30kg (66 lbs)

#### (2) Installing

- 1) Install air-conditioning unit by reversing the procedure of removal.
- 1) Install the air-conditioner unit to the floor plate.
  - : 17mm,
- 2) Fasten the heater hose with a hose band. Tighten the cooler hose to a designated torque.
- 3) Reconnect all harness connectors.
- 4) Insert the grill hose.
- 5) Mount the cab. (Refer to para. 1 cab.)
- 6) Install cover (10) with fastener (28).




Fig. 41 Outside view of air-conditioner




Fig. 42 Inst-panel harness connector




Fig. 43 Air-conditioner mounting bolts (17)

## 11. AIR CONDITIONER PIPING

### 11.1 CONSTRUCTION AND FUNCTION

#### 1) Cooler section

The cooler section of the air-conditioner consists of an air-conditioner unit, a receiver tank, and a compressor.


Both IN and OUT hoses connected with the receiver tank are called L hose, while the hose connecting with the suction side of the compressor is called S hose. Also the hose connecting with the delivery side of the compressor is called D hose.

#### 2) Heater section

The heater section of the air-conditioner consists of an air-conditioner unit, and an engine cooling water block.

AC unit side    IN ——— OUT  
                   OUT ——— IN

Connect hoses so they are located on the engine side.



### 11.2 DETACHING AND ATTACHING AIR-CONDITIONER

Regarding the attaching and detaching of the air-conditioner piping, refer to the figure below.




Fig 44 Air conditioner piping



## 12. RADIATOR

The radiator assy consists of a cooling water radiator, an oil cooler and a sub tank.


### 12.1 PREPARATION FOR DISMANTLING AND INSTALLING RADIATOR

- 1) Dismantle the engine cover, guards, air cleaner hoses around the radiator, (Refer to Dismantling and Installation of Guards and Air Cleaner.)
- 2) Open the cock under the radiator and drain out the water from inside the radiator.
- 3) Attach the suction stopper to the hydraulic tank and draw out the hydraulic oil of the oil cooler. (Refer to Dismantling and Installation of Power Take off Assy.)


### 12.2 DISMANTLING AND INSTALLATION OF RADIATOR ASSY

#### (1) Dismantling

- 1) Disconnect all hoses connected to the radiator and the oil cooler.
- 2) Remove fan guard.
- 3) Remove capscrews (45,46) that fasten stays (10).

 : 19mm


- 4) Attach an eye bolt M12 to each of the tapped holes to which the stays were installed. Place a wire sling in them and tension the wire sling so it will not get loose.
- 5) Loosen and draw out capscrews (44) that fix the legs of the radiator assy to the frame. Then remove the radiator assy so as to prevent the shroud from interfering with the fan.

 : 30mm

Weight of radiator assy : 123 kg (270 lbs)


#### (2) Installation

- 1) Place a wire sling in the radiator, install it, and temporarily fasten it with capscrews (44).


 : 30mm

 Confirm that insulators (37,38) are not damaged.

- 2) Temporarily fasten stays (10), (11) by means of capscrews (45,46).

 : 19mm

- 3) Adjust the clearance between the fan and the radiator shroud  $22.5 \pm 1.5$  mm ( $0.89 \pm 0.2$ ") throughout all circumference. Also adjust so the fan is inserted axially  $64 \pm 5$  mm ( $2.52 \pm 0.2$ ") into the shroud. Then coat capscrews (44) with Locktite #242 and tighten them.

 : 30mm

- 4) Fix all hoses, and adjust so the dimension of the inserting hose is 40mm (1.575"). Also, adjust so the clearance between the radiator hose (23) and the center section plate of the upper frame is  $29 \pm 5$  mm ( $1.142 \pm 0.2$ ").
- 5) Fill in cooling water to a designated level.
- 6) Run the engine for about ten minutes and confirm no water leakage.
- 7) Fill sub tank (6) with cooling water.




Fig. 45 Radiator assy

### 12.3 COMPONENT PARTS

Item	NAME	Q'ty	Item	NAME	Q'ty
3	RADIATOR ASSY	1	41	CAPSCREW	2
6	WATER TANK	1	44	CAPSCREW	4
9	PLATE ASSY	1	45	CAPSCREW	2
10	STAY	1	46	CAPSCREW	2
11	STAY	1	48	CAPSCREW	1
13	SUPPORT	1	52	LOCK WASHER	2
16	CLIP	4	53	LOCK WASHER	4
23	HOSE	1	57	WASHER	4
24	HOSE	1	58	WASHER	4
26	HOSE	1	64	WASHER	1
27	HOSE	1			
32	LOCK WASHER	4			
37	INSULATOR	1			
38	INSULATOR	1			
39	CLIP	1			

## 13. FUEL LINE

The fuel from the fuel tank passes through the separately installed filter (5), and is separated and removed the water mixed in the fuel.

The fuel which coming out from the separator (5) is supplied to the fuel filter installed on the engine by way of the separately installed filter (73) and the fuel pump installed on the fuel injection pump, and remove the impurities mixed in the fuel.

The fuel from the fuel filter is supplied to the fuel injection pump and inject from the nozzles. The oil returned from the engine is brought back directly to the fuel tank.

### 13.1 PREPARATION FOR DISMANTLING AND INSTALLATION OF FUEL LINE

- 1) Engine stop
- 2) Discharging fuel  
Loosen the cock under the fuel tank and discharge the remaining fuel.
- 3) Dismantle parts necessary for detaching and attaching the fuel line such as the engine cover, guard and muffler.

### 13.2 DETACHING AND ATTACHING FUEL LINE

- (1) Detaching
  - 1) Loosen the drain cock of the water separator and drain out water.
  - 2) Take off clips (20, 22, 49, 63) and disconnect hoses.
- (2) Attaching
  - 1) Attach hoses with clips (20, 22, 49, 63).  
 ⚠ For antife, fuel hose must be attached at correct mounting position.
  - 2) Replace the fuel filter element where necessary.
  - 3) Close the cock at the bottom face of the fuel tank and fill with fuel.
  - 4) Loosen the overflow valve of the distributor, the air venting plug of the fuel filter and the air plug of the water separator. Operate the fuel feed pump to vent air.
  - 5) Start the engine and run it at low idle revolution for more than one minute to confirm operation.
  - 6) Make sure of no fuel leakage.
  - 7) Install the engine cover, guard and muffler that were removed before.





Fig. 46 Fuel line

### 13.3 COMPONENT PARTS

Item	NAME	Qty	Item	NAME	Qty
5	FILTER (WATER SEPARATOR)	1	55	WASHER	3
19	CLIP	1	59	CAPSCREW (M10×20)	3
20	CLIP	6	60	NUT (M10)	1
22	CLIP	1	62	HOSE	1
28	HOSE	1	63	CLIP	6
42	CAPSCREW (M10×30)	2	73	FILTER ASSY	1
49	CLIP	3	74	BRACKET	1
52	LOCK WASHER	6	75	HOSE	1
54	HOSE	1	76	HOSE	1

## 14. ENGINE

### 14.1 PREPARATION FOR DISMANTLING AND INSTALLATION OF ENGINE

Before the engine is dismantled, the following operations must be completed. When installation has been completed, reassemble the engine by doing the same operations.

- 1) Discharge the oil of the fuel tank and the hydraulic oil tank.
- 2) Dismantle the guards, counterweight, radiator assy, air cleaner and muffler assy. (Refer to the Dismantling and Installation Procedures for each equipment.)
- 3) Disconnect the fuel hoses
- 4) Disconnect the piping to the pump.
- 5) Disconnect the connectors for the harnesses for sensors.

**!** Prepare a support which withstands the weight of the engine assy and on which the dismantled engine may be placed securely.

### 14.2 DISMANTLING AND INSTALLING ENGINE

#### (1) Dismantling

- 1) Removing engine mounting nuts  
Loosen and remove four engine mounting nuts (12) and draw out capscrews (10).
- 2) Lifting engine  
Place a wire sling in the lifting metal at the top of the engine and lift it up  
Weight of engine : about 900 kg (2180 lbs)
- 3) After dismantling of engine  
Remove the rubber mounts (1), (2) and cover (5) on the engine mounting frame.

#### (2) Installation

Coat the following parts with Locktite or ThreeBond and tighten the parts to the tightening torques of the following table.






Fig. 47 Mounting engine

### 14.3 TIGHTENING TOOLS

NAME	Size	Width across flat
 Spanner	M10	17
	M12	19
	M14	22
 Socket	M16	27

### 14.4 COMPONENT PARTS

Tightening Torque	Item	NAME	Q'ty	Tightening Torque	Item	NAME	Q'ty
55 ± 6 kgf-m (405 ± 43 ft-lbs) Loctite #271	1	RUBBER MOUNT	4	10 ± 1 kgf-m (72 ± 7 ft-lbs) Loctite #242	13	CAPSCREW (M12 × 35)	8
	2	RUBBER MOUNT	4		14	WASHER	8
	3	BRACKET	1		15	CAPSCREW (M14 × 35)	8
	4	BRACKET	1	15 ± 1 kgf-m (105 ± 7 ft-lbs) Loctite #242	16	WASHER	8
	5	BRACKET	1		17	CAPSCREW (M10 × 30)	1
	6	BRACKET	1		18	CLIP	1
	7	LOCK WASHER	2	4 ± 0.4 kgf-m (29 ± 2.9 ft-lbs)	20	NUT	1
	8	COVER	4				
	9	CAPSCREW (M20 × 130)	4				
	10	WASHER	8				
	11	NUT (M20)	1				

## 15. SWING REDUCTION GEAR

The swing motor is installed at the top of the swing reduction gear. In order to install the swing reduction gear to the swing frame or dismantle the reduction gear from the swing frame, dismantle or install the swing unit that integrates the reduction gear with the motor.

### 15.1 PREPARATION FOR DISMANTLING AND INSTALLING SWING REDUCTION GEAR

- 1) Remove guards. (Refer to the procedure for dismantling and installation of guards.)
- 2) Vent air from the hydraulic tank.
- 3) Attach the suction stopper to the hydraulic tank.
- 4) Disconnect the pipes and install caps and plugs to prevent entry of foreign matter.

### 15.2 DISMANTLING AND INSTALLING SWING REDUCTION GEAR

#### (1) Dismantling

##### 1) Removing capscrews

Loosen and remove fourteen capscrews (1) that fasten the flange of the swing reduction gear.

① : 36mm

##### 2) Lifting swing unit

Put an eye bolt into each of the tapped holes for the lifting screw (M12×1.75) located at the top of the swing motor assy. Place a wire sling in the swing unit, lift it up and bring it down on a prepared stand.

Weight of swing unit: about 490 kg (1080 lbs)

#### (2) Installation

##### 1) Checking the mounting face

Installation is performed in the reverse order of dismantling. Before entering installation operation, make sure that the mating faces of the flanges of the upper frame and of the swing reduction gear are free from burrs and stain.

##### 2) Coating the mounting faces with Loctite

Coat the mounting face of the swing reduction gear of the upper frame with Loctite #615.

##### 3) Lifting and placing swing unit

Using the same lifting jig that was used to dismantle the swing unit, lift it and install it in place, while checking the faucet joint of the flange, the meshing of the pinion at the end of the reduction gear shaft, the mounting holes for the capscrews and the orientation of the swing reduction gear.

##### 4) Attaching capscrews

Coat the threaded part of capscrews (1) with Loctite #242, screw them in and tighten them to install the swing reduction gear to the upper frame.

② : 36mm,

Tightening torque:  $95 \pm 9.5$  kgf·m

(687 ± 69 ft·lbs)




Fig. 48 Dismantling and installing swing reduction gear

Apply Loctite #242 Equivalent

Tightening torque  
 $95 \pm 9.5$  kgf·m (687 ± 69 ft·lbs)

Apply Loctite #515  
Equivalent




Fig. 49 Mounting part of swing reduction gear

### 15.3 COMPONENTS TO BE INSTALLED

No.	Nomenclature	Qty
0	SWING UNIT	1
1	CAPSCREW (M24×75)	14

## 16. UPPER FRAME

Methods of dismantling and installing the upper frame vary with disassembly condition and crane capacity. Methods may be classified as below :

Upper swing body - cab = about. 14 tons (30800 lbs)

Upper swing body - (cab + counterweight)  
= about. 8 tons (17600 lbs)

However, since the attachment is left detached, prepare a crane having a capacity sufficiently safe for the above weights.

### 16.1 PREPARATION FOR DISMANTLING AND INSTALLING UPPER FRAME

- (1) Dismantling cab (Refer to Sect. 1 Cab.)
- (2) Prevention of hydraulic oil leakage (Refer to Sect. 6 Hydraulic Tank.)
  - 1) Discharge the pressure out of the hydraulic tank.
  - 2) Install the suction stopper to the hydraulic tank.
- (3) Disconnecting piping
  - 1) Disconnect the pipes to the boom, arm and bucket at the boom foot.
  - 2) Plug the hose ends and tag the hoses so they are not mixed up at reassembly operation.
  - 3) Disconnect the harness for the boom work light. Then remove the attachment and the boom cylinder.
  - 4) Disconnect the piping to the travel system at the top of the swivel joint.
  - 5) plug and tag the hoses so they are not mixed up at reassembly.
  - 6) Remove the capscrews that lock the swivel joint and take off cover (18) and dust cover (3).

### 16.2 DISMANTLING AND INSTALLING UPPER FRAME

- (1) Dismantling
    - 1) Lifting upper frame
      - With counterweight :  
Take off the engine cover and put eye bolts (M48) in the two tapped holes in the counterweight, and attach two chain hoists to the eye bolts.  
Regarding the front, put two wire slings in the lifting holes at the back of the boom foot pin holes.
      - Without counterweight :  
Take off the engine cover and leave the counterweight removed.  
Attach two chain hoists to the frame at the mount of the counterweight, using the jig shown in the figure (next page).
- Attach two chain hoists to the frame at the mount of the counterweight, using the jig shown in the figure (next page).




Fig. 60 Upper part of swivel joint




Fig. 51 Lifting method (with counterweight)




Fig. 52 Lifting method (without counterweight)




Fig. 53 Matching marks on swing bearing and upper frame

Regarding the front, attach two wire slings, utilizing the lifting holes of the frame the same way as mentioned above

2) Removing swing outer race mounting bolts.

Put a matching mark to the swing bearing and the upper frame.

3) Tension the wire slings so they do not get slack and remove capscrews (17) and reamer bolt (14)

(2) Installation

1) installation is done in the reverse order of dismantling. First of all, clean the swing bearing mounting surface at the bottom of the upper frame and the top surface of the outer race so the surfaces are free from dust, dirt and oily matter.

2) Apply Loctite #515 over the entire surface of the top face of the outer race from inside the capscrews.

3) Lifting method

Lift the upper frame level and lower it slowly, while matching the matching marks left at disassembly and confirming the meshing of the swing pinion with the internal gear on the inner circumference of the inner race of the swing bearing.

4) Installing swing bearing to upper frame

Apply Loctite #242 to reamer bolts (14) that mount the outer race of the swing bearing, and attach reamer bolts (14). After fastening it temporarily, coat capscrews (17) with Loctite #242 and temporarily fasten all of them.

5) Tighten all capscrews (17) and reamer bolts (14) back-and-forth, and right-and-left, alternately at 180° intervals, to specified torques.

φ : 80mm,

Tightening torque : 50 ± 5 kgf-m

(362 ± 36 ft-lbs)

16.3 JIG FOR LIFTING REAR OF UPPER FRAME

Insert the counterweight mounting bolts from underneath, attach eye nuts and make a lifting jig using a wire sling of about 2.5 m (9 ft) and shackles.





Fig. 54 Location of reamer bolts (※ mark)

Apply Loctite #515 over the entire surface of inner race inside capscrews.



Apply Loctite #242  
Tightening torque  
50 ± 5 kgf-m (362 ± 36 ft-lbs)

Fig. 55 Installing swing bearing to upper frame




Fig. 56 Upper frame lifting jig





# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### TRAVEL SYSTEM

#### TABLE OF CONTENTS

		<b>LC18</b>
1. CRAWLER		
1.1 Dismantling and Mounting Procedure	1	
1.2 Construction	4	
1.3 Maintenance Standard	5	
1.4 Tools and Jigs	6	
2. UPPER ROLLER		
2.1 Dismantling and Mounting Procedure	7	
2.2 Construction	8	
2.3 Disassembly and Reassembly	8	
2.4 Maintenance Standard	11	
2.5 Tools and Jigs	11	
3. LOWER ROLLER		
3.1 Dismantling and Mounting Procedure	12	
3.2 Construction	13	
3.3 Disassembly and Reassembly	13	
3.4 Maintenance Standard	16	
3.5 Tools and Jigs	17	
4. FRONT IDLER		
4.1 Dismantling and Mounting Procedure	18	
4.2 Construction	19	
4.3 Disassembly and Reassembly	19	
4.4 Maintenance Standard	21	
4.5 Tools and Jigs	22	
5. IDLER ADJUSTER		
5.1 Dismantling and Mounting Procedure	23	
5.2 Construction	23	
5.3 Disassembly and Reassembly	24	
5.4 Maintenance Standard	26	
5.5 Tools and Jigs	27	
6. SPROCKET		
6.1 Dismantling and Mounting Procedure	27	
6.2 Maintenance Standard	28	
6.3 Tools and Jigs	28	
7. TRAVEL REDUCTION GEAR		
7.1 Dismantling and Mounting Procedure	29	
7.2 Maintenance Standard	30	
7.3 Tools and Jigs	30	
8. SWIVEL JOINT		
8.1 Dismantling and Mounting Procedure	31	
8.2 Maintenance Standard	31	
9. SWING BEARING		
9.1 Dismantling and Mounting Procedure	32	
9.2 Construction	33	
9.3 Disassembly and Reassembly	33	
9.4 Maintenance Standard	34	
9.5 Tools and Jigs	34	



**KOBE STEEL, LTD.**

Applicable Machines

LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC1805E K

# 1. CRAWLER

## 1.1 DISMANTLING AND MOUNTING PROCEDURE

### (1) Dismantling

- 1) One master pin (6) is fixed in the track link of the crawler. Turn the crawler so the master pin is located ahead of the front idler.
- 2) Put square wooden blocks A and B under the shoe at the tip of the crawler and in the gap with the link above the track frame, in order to relieve the load of master pin.
- 3) Loosen the grease nipple for the track spring adjuster to let the grease in the cylinder out and slacken the tension of the crawler.

⑤ : 19mm

- ⚠ When loosening the grease nipple of the adjuster, do not loosen it more than one turn.
- Where grease does not come out well, move the machine back and forth.
- Take care as grease may jet out.




Fig. 1 Location of master pin




Fig. 2 Removing shoe





Fig. 3 Slackening the tension of crawler

4) Remove master pin (6) by knocking it with the master pin drawing jig (a).

- ⚠ Use care as the front idler may pop out of the front idler by spring action if the master pin is drawn out where the front idler parts are broken.
- If you use a big hammer, wear a long-sleeved garment and protective goggles to protect yourself from flying objects.
- Unless you knock on the master pin by attaching the shoe plate to it, it gets hard to draw out the master pin as the link is distorted.




YH-878

Fig. 4 Removing master pin

5) Remove the crawler by stretching it over the ground, while moving back the machine slowly by operating the travel lever.

- ⚠ When the master pin has been drawn out and crawler has been separated, the end of the shoe plate may fall down. Therefore, do not get your feet close to the point where the end of the shoe plate may drop.



YH-878

Fig. 5 Dismantling crawler

## (2) Mounting

1) Set the crawler so it is directed correctly to the machine body.

Namely, place the track links on the ground so they converge, facing the front idler, as shown in the figure on the right.

2) Jack up the machine body and place it in a position at which the end of the track links engage with the sprocket. Move back the machine slowly over the track links till it comes at the position of Fig. 5.

3) Move the machine forward slowly, while assisting the crawler being coiled around the sprocket by inserting a crowbar in the master pin hole, till the crawler passes the regular position and engaged with the front idler. Finally set the crawler in the position of Fig. 5 by assisting it with a crowbar.

Protect the lower frame properly so it is not damaged as the track link may get slack and scratch the lower frame.





Fig. 6 Mounting direction of crawler




YH-878

Fig. 7 Coiling crawler

4) Hook a chain block in the upper shoe plate and lower shoe plate in order to fasten the crawler. Then correctly align the master pin holes at both ends of the track link.

**⚠** Place a square wooden block (A) under the shoe plate so the end of the shoe plate does not fall and press your foot when setting the master pins.



YN 074

Fig. 8 Aligning master pin holes

5) Install the collar (7).

Put the master pin drawing jig (8) which was used when master pin was removed against the master pin and knock it in with a hammer.

**⚠** •Be careful for flying object when using a big hammer. Always use safety glasses and long sleeve shirt.


•Coat the master pin with molybdenum disulfide grease, before pressing it in.



YN 075

Fig. 9 Pressing in master pins

6) After mounting work has been completed, grease the grease nipple for the track spring adjuster and adjust the crawler tension.



YN 076

Fig. 10 Adjusting crawler tension

1.2 CONSTRUCTION




Fig. 11

No.	NAME	Q'TY	
		NOT LC	LC TYPE
1	TRACK LINK (RH)	48	51
2	TRACK LINK (LH)	48	51
3	TRACK BUSHING	46	49
4	MASTER BUSHING	2	2
5	TRACK PIN	46	49
6	MASTER PIN	2	2
7	COLLAR	4	4
8	SEAL	92	98
10	SHOE	48	51
11	BOLT	192	204
12	NUT	192	204

### 1.3 MAINTENANCE STANDARD




Fig. 12

Table 1


Unit : mm (in)

No.	ITEM	STANDARD VALUE		REFERENCE VALUE FOR REMEDY	SERVICEABILITY LIMIT	REMEDY	
A	Link pitch	293.2 ± 0.1 (8.000 ± 0.004)		207.5 (8.169)	211 (8.307)	Replace	
B	O.D. of bushing	∅66.65 <sup>+0.05</sup> <sub>0</sub> (∅2.624 <sup>+0.002</sup> <sub>0</sub> )		∅63 (∅2.480)	∅51 (∅2.008)		
C	Height of link	117.0 ± 0.2 (4.630 ± 0.008)		114 (4.488)	110 (4.331)		
D	Interference between bushing and link	Basic dimension	Tolerance		Interference		Interference
		∅66.65 (∅2.624)	Shaft	+0.05 (-0.002) 0 (0)	0.10 (0.0039)		0
E	Interference between track pin and link	∅44.50 (∅1.752)	Shaft	+0.05 (-0.002) 0 (0)	0.25 (0.0098)		0
F	Interference between master pin and link	∅44.27 (∅1.743)	Shaft	+0.03 (-0.001) 0 (0)	0.16 (0.0063)		0
G	Clearance between links (both sides)	1.2 (0.047)		4 (0.157)	6 (0.236)		
H	Tightening torque of shoe bolt	95 ± 9.5 kgf·m (587 ± 60 ft·lbs)				Retighten	

1.4 TOOLS AND JIGS


(1) Tightening tool

Unit : mm

NAME	WIDTH ACROSS FLATS
 Socket	19, 30

(2) Jig

Unit : mm (in)

No.	NAME	SHAPE
a	Master pin drawing rod	




## 2. UPPER ROLLER

### 2.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

- 1) Stretch the crawler by referring to "1.Crawler 1.1 Dismantling and Mounting Procedure".



YN-074

Fig. 14 Stretching crawler

- 2) Remove cap screws (2) that fasten the upper roller and separate upper roller ass'y (1) from the bracket.

② : 30mm.

Weight of upper roller : 18.5kg (40.7 lbs)

#### (2) Mounting

- ⚠** Before mounting the upper roller, make sure that sufficient oil is filled in and that the upper roller rotates smoothly by hand. If the oil volume is insufficient, the upper roller does not rotate smoothly or oil is leaking. refill oil or check the O ring and the floating seals and replace them where necessary  
Oil : Engine oil API CD grade #30 (SHELL RIMURA CT#30)  
Volume : 50cc (3cu.in)

- 1) Insert the shaft of the upper roller ass'y into the bracket, matching the spring pin on the collar of the upper roller with pin hole of the bracket.
- 2) Coat mounting cap screws (2) with Loctite #242 and attach them.  
② : 30mm,  
Tightening torque :  $55 \pm 5.5 \text{ kgf.cm}$   
( $400 \pm 40 \text{ ft.lbs}$ )
- 3) Install the crawler by referring to "1.Crawler 1.1 Dismantling and Mounting Procedure".




Fig. 15 Upper roller ass'y

## 2.2 CONSTRUCTION

No.	NAME	Q'TY
1	ROLLER	1
2	SHAFT	1
3	COLLAR	1
4	PLATE	1
5	COVER	1
6	BUSHING	2
7	FLOATING SEAL	1
8	O RING	1
9	CAPSCREW M10×20	2
10	PLUG PT1/4	1
11	O RING	1
12	SPRING PIN	1
13	SNAP RING	1




Fig. 16 Construction of upper roller

## 2.3 DISASSEMBLY AND REASSEMBLY

### (1) Disassembly

- 1) Remove plug (10) and drain out oil.  
 : 6mm
- 2) Mount the end face inside upper roller (1) on stand jig (f) and separate snap ring (13), using snap ring pliers.
- 3) Take off cover (5) using a spanner. (width across flat = 36mm)
- 4) Separate O ring (8) from cover (5).
- 5) Loosen two cap screws (9) and draw out plate (4) from upper roller (1).  
 : 8mm
- 6) Put the extrusion jig (h) against the end face of shaft (2) and lightly extrude shaft (2) with collar (3) for floating seal (7), using a press or hammer
- 7) Take out floating seal (7) from upper roller (1).




Fig. 17 Preparation for disassembly




Fig. 18 Extruding shaft

- 8) Take out, from collar (3), floating seal (7) that is located on the side from which shaft (2) was disassembled.
- 9) Remove collar (3) and O ring (11).
- 10) Take out spring pin (13) from collar (3) using a pliers.
- 11) When extruding bushing (6), mount upper roller (1) on the stand jig (f) with its floating seal inserting side up, put the extrusion jig (g) against the end face of bushing (6) and extrude it by means of a press.




Fig. 19 Taking out floating seal, collar and O ring

(2) Reassembly

Reassembly of the upper roller is performed in the reverse order of disassembly.

- 1) Mount upper roller (1) on the top end face of the stand jig (f) with the floating seal inserting side down
- 2) Make sure that the outer circumference of bushing (6) is not galled and coat the inserting area of the bushing with molybdenum disulfide grease.
- 3) Insert the jig (i) into bushing (6) and press in the bushing with the bore of the bushing and the bore of the roller as a guide.  
As bushing (6) divides into two, repeat the same work as above.




Fig. 20 Extruding bushing

**⚠** If you fail in this operation by pressing the bushing unevenly, the bushing is distorted and gets unserviceable. In that case, do not re-use the bushing as it may develop malfunctioning after assembly.




Fig. 21 Pushing in bushing

- 4) Install spring pin (13) to collar (3).
- 5) Install collar (3) and O ring (11) with thinly grease coated to shaft (2).
- 6) Two floating seals (7) make a pair. Attach one floating seal to collar (3) fixed in shaft (2), and another to the inside of upper roller (1).




Fig. 22 Fixing spring pin, collar, O ring




Fig. 23 Fixing floating seal

- 7) Coat shaft (2) with a thin film of oil and insert it into upper roller (1).





Fig. 24 Inserting shaft

- 8) Mount upper roller (1) on the stand jig (6) and attach plate (4) to the end face of the shaft with capscrews (9). In that case, coat the screwed part of capscrews (9) with Locktite #242 beforehand.

 : 3mm,

Tightening torque :  $5.7 \pm 0.7 \text{ kgf}\cdot\text{m}$   
(48.5 = 5ft.lbs)

- 9) Coat O ring (8) with grease and fix it in the groove of cover (5).
- 10) Tighten cover (5) to upper roller (1), using spanner.
- 11) Fix snap ring (13) into upper roller (1), using snap ring pliers.






Fig. 25 Installing cover

- 12) Fill in 50cc (3cu.in) of engine oil API grade CD#30 (SHELL RIMURA GT#30) through the plug hole in the center of cover (5).

- 13) Place seal tape around plug (10) and screw it into the plug hole of cover (5).

 : 6mm,

Tightening torque : 2.2~2.5kgf·m  
(16~18ft.lbs)

-  After assembling the upper roller, confirm that oil is not leaking from it and that it rotates smoothly by hand.




Fig. 26 Filling oil

## 2.4 MAINTENANCE STANDARD




Fig. 27 Cross-sectional view of upper roller

Table 2

Unit : mm (in)

No.	ITEM	STANDARD VALUE		REFERENCE VALUE FOR REMEDY	SERVICEABILITY LIMIT	REMEDY	
A	O.D.	±140 (±5.51)		—	—	Padding weld, repair or replace.	
B	Width	205 (8.071)		—	—		
C	Tread dia.	±120 (±4.72)		±110 (4.33)	±108 (4.25)		
D	Flange width	27.5 (1.083)		—	13 (0.700)		
E	Clearance between shaft and bushing	Basic dimension	Tolerance		Fit	Fit	Replace bushing.
		±60 (±2.362)	Shaft	-0.025 -0.050 (-0.00098) -0.002	Clearance 0.7 (0.028)	Clearance 1.0 (0.04)	
F	Interference between roller and bushing	±65 (±2.559)	Hole	+0.030 0 (+0.00118) 0	Interference 0	Clearance 0.01 (0.0004)	
G	Tightening torque of cap screw	6.7 ± 0.7 kgf·m (48.5 = 5ft·lbs)					Apply Locktite #242
	Oil	Engine oil API grade CD #30 (SHELL RIMURA CT #30), 50cc (3.1cu in)					Replenish.
	Roller rotation	Roller rotates smoothly by hand.					Reassembly.

## 2.5 TOOLS AND JIGS

### (1) Tightening tools

Unit : mm (in)

NAME	WIDTH ACROSS FLATS
Socket	30
Allen key wrench	6, 8
Spanner	36

### (2) Jig

Unit : mm (in)

No.	NAME	SHAPE
f	Stand jig	


No.	NAME	SHAPE
g	For extruding bushing	
h	For extruding shaft	
i	Bushing fixing jig	

### 3. LOWER ROLLER


#### 3.1 DISMANTLING AND MOUNTING PROCEDURE

##### (1) Dismantling

- 1) Slightly loosen capscrews (3), (4) fasten lower roller ass'y (1) and track guide (2) with the track frame.


 : capscrews (3): 32mm  
 capscrews (4): 36mm

- 2) Loosen the grease nipple of the crawler adjuster and slacken the crawler tension.

 : 19mm

- 3) Lift the track frame to an extent that the lower roller can be taken out, using the front attachment.


- 4) After lifting the track frame to flat firm roadbed, place square wooden blocks under the lower frame to stabilize the machine body.

 Always place square wooden blocks so they support the front and back lower frames, in order to stabilize the machine body. Lower the front attachment down to the ground, stop the engine and proceed to work.

- 5) Remove the capscrews fastening the lower roller and the track guide and pull out the lower roller and the track guide.

Weight of lower roller ass'y : 60.4kg (133 lbs)


Weight of track guide : 25kg (55 lbs)

 : 32, 36mm

##### (2) Mounting

- 1) Coat the mounting capscrews with Locktite #242 beforehand. Match the capscrews to the bolt holes and fasten them temporarily.

- 2) Bring the machine in full contact with the ground and fasten the capscrews.


 : 32, 36mm,

Tightening torque :

capscrews (3) :  $74.5 \pm 7.5 \text{ kgf}\cdot\text{m}$  ( $539 \pm 54 \text{ ft}\cdot\text{lbs}$ )

capscrews (4) :  $95 \pm 9.5 \text{ kgf}\cdot\text{m}$  ( $687 \pm 69 \text{ ft}\cdot\text{lbs}$ )

- 3) Fasten the grease nipple of the crawler adjuster, fill in grease and adjust the crawler tension.

 : 19mm,

Tightening torque  $6 \pm 1 \text{ kgf}\cdot\text{m}$

$43 \pm 7 \text{ ft}\cdot\text{lbs}$




Fig. 28 Lower roller ass'y and track guide




Fig. 29 Preparation for dismantling and mounting




Fig. 30 Supporting track frame





Fig. 31 Dismantling and mounting lower roller ass'y

7K-674

### 3.2 CONSTRUCTION



No.	NAME	Q'TY	No.	NAME	Q'TY
1	ROLLER	1	7	O RING	2
2	SHAFT	1	8	PLUG	2
3	BUSHING	2	9	LOCK RING	4
4	COLLAR	1	11	FLOATING SEAL	2 Set
5	COLLAR	1			

Fig. 32 Construction of lower roller ass'y

### 3.3 DISASSEMBLY AND REASSEMBLY

#### (1) Disassembly

- 1) Remove the plug (8), and drain out the oil.
- 2) Insert the lock ring puller jig (E) into the collar mounting cap screw hole in the collars (4, 5), rotate the collar by tapping the jig with a mallet, and drive out the lock ring (9) using a chisel and mallet.




Fig 33 Drawing out lock ring

- 3) Mount the lower roller so shaft (2) stands perpendicular to the top end face of the stand jig (m). Put the extrusion jig (p) against the shaft end and extrude the shaft with a press or a mallet.

**⚠** The shaft (2) extrusion operation may cause the remaining lube oil to flow out and contaminate the working floor. Prepare an oil container beforehand.

- 4) Take out floating seal (11) from collar (4), (5).

- 5) Take out floating seal (11) from roller (1).

- 6) Mount roller (1) on the stand jig (m), put the tip of the extrusion jig (n) against the end face of bushing (3).

**⚠** Hammer the inside surface of roller lightly so as not to damage the surface. Put the extrusion jig (n) fractionally over the circumference of bushing (3) and extrude it little by little.

Push with a press or mallet.




Fig. 34 Taking out shaft




Fig. 35 Taking out floating seal




Fig. 36 Taking out floating seal




Fig. 37 Extruding bushing



7) Separate O ring (7) from shaft (2).

(2) Assembly

1) Coat O ring with grease and fit it in the shaft groove.

**⚠** At reassembly, always use a new O ring.

2) Make sure that the outer circumference of bushing (3) is not galled and put the jig (q) into bushing (3).

3) Press bushing (3) vertically into roller, using the bore of the bushing and the bore of the roller as a guide.

**⚠** Coat the fitting part of the bushing with molybdenum disulfide grease.

• If you have failed the above-mentioned operation by uneven pressing or something, do not use the failed bushing again.

4) Insert the shaft (2) into the roller (1) using the press or hammer.




Fig. 38 Taking out O ring




Fig. 39 Pressing in bushing

5) Install the floating seal (11) in the roller (1)

6) Install the floating seal (11) in the collars (4, 5)

7) Install the collar (4, 5) on the shaft (2).




Fig. 40 Inserting shaft




Fig. 41 Inserting floating seals and collars

- 8) Drive the lock ring (9) onto the collars (4,5).
- 9) Remove the plug (8), and add 250 cc (15.3 cu-in) of engine oil #30, grade CD, API classification (SHELL RIMURA CT#30). After filling, wind sealing tape around the plug (8), and tighten the plug with a hex key.

⚡ : 6mm,  
Tightening torque 2.2~2.5kgf·m  
(16~18ft·lbs)

- ⚠ After assembling the lower roller, confirm that oil is not leaking and that the roller rotates smoothly by hand.




Fig. 42 Installing lock ring

### 3.4 MAINTENANCE STANDARD




Fig. 43 Lower roller

Table 3



Unit : mm (in)

No	ITEM	STANDARD VALUE		REFERENCE VALUE FOR REMEDY	SERVICEABILITY LIMIT	REMEDY	
A	O.D. of flange	ø220 (ø8.661)		—	—	Pudding weld, repair or replace.	
B	Tread dia.	ø185 (ø7.283)		ø175 (ø6.890)	ø170 (ø6.693)		
C	Flange width	24 (0.945)		18 (0.709)	16.5 (0.650)		
D	Clearance between shaft and bushing (coiled bushing)	Basic dimension	Tolerance		Fit	Fit	Replace bushing
		ø75 (ø2.953)	Shaft	-0.03 -0.06 (-0.0012) (-0.0024)	Clearance 0.7 (0.0276)	Clearance 1.0 (0.04)	
E	Interference between the bore of roller and bushing	ø83 (ø3.268)	Hole	-0.035 0 (+0.0014) 0	Interference 0	Clearance 0.01 (0.0004)	
F	Oil	Engine oil API grade CD #30 (SHELL RIMURA CT #30), 250cc (15.3cu-in)				Replenish	
	Roller rotation	Rotates smoothly by hand				Reassemble	

### 3.5 TOOLS AND JIGS






#### (1) Tightening tools

Unit: mm

NAME	WIDTH ACROSS FLATS
 SOCKET	19, 32, 36
 ALLEN KEY WRENCH	6

#### (2) Jigs

Unit: mm (in)

No.	NAME	SKETCH
e	Lock ring drawing jig	
n	Bushing extrusion rod	
m	Stand jig	
p	Shaft extrusion jig	
q	Bushing fixing jig	

## 4. FRONT IDLER

### 4.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

1) Dismantle the crawler ass'y.

2) Take out idler (1) forward idler adjuster ass'y (2) from the track frame, using a crowbar or by placing a wire sling in it

3) Loosen capscrews (4) and separate idler ass'y (1) idler adjuster ass'y (2).

④ : 36mm

Idler : 171.5kg (377 lbs)

+ Adjuster : 173kg (381 lbs)

Front Idler Adjuster : 344.5kg (758 lbs)

**⚠** The separated idler ass'y (1) is easy to fall down : Lay it down so it will not fall down on your feet, utilizing square wooden blocks.

#### (2) Mounting

1) Attach idler ass'y (1) to the top of idler adjuster ass'y (2) by means of capscrews (4) in the reverse order of dismantling the idler ass'y. In that case, coat the screwed part of capscrews (4) with Locktite #242 beforehand.

④ : 36mm,

Tightening torque : 95kgf·m  
(687ft·lbs)

2) Fit the idler to the track frame so the grease nipple (3) comes outside of it.

③ : 10mm,

Tightening torque : 6±1kgf·m  
(43±7ft·lbs)

In that case, make sure that the tip of the idler adjuster ass'y is correctly set in the support of the track frame.

3) Fit the crawler ass'y, adjust the crawler tension, according to the mounting procedure of the crawler.

On that occasion, make certain that lubrication through the grease nipple is normal and that grease is not leaking from the grease cylinder.




Fig. 44 Dismantling front idler ass'y




Fig. 45 Removing idler ass'y




Fig. 46 Storing idler ass'y




Fig. 47 Fitting idler ass'y




Fig. 48 Attaching idler adjuster ass'y

## 4.2 CONSTRUCTION

No.	NAME	Q'TY	No.	NAME	Q'TY
1	IDLER	1	5	SHAFT	1
2	BUSHING	2	6	PIN	2
3	FLOATING SEAL	2	7	O RING	2
4	SLIDE BLOCK	2	8	PLUG	1




Fig. 49 Construction of idler ass'y

## 4.3 DISASSEMBLY AND REASSEMBLY

### (1) Disassembly

- 1) Remove plug (8) located on one side of slide block (4) and discharge oil.

↖ : 5mm

- 2) Place the pin drawing jig (R) on the top of pin (6) and draw it out, tapping it with a hammer.
- 3) Mount idler (1) on stand (U), place the shaft extrusion jig (S) against shaft (5) extrude it by press.




Fig. 50 Drawing out pin

- 4) With idler (1) mounted on the stand, tap bushing (2) lightly by hammer, while placing the bushing drawing rod (T) against the end face of bushing (2) evenly all round, till it comes out.

- 5) Take out floating seals (3) from slide block (4). If you intend to re-use floating seals (3), confirm that there is no scoring and rusting on the contact surface and store the floating seals in pairs by placing thick paper between the sealing faces.

- 6) Separate O ring (7) from shaft (5).




Fig. 51 Extruding shaft




Fig. 52 Removing bushing

(2) Assembly

- 1) Press bushing (2) into the embossed hole in the center of idler (1), using the bushing fixing jig (V).




Fig. 53 Pressing in bushing

- 2) Fit grease-coated O ring (7) to the O ring groove of shaft (5).

- 3) Match the pin (6) hole in shaft (5) with the pin hole in slide block. Press shaft (5) into slide block (4) from the O ring (7) inserted side.




Fig. 54 Pressing in shaft

- 4) Knock in pin (6).

- 5) Fix a pair of floating seals (3) to one side of slide block (4) and idler (1).




Fig. 55 Inserting idler

- 6) Coat shaft (5) with a thin film of oil and insert idler (1) in place.

- 7) Fix a pair of floating seals (3) to idler (1) and other slide block (4).




Fig. 56 Pressing in slide block

- 8) Attach O ring (7) to the O ring groove of shaft (5)

- 9) Match the pin (6) hole in shaft (5) with the pin hole in slide block (4). Then press slide block (4) into shaft (5), using the collar fixing jig (W).

- 10) Knock in pin (6), using a hammer.

- 11) Fill in 300cc (18.8cu-in) of engine oil API grade CD #30 (SHELL RIMURA CT #30) through the plug hole of slide block, place the screwed part of plug (8) with seal tape and put in plug (8).

◀ : 5mm

⚠ After mounting the idler ass'y to the idler adjuster ass'y, make certain that no oil leaks from floating seal (3) and plug (8) and that idler (1) rotates smoothly.




Fig. 57 Knocking in pin

4.4 MAINTENANCE STANDARD




Fig. 58 Front idler

Table 1




Unit : mm (in)

No.	ITEM	STANDARD VALUE		REFERENCE VALUE FOR REMEDY	SERVICEABILITY LIMIT	REMEDY	
A	Dia. of idler projection	∅640 (∅25.197)		—	—	Padding weld, repair or replace.	
B	Tread dia.	∅595 ± 1.5 (∅23.425 ± 0.059)		∅585 (∅23.150)	∅585 (∅23.031)		
C	Flange width	102 ± 0.8 (4.016 ± 0.031)		96 (3.780)	94 (3.701)		
D	Clearance between shaft and bushing	Basic dimension	Tolerance		Fit	Fit	Replace bushing.
		∅80 (∅3.150)	Shaft	- 0.030 - 0.060 (- 0.0012) (- 0.0034)	Clearance 1.0 (0.039)	Clearance 1.5 (0.059)	
E	Interference between roller and bushing	∅90 (∅3.543)	Bore	0.035 0 (0.0014) 0	Interference 0	Clearance 0.01 (0.0004)	
	Oil	Engine oil API grade CD#30 (SHELL RIMURA CT#30), 300cc (18.3cu.in)				Replenish	
	Idler rotation	Rotates smoothly by hand.				Reassemble	

#### 4.5 TOOLS AND JIGS





##### (1) Tightening tools



Unit : mm

NAME	WIDTH ACROSS FLATS
 SOCKET	36
 SPANNER	19
 ALLEN KEY WRENCH	5

##### (2) Jigs

Unit : mm (in)

No.	NAME	SKETCH
R	Pin drawing jig	
S	Shaft drawing jig	
T	Bushing drawing rod	
U	Stand	

No.	NAME	SKETCH
V	Bushing fixing jig	
W	Slide block fixing jig	



## 5. IDLER ADJUSTER

### 5.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

- 1) Idler adjuster ass'y (2) is drawn out of the crawler frame, integrated with idler ass'y (1). Do this job by referring to "4.1.(1)" Dismantling front idler.

- 2) Loosen capscrews (4) and separate idler ass'y (1) from idler adjuster ass'y (2).

Weight of idler adjuster ass'y : 173kg (381 lbs)

(1) + (2) = 344.5kg (758 lbs)

④ : 36mm

#### (2) Mounting

- 1) Mounting is done in the reverse order of dismantling :

First of all, mount idler ass'y (1) to idler adjuster ass'y (2) and fasten them together with capscrews (4).

④ : 36mm,

Tightening torque : 95kgf-m  
(687ft-lbs)

- 2) Before mounting the idler adjuster to the track frame, assemble it with the idler ass'y. For the procedure, refer to "4.1.(2)" Mounting Front Idler.

Apply locktite #242.  
TIGHTENING TORQUE  
30kgf-m (282ft-lbs)




Fig. 58 Crawler/idler ass'y

### 5.2 CONSTRUCTION

No.	NAME	Q'TY
1	GREASE CYLINDER	1
2	BRACKET	1
3	NUT M56×P3	1
4	SPRING PIN	1
5	SPRING	1
6	CAPSCREW	2
7	GREASE NIPPLE	1
8	PISTON	1
9	OIL SEAL	1
10	O RING	1
11	PIN	2





Fig. 60 Idler adjuster ass'y

### 5.3 DISASSEMBLY AND REASSEMBLY

#### (1) Disassembling Idler Adjuster Ass'y

- 1) Before disassembling and reassembling the idler adjuster ass'y, prepare spring setting jig (V).


Capacity of hydraulic jack ; more than 20 tons (44000 lbs)

 : 46mm

- ⚠ Large power is needed to set the spring. Prepare a special jig before disassembly and reassembly.

- 2) Place a hydraulic jack between the jig base and the stand.

- 3) Loosen the holding-down nuts of the jig and draw out the retainer plate upward.


 : 46mm

- 4) Draw out piston (8) from grease cylinder (1) of the idler adjuster ass'y.

- 5) Taken out oil seal (9) and O ring (10) from grease cylinder (1).

- 6) Set the idler adjuster ass'y thus disparted on the stand of the jig (V), with its bracket side (2) facing up.

- 7) Put the retainer plate over bracket (2) and confirm that the center hole is aligned with the center of nuts (3). Fasten the holding-down nuts by turns and fix the idler adjuster ass'y.

 : 46mm

- 8) Compress spring (5) till nuts (3) at the tip of grease cylinder (1) can be turned freely by a hydraulic jack. Then take off spring pin (4) and nuts (3).

 : 46mm




Fig. 61 Disassembly/assembly jig V




Fig. 62 Lifting idler adjuster in place




Fig. 63 Mounting retainer plate





Fig. 64 Compressing spring by hydraulic jack

- 9) Allow the hydraulic jack to shrink slowly till the spring is extended to its free length. Remove the retainer plate and take off bracket (2). Measure the free length of the spring and check it with the value given in the maintenance standard. About 627.3mm (24.7in)

 : 46mm

- 10) Attach lifting nut (W) to the screw M56 at the tip of grease cylinder (1), place a wire sling to it and lift it by crane. Remove grease cylinder (1) and spring (5) in pairs.


- 11) Draw out grease cylinder (1) from spring (5).

(2) Reassembly

Reassembly is done in the reverse order of disassembly


- 1) Insert grease cylinder (1) into spring (5) and attach lifting nut (w) to screw M56 at the tip of the grease cylinder. Lift the grease cylinder by crane and erect it in the center of the jig stand upright.


- 2) Install bracket (2) on top of spring (5). Center the rod of grease cylinder (1) and the holes in bracket (2). Attach the retainer plate and four holding-down nuts. Fasten the nuts evenly all round and fix the idler adjuster ass'y to the jig body.


 : 46mm

- 3) Extend the hydraulic jack, compress spring (5) to a set length and screw in nut (3) to the screwed part at the tip of grease cylinder (1). Set length : 852.5mm (33.563")

- 4) Screw in nut (3) till the holes for locking spring pins (4) are aligned. Then fit spring pin (4).


 : 46mm

 : 85mm



YK-874

Fig. 65 Removing retainer plate



YK-874

Fig. 66 Removing and attaching idler adjuster ass'y




Fig. 67 Attaching idler adjuster ass'y to jig body

- 5) Take out the idler adjuster ass'y from the jig.
- 6) Attach oil seal (9) and O ring (10) coated with grease, to grease cylinder (1).
- 7) Fill up grease in grease cylinder (1), separate the grease nipple from piston (7) and discharge the entrapped air through the grease nipple mounting hole, while pushing in the piston (8) by hand. In that case, the entrapped air is easy to escape if the piston is pushed in with the grease nipple hole facing down.
- 8) Screw in a grease nipple into piston (6)
  - ① : 19mm,
  - Tightening torque :  $6 \pm 1 \text{ kgf}\cdot\text{m}$   
( $43 \pm 7 \text{ ft}\cdot\text{lbs}$ )




Fig. 68 Taking out idler adjuster ass'y

W1072

#### 5.4 MAINTENANCE STANDARD

Table 5

No.	ITEM	STANDARD VALUE
A	Installed length of spring mm	527.5 (20.8")
B	Free length of spring mm	About 627.3 (24.7")
C	Stroke mm	64 (2.520")
D	Set length mm	802.5 (31.569")
E	Outer circumference of piston	Not scoring and rusting
F	Tightening torque of grease nipple	$6 \pm 1 \text{ kgf}\cdot\text{m}$ ( $43 \pm 7 \text{ ft}\cdot\text{lbs}$ )






Fig. 69 Idler adjuster



## 5.5 TOOLS AND JIGS

### (1) Tightening Tools

Unit : mm

NAME	WIDTH ACROSS FLATS
 SPANNER	46, 85
 SOCKET	19, 36

### (2) Jigs

No.	NAME	SKETCH	No.	NAME	SKETCH
V	Spring setting jig		W	Lifting nut	


## 6. SPROCKET

### 6.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling


- 1) Remove the crawler ass'y
- 2) Place square wooden blocks under the track frame so the sprocket is off the ground.
- 3) Loosen 26 capscrews (C) (M20) for the mounting of the sprocket by means of a socket and dismantle the sprocket.

Single weight of sprocket : 82kg (180 lbs)

 : 30mm

#### (2) Mounting

- 1) Check the jointing parts of the travel reduction gear and the sprocket, eliminate burrs and contamination thoroughly and install the sprocket.
- 2) Coat the sprocket mounting capscrews with Loctite #242 and fasten the sprocket temporarily.
- 3) Remove the square wooden blocks placed under the track frame and tighten the sprocket against the travel reduction gear with the capscrews.

 : 30mm,

Tightening torque : 55 J.6.5kgf-m  
(397 ± 40ft. lbs)




Fig. 70 Lifting the sprocket




Fig. 71 Separating sprocket




Fig. 72 Tightening capscrews

6.2 MAINTENANCE STANDARD

Table 6

SPECIFICATIONS	LINK PITCH	203.2mm (8 in)	NUMBER OF TEETH	23
	ROLLER DIA.	∅66.6 (2.622 in)	PITCH DIA.	∅753.16 (29.652 in)




Fig. 73

Table 7

Unit : mm (in)

No.	NAME	STANDARD VALUE	REFERENCE VALUE FOR REMEDY	SERVICEABILITY LIMIT	REMEDY
A	O.D. of sprocket	∅775.4 (30.512 <sup>+0.050</sup> <sub>-0.127</sub> )	∅767 (30.197)	∅765 (30.118)	Padding weld, repair or replace.
B	Width of sprocket teeth	88.15 <sup>+0.050</sup> <sub>-0.127</sub> (3.469)	82 (3.229)	80 (3.150)	Replace.
C	Dia. of sprocket tooth bottom	∅684.7 <sup>+0.050</sup> <sub>-0.127</sub> (26.957)	∅677 (26.658)	∅675 (26.575)	Padding weld, repair or replace.

6.3 TOOLS AND JIGS

(1) Tightening Tools

Unit : mm

NAME	WIDTH ACROSS FLATS
SOCKET	30

(2) Jigs

Table 8

No.	NAME	SKETCH
W	Tooth profile gauge	

## 7. TRAVEL REDUCTION GEAR

### 7.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

- 1) Dismantle the crawler ass'y.
- 2) Place square wooden blocks under the track frame and float the sprocket off the crawler.
- 3) Loosen the capscrews that mount the cover inside the track frame and take off the cover.

① : 19mm

- 4) Vent air out of the hydraulic oil tank beforehand, place the suction stopper, disconnect the hydraulic piping connected with the travel motor from the joints and plug the tubes and joints in order to prevent outflow of oil and intrusion of dust and other foreign matter.

② : 19mm - Ø10 pipe dia  
 27, 32mm - Ø18 pipe dia  
 41mm - Ø26 pipe dia

- 5) Loosen 18 capscrews that fasten the track frame to the travel reduction gear. On that occasion, put a matching mark between the track frame and the travel reduction gear.

③ : 36mm

- 6) Place a wire sling in an area near the sprocket of the travel reduction gear and extrude the unit out of the track frame.

Weight of travel reduction gear :  
 320kg (704 lbs) (with brake valve)  
 402kg (884 lbs) (with sprocket)

④ : 36mm

#### (2) Mounting

- 1) If there are burrs and contamination in the fitting part and the joints with which the travel reduction gear are fastened, service it beforehand, place a wire sling in the travel reduction gear the same way as in the dismantling, and install it to the track frame.
- 2) Coat the threaded part of the mounting capscrews with Locktite #242 and tighten them.

⑤ : 36mm,

Tightening torque :  $95 \pm 9.5 \text{ kgf}\cdot\text{m}$   
 (687 ± 690 lbf·ft)




Fig. 74 Lifting sprocket




Fig. 75 Removing cover




Fig. 76 Removing piping and capscrews




Fig. 77 Dismantling and mounting travel reduction gear





Fig. 78 Tightening capscrews

1/11/14

3) Reconnect the hydraulic piping separated during dismantling, tighten the joints to a specified torque and install the cover to the inside of the crawler frame, using capscrews.

No.	SCREW SIZE	TIGHTENING TORQUE kgf·m (ft·lbs)	
1	PF 1	25.0 ± 1.0 (180 ± 7)	41mm, Ø28
2	PF 1/2	11.0 ± 1.0 (80 ± 7)	32mm, Ø18
3	PF 1/4	3.7 ± 0.2 (27 ± 1)	19mm, Ø10

4) Remove the square wooden blocks supporting the track frame and install the crawler.

5) Check the engine oil level in the reduction gear and replace or replenish oil as required.  
Capacity of engine oil: 8.5 ℓ (2.25gal)  
Kind of oil: Extreme-pressure gear oil #90 grade GL-4 by API classification

 : 6mm, 14mm

6) Checking oil level in travel reduction gear  
a) Stop the machine so the drain plug comes right under the machine.  
b) Remove the level plug and check the oil level and fouling. The oil level is proper if it is at the tip of the plug. Replenish oil when deficient.




Fig. 79 Attaching hydraulic pipe joints




Fig. 80 Checking oil level

## 7.2 MAINTENANCE STANDARD




Table 9

	ITEM	STANDARD VALUE
Tightening torque	Travel reduction gear mounting bolt	Apply Loctite #242. 95 ± 9.5kgf·m (687 ± 69ft·lbs)
Oil	Kind	Extreme-pressure gear oil #90 grade GL-4 by API classification
	Capacity	8.5ℓ (2.25gal)

## 7.3 TOOLS AND JIGS

(1) Tightening tools

Unit: mm

NAME	WIDTH ACROSS FLATS
 SPANNER	19,27,32,41
 SOCKET	36
 ALLEN KEY WRENCH	6,14

Apply loctite #242 equivalent  
TIGHTENING TORQUE 95 ± 9.5kgf·m (687 ± 69ft·lbs)




Fig. 81 Installing travel reduction gear



## 8. SWIVEL JOINT

### 8.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

- 1) When disconnecting pipings, stop the engine, vent air from the hydraulic pipings and install the suction stopper.
- 2) Separate all the hydraulic pipes connected with the swivel joint. In that case, attach a tag to each pipe showing to what port it should be connected.
 

🔧 : 19mm	∅10 pipe dia
🔧 : 27mm, 32mm	∅18 pipe dia.
🔧 : 41mm	∅28 pipe dia.
- 3) Put a plug to each of the connecting ports and pipes.
- 4) Loosen locknut (29) and remove capscrews (20)
 

🔧 : 24mm	
----------	--
- 5) Loosen swivel joint fastening capscrews (21) and take out the washers (27).
 

🔧 : 19mm	
----------	--
- 6) Attach eye bolts to the swivel joints, place a wire sling in the eye joints. lift it by crane and lower it.

#### (2) Mounting

- 1) Mounting is performed in the reverse order of dismantling. Lift the swivel joint so the swivel joint mounting bracket comes in contact with the bottom surface in the center of the lower frame and match the mounting holes.
- 2) Coat the threads of the capscrews (21) with Locktite #242 and tighten them up.
 

🔧 : 19mm,	
Tightening torque : $11 \pm 1 \text{ kgf-m}$	
	$(80 \pm 7 \text{ ft-lbs})$

### 8.2 MAINTENANCE STANDARD

Table 10

No.	SCREW SIZE	TIGHTENING TORQUE kgf-m (ft-lbs)
1	PF1	$25.0^{+3}$ ( $160^{+4}$ )
2	PF1/4	$3.7 \pm 0.2$ ( $27 \pm 1$ )
3	PF1/2	$11.0 \pm 1.0$ ( $80 \pm 7$ )




Fig. 82 Swivel joint




Fig. 83 Hydraulic piping for swivel joint

## 9. SWING BEARING

### 9.1 DISMANTLING AND MOUNTING PROCEDURE

#### (1) Dismantling

- 1) With the upper frame removed, loosen capscrews (15) that fix the inner race of swing bearing (5) to the stand of the lower frame, and take off all of them.

⑤ : 36mm

- 2) Let out the grease in the swing bearing inner race.
- 3) Attach T-bolts to swing bearing (5), lift it by crane, separate it from the lower frame and lift it down.

Weight of swing bearing : 570kg (1,257 lbs)




Fig. 84 Swing bearing




Fig. 85 Lifting swing bearing

YH-E74


#### (2) Mounting

- 1) Before mounting the swing bearing, clean thoroughly the swing bearing and the matching surface of the swing bearing base on the lower frame to be free from dirt, oil and other foreign substance.
- 2) Lift the swing bearing onto the base so the S mark stamped on the inner race of the swing bearing is located on the left hand side (See the figure on the right.) of the lower frame.
- 3) Coat the threads of the capscrews with Loctite #242 and screw in all the capscrews (36 pcs) to an extent that they are fastened temporarily.
- 4) Fasten the capscrews at 150° intervals alternately and tighten them up to a specified torque

⑤ : 36mm,

Tightening torque : 95 = 9.5kgf·m  
(687 ± 69N·lbs)

- 5) Before installing the upper frame, mount the swing bearing to the base of the lower frame according to the mounting procedure of the swing bearing.
- 6) Fill in 14kg (31 lbs) of SHELL RETINAX AM grease equivalent into the grease bath.



SECTION A-A




Fig. 86 Location of S mark on swing bearing

## 9.2 CONSTRUCTION

No.	NAME	Q'TY	No.	NAME	Q'TY
1	OUTER RACE	1	7	SEAL	1
2	INNER RACE	1	8	GREASE NIPPLE	1
3	BALL	64	9	PLUG	1
4	RETAINER	64	10	TAPER PIN	7
5	SEAL	1	11	O RING	1
6	SEAL	1			

## 9.3 DISASSEMBLY AND REASSEMBLY

### (1) Disassembly

- 1) Take out seal (5) fitted in the groove of inner race (2) and seal (6) fitted in the groove of outer race (1) and place them level on a square wooden block or something.
- 2) Draw out taper pin (10), using a hammer and an extrusion rod.
- 3) Draw out plug (9), utilizing an pull bolt inserted in the screwed hole (M6) of the plug and using a puller.
- 4) After drawing out plug (9) while rotating outer race (1) little by little, take out ball (3) and retainer (4) from the hole in sequence.
- 5) Separate outer race (1) from inner race (2), using a crane.
- 6) Remove seal (7) from outer race (1).

### (2) Reassembly

- 1) Install seal (7) to outer race (1).
- 2) Degrease thoroughly the groove for seal (5) located in the inner circumference of outer race (1) and the groove for seal (6) located in the outer circumference of inner race (2). Coat the grooves with adhesive Cyano Bond PO 1, fit seal (6), and place inner race (2) on a surface plate.
- 3) Lift and lower outer race (1) slowly till the top surface of inner race (2) matches the bottom of the sealing groove of outer race (1). Place an adjusting washer under outer race (1) so the track surface of ball (3) is aligned, in order to support the outer race.
- 4) Insert, through the hole for plug (9) in outer race (1), ball (3) and retainer (4) coated with grease (Shell Albenia EP#2) alternately.

- ⚠** When inserting ball (3) retainer (4), the raceways must be aligned completely. To achieve it, outer race (1) should be adjusted. It is very dangerous to put your finger into the plug hole directly; always use a push rod or a hooked rod.




Fig. 87 Cross-sectional view of swing bearing




Fig. 88 Disassembling swing bearing




Fig. 89 Removing balls and retainers




Fig. 90 Fitting balls

- 4) Push in outer race (1) and plug (9), confirming the orientation and the position of the hole for taper pin (10).
- 5) Knock in taper pin (10) and caulk the head of the taper pin with a punch.
- 6) Coat seal (5) with adhesive Cyano Bond PO-1 and fit it into outer race (1).
- 7) Confirm that grease nipple (8) is normal. Inject grease (Shell Albania EP#2) and confirm that the outer race rotates smoothly and that the lip of the seal is not scored.




Fig. 91 Fitting retainer

#### 9.4 MAINTENANCE STANDARD

Regarding the maintenance standard for the wear of the swing bearing, refer to Maintenance Standard and Measurement of Swing Performances under Test Procedure that are explained in a separate manual.

#### 9.5 TOOLS AND JIGS

Unit : mm (in.)

No.	NAME	SKETCH
y	T-bolt and nut	

# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### ATTACHMENT

#### TABLE OF CONTENTS

1. BUCKET	
1.1 Dismantling and Mounting Procedure .....	1
1.2 Construction .....	2
1.3 Maintenance Standard .....	2
2. ARM	
2.1 Dismantling and Mounting Procedure .....	4
2.2 Construction .....	5
2.3 Maintenance Standard .....	7
3. BOOM	
3.1 Preparation for Dismantling and Mounting .....	9
3.2 Dismantling and Mounting Procedure .....	9
3.3 Construction .....	10
3.4 Maintenance Standard .....	12
4. HYDRAULIC CYLINDER	
4.1 Dismantling and Mounting Hydraulic Cylinder .....	14

**LC21**

Applicable Machines

LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC2105E K

# 1. BUCKET

## 1.1 DISMANTLING AND MOUNTING PROCEDURE

### (1) Dismantling bucket

- 1) Operate the operating lever and bring the bucket down to the ground so the bucket and arm connecting pins are not loaded.
- 2) Remove the ring and the pin by means of a flat-bladed screwdriver and draw out pin (A), in order to remove pin (A) in the embossment of the bucket. (Fig. 1)

- ⚠ If the pin is hard to come off, the pin is loaded: Adjust it by manipulating the operating lever
- Exercise care so the dust seal between the arm and the bucket embossment is not scored.




Fig. 1 Removing bucket pin

74-274

- 3) Adjust the bucket by manipulating the operating lever so the pin (B) between the bucket link and the bucket is not loaded.
- 4) Remove the pin securing ring and the pin in the bucket embossment, using a flat-bladed screwdriver and draw out pin (B). (See Fig. 2)

### (2) Mounting bucket (See Fig. 3)

Mounting is performed in the reverse order of dismantling, including the following operations:

- 1) Clean the welds of the structures and check that there is no crack on the welds
- 2) Check the bushing in the bucket embossment to see if it is not worn nor damaged, according to "Maintenance Standard" which will be explained later. Replace it where necessary.
- 3) Check that the dust seal is not scored and replace a faulty one if necessary.
- 4) When inserting the pin, coat the shaft with grease.

- ⚠ The bucket can be mounted easily if the bucket link is installed in the beginning.
- When aligning the pin holes, do not put your finger in the pin holes in any circumstances, but align them visually.

- 5) Adjust the clearance between the bucket and the arm by referring to "Maintenance Standard" which will be dealt with later.




Fig. 2 Removing link pin

74-274




Fig. 3 Mounting bucket

74-274

## 1.2 CONSTRUCTION




Fig. 4 Construction of bucket

No	NAME	Qty	No.	NAME	Qty	No.	NAME	Qty
1	BUCKET	1	6	NUT	10	11	SHIM	3
2	TOOTH ASSY	5	7	O RING	4	12	SHIM	30
3	SIDE CUTTER (RH)	1	8	CAPSCREW (M20)	3	13	BUSHING	1
4	SIDE CUTTER (LH)	1	9	LOCK WASHER	3	14	SPRING PIN	2
5	CAPSCREW (M24)	10	10	PIN	1			

## 1.3 MAINTENANCE STANDARD

### (1) Tightening torque

Table 1

Unit: kgf-m (ft-lbs)


No.	NAME	TIGHTENING TORQUE	REMARK
6	Side cutter fastening nut	100~110 (723~796)	After fastening nuts, spot weld.
8	Capscrew	32±3 (231±22)	For adjusting bucket mounting clearance : 17mm



(2) Procedure for adjusting clearance


Adjustment of clearance between bucket and arm

- 1) Shift O ring (3) toward the bucket embossment, using a spatula.
- 2) When adjusting clearance (B), bring the non-adjusting side of the bucket in contact with the arm.
- 3) Measure clearance (B) and check that it is within 1.2mm (0.05in).
- 4) Adjust clearance (B) where it is more than 1.2mm (0.05in).
- 5) An average of 10 shims of 1mm (0.04in) thickness are set in each of the three socket head cap screws (1). The clearance can be adjusted by 1mm (0.04in) if one shim is removed.

 : 17mm

- 6) After adjustment, tighten the socket head cap screws evenly.
- 7) Operate the bucket and confirm that the total sum of both clearances are within 1.2mm (0.05in)
- 8) Refit O ring (3) to its original position.

- ⚠**
- When shifting O ring (3) by means of a spatula, use care so as not to score O ring (3).
  - Remove shims (2), push out bushing (5) rightwards by means of three socket head cap screws (1) and adjust clearance (B) so it falls within the standard value evenly all round.
  - Check the clearance at 120 hours' intervals in normal operation. Shorten these intervals in special operation. Adjust the intervals as necessary.



YH-E74

Fig. 5 Adjusting clearance between bucket and arm

## 2. ARM

### 2.1 DISMANTLING AND MOUNTING PROCEDURE

Here in under is explained how to dismantle and mount the arm that is fixed to the bucket cylinder.

#### (1) Dismantling

- 1) Retract the rod of the bucket cylinder most and fix the bucket cylinder and the bucket link to the arm.
- 2) Stop the engine and discharge the remaining air from inside the hydraulic oil tank. Remove the hoses connected to the bucket cylinder and plug the connections.
- 3) Place a nylon sling in the body of the arm cylinder and lift it so pin (G) is not loaded.
- 4) Remove capscrews (26) fixing pin (G) and draw out pin (G).

 : 30mm

- 5) Place wooden blocks under the arm cylinder and support the arm cylinder.
- 6) Insert pin (G) into the original position of the arm and attach capscrews (26).
- 7) Place a wire sling in pin (G) and the tip (A) of the arm and lift the arm slightly so pin (F) connecting the arm with the boom is not loaded.
- 8) Remove capscrew (50), plate (49) fixing pin (F) and draw out pin (F).

 : 24mm

- 9) Dismantle the arm with the bucket cylinder.

Weight of arm assy : 1000kg (3520 lbs).

#### (2) Mounting

- 1) Before installing the arm, check the thrust clearance of the pin (G) and the pin (F) and decide the thickness of shims (#47) & (#93) by referring to "Maintenance Standard" which will be described later.

Also check dust seal (17) and replace it if necessary.


- 2) Place a wire sling at pin (G) and the tip (A) of the arm, lift the arm and align the pin holes in the arm and in the boom.
- 3) Install shims (#93) decided under 1) and the grease-coated pin (F) and plate (49) and attach fastening capscrew (50) coated with Loctite #242.

 : 24mm

- 4) Align the pin holes in the rod side of the arm cylinder and in the arm and insert pin (G) and shims (#47).

- 5) Put capscrew (26) fixing pin (G) through pin (G), locknut (28) with Loctite #242 and tighten it up.

On that occasion, set the clearance between the tip of the capscrew and the nut face to 0~0.5mm (0.02in). (See Fig. 7)

 : 30mm

- 6) Attach the hydraulic hoses to the bucket cylinder.

#### Tightening torque

Item	Size	Tightening torque kgf·m (ft·lbs)
Tube clamp	M12	12.3 ± 1.2 (89 ± 8.7)
Band of cylinder	M10	3.2 ± 0.6 (23 ± 4.3)
Nut and sleeve in bite type tube fitting	Tube ∅35×5.0	4.5 ± 4.5 (325 ± 33)





Fig. 6 (1/2) Dismantling and mounting arm




Fig. 6 (2/2) Dismantling and mounting arm




Fig. 7 Tightening locknut

2.2 CONSTRUCTION




Fig. 8 Arm

\* : Only necessary number of shims must be selected.

No.	NAME	QTY	No.	NAME	QTY	No.	NAME	QTY
1	ARM	1	16	DUST SEAL	4	29	LOCK WASHER	2
2	CYLINDER	1	17	DUST SEAL	2	30	WASHER	2
3	BUCKET LINK	1	18	O RING	2	32	WASHER	5
4	IDLER LINK (RIGHT)	1	19	CLAMP	2	33	GREASE NIPPLE	5
5	IDLER LINK (LEFT)	1	*20	SHIM $\varnothing 82$ (Selected: (t=0.5,0.9,1.2,1.6,2.3)	18	34	GREASE NIPPLE	1
6	TUBE	1				35	GREASE NIPPLE	1
7	TUBE	1	21	CLIP	2	36	CONNECTOR	1
8	HOSE	2	*22	SHIM $\varnothing 92$ (Selected: (t=0.5,0.9,1.2,1.6,2.3)	3S	37	CONNECTOR	1
9	PIN	2				38	HOSE	1
10	PIN	1	23	CAPSCREW (M12 $\times$ 60)	4	39	RING	2
11	PIN	1	24	CAPSCREW (M12 $\times$ 75)	8	40	PIN	2
12	PIN	1	25	CAPSCREW (M20 $\times$ 160)	3	*47	SHIM $\varnothing 112$ (Selected: (t=1.2,1.6,2.3)	18
13	PIN	1	26	CAPSCREW (M20 $\times$ 180)	1			
14	DUST SEAL	4	27	CAPSCREW (M6 $\times$ 12)	2	50	WASHER	4
15	DUST SEAL	2	28	NUT	8			

## 2.3 MAINTENANCE STANDARD

### (1) Clearance between pin and bushing




Fig 9 Clearance between pin and bushing of arm section

Table 2

Unit : mm (in)

No.	Item	Standard dimension			Clearance			Remedy
		Pin dia	Tolerance on pin dia	Tolerance on bushing bore dia	Standard value	Reference value for remedy	Serviceability limit	
A	Arm cylinder (arm side)	∅90 (∅3.5433)		+0.375 (0.0148)	0.39 (0.015)			
B	Bucket link (bucket side)			+0.320 (+0.0126)	0.51 (0.020)			
C	Idler link (connected part of arm)	∅80 (∅3.1496)		+0.279 (+0.0110)	0.26 (0.010)			
				+0.194 (+0.0076)	0.41 (0.016)			
D	Bucket cylinder (rod side)	∅90 (∅3.5433)	-0.070 (-0.0028) -0.130 (-0.0051)	+0.250 (+0.0098)	0.12 (0.004)	2.5 (0.098)	3.0 (0.118)	Replace bushing or pin
D	Bucket link (cylinder side)			-0.375 (+0.0148)	0.39 (0.015)			
				+0.320 (+0.0126)	0.51 (0.020)			
E	Bucket cylinder (arm side)			+0.250 (0.0098)	0.12 (0.005)			
				+0.050 (+0.0020)	0.38 (0.015)			
G	Arm cylinder (arm side)	∅110 (∅4.3307)						
F	Connecting part of arm and boom	∅100 (∅3.9370)	±0.02 (±0.0008)	+0.375 (+0.0148)	0.30 (0.012)			
				+0.320 (+0.0126)	0.40 (0.016)			

(2) Thrust clearance between arm and cylinder mounting mounting




Fig. 10 Thrust clearance between arm and cylinder mounting

Table 3

Unit: mm (in)

Section	Item		Standard dimension		Shim adjusted clearance X (total of both sides)			Remedy				
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit					
A	Arm top (bucket mounting part)	Arm	L1	380 <sup>+0.1</sup> (14.961 <sup>+0.002</sup> )	Less than 1.2 (0.047)	2.5 (0.098)	3.0 (0.118)	Shim adjustment				
		Bucket	L1	382 <sup>+0.2</sup> (15.039 <sup>+0.008</sup> )								
D	Bucket link (bucket side)	Link side	L2	(380 (14.961))								
		Bucket	L2	382 <sup>-0.1</sup> (15.039 <sup>-0.004</sup> )								
C	Idler link (arm connecting part)	Arm	L3	380 <sup>+0.2</sup> (14.961 <sup>+0.008</sup> )								
		Link side	L3	---								
D	Bucket link (cylinder side)	Rod side	L4	128 <sup>-0.2</sup> ( 5.039 <sup>-0.008</sup> )								
		Link side	L4	130 <sup>+0.2</sup> ( 5.118 <sup>+0.008</sup> )								
E	Bucket cylinder mounting part (arm side)	Bottom side	L5	128 <sup>-0.2</sup> ( 5.039 <sup>-0.008</sup> )					Less than 2.0 (0.079)	3.0 (0.118)	4.0 (0.157)	
		Arm	L5	130 <sup>+0.2</sup> ( 5.118 <sup>+0.008</sup> )								
F	Connecting part between arm and boom	Arm	L6	400 <sup>+0.2</sup> (15.748 <sup>+0.008</sup> )								
		Boom	L6	401.8 <sup>-0.2</sup> (15.819 <sup>-0.008</sup> )								
G	Arm cylinder mounting part (arm side)	Rod side	L7	140 <sup>-0.2</sup> ( 5.512 <sup>-0.008</sup> )	Less than 2.0 (0.079)	3.0 (0.118)	4.0 (0.157)					
		Arm	L7	142 <sup>+0.1</sup> ( 5.591 <sup>+0.004</sup> )								

### 3. BOOM

#### 3.1 PREPARATION FOR DISMANTLING AND MOUNTING

- 1) Retract the arm cylinder mast. Support it by wooden blocks and fix it to the boom.
- 2) Bring down the boom and support the top end by an appropriate stand.
- 3) Stop the engine and lock the operating lever.
- 4) Disconnect the electric wiring for the working light.
- 5) Vent the remaining air in the hydraulic oil tank and separate the hydraulic pipes of the upper frame side and those of the attachment side. Plug the joints.

#### 3.2 DISMANTLING AND MOUNTING PROCEDURE

##### (1) Dismantling

- 1) Dismantle the arm cylinder and the boom cylinder by referring to "4.1 Dismantling and Mounting Hydraulic Cylinder" which will be dealt with later.
- 2) Temporarily lift the boom lightly by crane so boom foot pin (53) will not be loaded.
- 3) Separate capscrew (57) fastening boom foot pin (53) and plate (56). Then draw out boom foot pin (53).
- 4) Lift the boom by crane and remove it with shims (37).

▲ Put a tag to each shim showing the location and keep it so it will not be lost.



##### (2) Mounting

Mounting of the boom is done in the reverse order of dismantling, but pay attention to the following points:


- 1) Replace the worn pin and bushing and dust seal (47) by referring to "Maintenance Standard" which will be described later.
- 2) In installing the boom and the cylinders, check the thrust-wise clearance in the mounting part and decide the thickness of shims by referring to "Maintenance Standard" which will be explained later.
- 3) When installing pins (53), (29), (54), and (28), coat the inner surface of the bushing with molybdenum-added grease.
- 4) Before tightening locknut (40) of the locking capscrews for the boom cylinder rod pin (29) and the arm cylinder head pin (28), coat them with Loctite #242. Set the distance between the tip of the capscrew and the nut face to  $0-0.5\text{mm}$  ( $0-0.02\text{in}$ ).

#### ▲ Tightening torque

Item	Size	Tightening torque kgf·m (ft lbs)
Tube clamp	M13	$12.3 \pm 1.2$ (89 ± 8.7)
Band of cylinder	M10	$3.2 \pm 0.6$ (23 ± 4.3)
Nut and sleeve in bite type tube fitting	Tube ∅35×5.0	$46 \pm 4.5$ (325 ± 33)



SECTION AA



SECTION CC

Fig. 11 Dismantling and mounting boom

3.3 CONSTRUCTION




Fig. 12 Boom



NOTE: Only necessary number of shims must be selected.

No	NAME	QTY	No.	NAME	QTY	No.	NAME	QTY
1	BOOM	1	29	PIN	1	58	WASHER	4
2	BOOM CYLINDER (LH)	1	30	PIN	1	*59	SHIM	2S
3	BOOM CYLINDER (RH)	1	31	COLLAR	2		(t=0.5,0.9,1.2,1.6,2.3)	
4	TUBE	1	32	CAPSCREW (M20×180)	1	*65	SHIM	3S
6	TUBE	1	33	CAPSCREW (M20×25)	2		(t=0.5,0.9,1.2,1.6,2.3)	
6	TUBE	1	37	SHIM t=3.2	2	69	PLATE	2
7	TUBE	1	40	NUT	6	73	HOSE	1
8	TUBE	1	44	HOSE	1	77	BRACKET	1
9	TUBE	1	47	DUST SEAL	2	76	CAPSCREW (M10×20)	1
10	TUBE	1	46	GREASE NIPPLE	7	79	WASHER	1
11	TUBE	1	49	PLATE	1	80	GREASE NIPPLE	1
12	TUBE	1	50	CAPSCREW (M16×35)	2	81	HOSE	1
13	TUBE	1	51	WASHER	2	83	ARM CYLINDER	1
14	TUBE	2	52	HOSE	4	*87	SHIM	1S
15	HOSE	2	53	PIN	1		(t=0.5,0.9,1.2,1.6,2.3)	
16	HOSE	1	54	PIN	2	92	CAPSCREW (M20×190)	2
17	HOSE	1	55	HOSE	3	*93	SHIM (t=1.2,1.6)	1S
27	HOSE	1	56	PLATE	1			
28	PIN	1	57	CAPSCREW (M20×55)	2			

### 3.4 MAINTENANCE STANDARD

#### (1) Clearance between pin and bushing




Fig. 13 Clearance between boom pin and bushing

Table 4

Unit: mm (in)

No.	Item	Standard dimension			Clearance			Remedy
		Pin dia	Tolerance on pin dia	Tolerance on bushing bore dia	Standard value	Reference value for remedy	Serviceability limit	
A	Boom foot	∅110 (∅4.3307)	±0.02 (±0.0008)	+0.295 (+0.0116)	0.22 (0.008)	2.5 (0.098)	3.0 (0.12)	Replace bushing or pin
		+0.240 (+0.0094)		0.32 (0.013)				
B	Boom cylinder (Head side)	∅100 (∅3.9370)		0.07 (0.003)	0.27 (0.011)			
C	Boom cylinder (Rod side)	∅110 (∅4.3307)		+0.250 (+0.0096)				
			+0.050 (+0.0020)	0.36 (0.015)				
E	Arm cylinder (Head side)		-0.070 (-0.0028)					
			-0.190 (-0.0051)					

(2) Thrust-wise clearance between boom and cylinder mounting




Fig. 14 Thrust-wise clearance between boom and cylinder mounting

Table 5

Unit: mm (in.)

Section	Items		Standard dimension		Shim adjusted clearance X (total of both sides)			Remedy
			Code	Dimension	Standard value	Reference value for remedy	Serviceability limit	
A	Booms foot	Boom	L1	$830_{-0}^{+0}$ (32.677 $_{-0.000}^{+0.000}$ )	Less than 0.6 (0.024)	2.5 (0.098)	3.0 (0.118)	Shim adjustment
		Upper frame		$882_{-0.012}^{+0.012}$ (34.756 $_{-0.012}^{+0.012}$ )				
B	Boom cylinder (Head side)	Boom cylinder	L2	$130_{-0.05}^{+0}$ ( 5.118 $_{-0.020}^{+0}$ )	Less than 0.6 (0.024)	2.5 (0.098)	3.0 (0.118)	
		Upper frame		$131_{-0.05}^{+0}$ ( 5.157 $_{-0.020}^{+0}$ )				
C	Boom cylinder (Rod side)	Boom cylinder	L3	$120_{-0.05}^{+0}$ ( 4.724 $_{-0.020}^{+0}$ )	Less than 1.2 (0.047)	3.0 (0.12)	4.0 (0.16)	
		Boom		1581 (22,874)				
E	Arm cylinder (Head side)	Arm cylinder	L4	$140_{-0.05}^{+0}$ ( 5.512 $_{-0.020}^{+0}$ )	Less than 0.6 (0.024)	2.5 (0.098)	3.0 (0.118)	
		Boom		$142_{-0.05}^{+0.07}$ ( 5.591 $_{-0.020}^{+0.028}$ )				

## 4. HYDRAULIC CYLINDER

### 4.1 DISMANTLING AND MOUNTING HYDRAULIC CYLINDER

#### (1) Dismantling hydraulic cylinder

- 1) Lift the cylinder lightly so the rod side pin is not loaded.

Then remove the rod side pin and the shims. But, when it is difficult to remove the rod side pin of the boom cylinder, firstly remove the head side pin by referring to 4) which will be described later.


Put a tag to each of the shims showing location or attach each shim to its removed position by means of a string.


- 2) Retract the cylinder rod.
- 3) Disconnect the joints of the hydraulic hoses and plug those joints to prevent entry of foreign matter.
- 4) Lift the cylinder lightly so the head pin is not loaded.

Then remove the head pin and the shim.

#### (2) Mounting hydraulic cylinder


- 1) Mounting the hydraulic cylinder is performed in the reverse order of dismantling.
- 2) Adjust the clearance in the thrust direction between the rod and head pin mount, using iron shims, so that the clearance falls within the standard dimension.
- 3) Before inserting pins, coat the shaft with grease.
- 4) Coat the pin locking capscrew and the nut with Loctite #242 and set the gap between the tip of the capscrew and the nut face to less than 0.5mm (0.02in)

 : 30mm




YH-E74

Fig. 15 How to dismantle and mount boom cylinder



YH-E74

Fig. 16 How to dismantle and mount arm cylinder



YH-E74

Fig. 17 How to dismantle and mount bucket cylinder

# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### CONTROL SYSTEM

#### TABLE OF CONTENTS

1. OPERATING CONTROLS	
1.1 Operating Switches of Control Board .....	1
1.2 Display Function .....	6
1.3 Control Lever Operation .....	10
1.4 Engine Control .....	11
2. MECHATRONIC CONTROL	
2.1 KPSS Controller (C-1) .....	11
2.2 Cluster gauge Controller (C-2) .....	14
3. MAIN ELECTRIC EQUIPMENT	
3.1 Summary of Main Electric Equipment .....	21
3.2 List of Electric Equipment .....	43

**LC22**

**Applicable Machines**


LC03801~

YC01101~


Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC2205E K

# 1. OPERATING CONTROLS

## 1.1 OPERATING SWITCHES OF CONTROL BOARD




(1) Starter key switch




- HEAT ; No function (Use other injection switch)
- OFF ; E/G stop position  
Key pull out position
- ACC ; Accessory usable position  
Cigarette lighter  
12V socket
- ON ; E/G running position
- START ; E/G start position

(2) K.P.S.S. work mode switch




- H ; For heavy digging operation.
- S ; For light duty operation.
- FC ; For fine manipulation.
- D ; Independent travel.

(3) Accel potentiometer



- LO ; Low idling  
(Minimum revolution)
- HI ; High idling  
(Maximum revolution)


(4) Variable loading mode switch



This variable speed switch allows the operator to adjust the raise speed of the boom in relation to the swing speed when these functions are performed at the same time. If the dial is turned clockwise, the speed of the boom is decreased while the swing speed is

increased. Turning the dial counterclockwise, increases the speed of the boom and decreases the swing speed. This allows you to adjust the boom and swing speeds to match your needs

(5) Wiper and washer switch



- OFF ; Wiper switch off
- One notch ; Intermittently
- Two notch ; Continuously
- Press ; Washer fluid sprays out




- Do not press the switch if the washer fluid is empty. Otherwise the motor may be damaged.
- The washer tank is located at the lower right-hand side of the floor mat by the operator's seat.

(6) Working light IFR select switch



- Boom & Frame working light
- OFF
- Boom & Frame & Rear working light

(7) Buzzer stop/Time set (Oil supply reset) switch




- Buzzer stop
- OFF
- Time set

1) Buzzer sound included next function

- E/G Oil pressure
- E/G Air filter restriction
- E/G Water temperature
- E/G Oil filter restriction
- Time correct (Every 250Hr E/G oil)


2) Buzzer stop/Time set/Oil change reset switch



**BUZZER STOP**  
pressing the top of the switch will turn OFF the buzzer on the instrument panel.


**NOTE :** The buzzer sounds under the following conditions;





1. Air cleaner clogged
2. Oil level low
3. Abnormal rise in coolant temperature
4. Engine oil change reminder

If the buzzer sounds, then inspect and correct any problems that may exist.



**TIME SET**


Pressing and holding the bottom of the switch will change the reading of the clock display.

**OIL CHANGE RESET**


At a regular 500 hour interval the gauge cluster will display a reminder to change the engine oil. The buzzer will also sound. Change the engine oil at this time.

**NOTE :**


- To remove the display and to stop the buzzer, press the top of the buzzer stop switch two times.
- If you want to change your engine oil at an interval of less than 500 hours, then you can reset the reminder through the following procedure




1. Turn the work mode selector switch to the "D" mode.



2. Press the bottom of the buzzer stop switch and the gauge cluster will display the number of hours your machine has operated since the last oil change.




3. The oil change reminder will be displayed only at the 500 hour interval, so to receive the reminder sooner, you must make the gauge cluster believe that 500 hours have elapsed.




**FOR EXAMPLE**

To reset the reminder to a 200 hour interval; press and hold the buzzer stop switch for 30 seconds, the elapsed hours display will begin to count upwards automatically.




When you reach the 300 hour mark, then release the switch. The gauge cluster will now believe that 300 hours have elapsed, and the reminder will be displayed after 200 more hours of operation. (300 + 200 = 500)



4. The oil change reset procedure must be performed each time after the reminder is displayed. (If you want an interval of less than 500 hours)

**(8) K.P.S.S work mode release switch**




RELEASE ; S mode E/G rpm in CPU trouble

K.P.S.S ; Normal operation

- Remove the rubber cap but do not touch this switch unless CPU trouble is displayed.

**(9) Swing flasher select switch**



- Swing flashers light in Swing operating
- Swing flashers do not flash


**(10) Auto accel select switch**



ON ; E/G auto accel in operating lever and neutral lever continues for four seconds E/G decel revolution

OFF ; Auto accel released position

(11) Air conditioner



(A) FAN SWITCHES

The switches control the air conditioner ON/OFF function and the blower speed.

- I position ..... Low
- II position ..... Medium
- III position ..... High (Maximum)

(B) AIR VENT SELECTION SWITCH

These switches control the open/close position of each air vent. Select the desired air flow mode from the three mode position. The selected position is always shown by a lamp.

(C) AIR INLET SELECTION SWITCH

This switch selects the open or close position of air inlet.

(D) TEMPERATURE CONTROL SWITCHES

These switches control the temperature of air coming out of the air vents to any of five levels during heating (red level) and cooling (blue level).


- 1) Push the right switch (⊖), and the range of the LED lights decrease and the air temperature goes down.
- 2) Push the left switch (+), and the range of the LED lights increase and the air temperature goes up.

(E) AIR CONDITIONER SWITCH

This is used to turn ON and OFF the cooling function during cooling or dehumidification heating, or while the cool box is being used. Push once to change over from ON/OFF to OFF/ON.

When the switch is turned ON, the ☆ lamp on the upper part of the switch lights up.

(12) Horn switch



Push on horn mark


(13) Power boost switch



During pushing on power boost mark digging force increases 12%


⚠ Never use power boost switch during lifting operations. Unexpected implement speed changes could result in injury to personnel.

(14) Manual E/G stop knob



⚠ Only use to stop the engine in an emergency

(15) Travel speed select switch



- High speed Max. 5.5km/h
- Low speed Max. 3.5km/h

## 1.2 DISPLAY FUNCTION
























### (1) OK MONITOR FUNCTIONS BY MULTI DISPLAY

Priorities given to displays are as listed in Tables. Displays with higher priorities are displayed first. For instance, if the engine oil pressure (priority 3) and the fuel level (priority 5) are both abnormal, the engine oil

pressure alarm having a higher priority is displayed. Where alarms of equal priority, the radiator water level and the engine oil level faults occur, for instance the radiator water level alarm and the engine oil level alarm displayed in sequence.

PRIORITY DISPLAYS TABLE


Table 1

Priority	Service diagnosis function					Buzzer	
1	SYSTEM STATUS DISPLAY 					—	
2	ENGINE PRE-HEATING 	ENGINE PRE-HEAT COMPLETE 				—	
3	ENGINE OIL PRESSURE 	ENGINE COOLANT TEMPERATURE 	ENGINE AIR CLEANER RESTRICTION 	ENGINE OIL FILTER RESTRICTION 	Buzzer		
4	SERVICE DIAGNOSIS FUNCTION 	ENGINE STOPPED 	STEPPING MOTOR FAIL 	STEPPING MOTOR OFF 	—		
5	ENGINE COOLANT LEVEL 	ENGINE OIL LEVEL 	HYDRAULIC OIL LEVEL 	BATTERY CHARGING SYSTEM 	FUEL LEVEL 	I.T.C.S. CONTROLLER - CPU 	—
	HYDRAULIC TANK PRESSURE (5K420GPa) (GPa) 	HYDRAULIC OIL FILTER 					—
6	ATTACHMENT BOOST PRESSURE 	REPLACE ENGINE OIL 				—	
7	SYSTEM STATUS DISPLAY 					—	
8	TIME DISPLAY 					—	

12) SYSTEM

● NG DISPLAY ON MULTI DISPLAY

1) SYSTEM STATUS DISPLAY



YMK-2-72

This symbol is displayed when the controller for the clusters gauge and warning lamp. Monitoring system is not functioning properly.

2) SYSTEM STATUS DISPLAY



YMK-2-23

This symbol is displayed if all systems and components are normal.

3) ENGINE PRE-HEATING



LC2-2049

This symbol is displayed when key switch is turned to heat position and the engine preheat circuit is activated.

This display lasts about 25 seconds and then goes out at completion of pre-heating, at which time GLOW is displayed.

4) ENGINE PRE-HEAT COMPLETE



LC2-0093

This symbol is displayed when engine pre-heating is complete.



Stop preheating immediately after preheat complete is displayed to prevent damaging the air heater.

5) ENGINE OIL PRESSURE



YMK-2-25

This symbol is displayed, and the warning buzzer is sounded, when engine oil pressure is too low. Stop the engine immediately and check the engine oil level.

6) ENGINE COOLANT TEMPERATURE



YMK-2-26

This symbol is displayed, and the warning buzzer is sounded, if the engine coolant temperature becomes abnormally high. If this symbol is displayed, reduce engine speed to idle until the coolant temperature is reduced.

7) ENGINE AIR CLEANER RESTRICTION



YMK-2-27

This symbol is displayed, and the warning buzzer is sounded, if the engine air cleaners become too restricted to allow proper air flow.

Replace or clean the air cleaner if this symbol is displayed.

8) ENGINE OIL FILTER RESTRICTION



LC2-0054

This symbol is displayed, and the warning buzzer is sounded, if the engine oil filter becomes too restricted due to contamination.

This symbol is only displayed when the alternator is charging.

If this symbol is displayed, replace the engine oil filters immediately.

9) 10) 11) NO FUNCTION

12) ENGINE COOLANT LEVEL



YMK-2-24

This symbol is displayed when engine coolant level is low. This is only shown when key switch is turned to the ON position, before engine startup.

If this symbol is displayed, check radiator and surge tank coolant levels.

13) ENGINE OIL LEVEL



LC2-0059

This symbol is displayed when engine oil level in the engine oil pan is low. This symbol is only shown when the key switch is turned to the on position, before engine start up.

This symbol will not display if the alternator is charging and engine oil level drops during operation. If this symbol is displayed, check engine oil level immediately before starting engine.

14) HYDRAULIC OIL LEVEL




YMK-2-28

This symbol is displayed when hydraulic oil level is low. The attachment must be in the proper check position to accurately determine hydraulic oil level. If this symbol is displayed, place machine in proper check

position, verify with hydraulic tank sight gauge, and add oil if required.

15) BATTERY CHARGING SYSTEM



YMK-2-31

This symbol is displayed when a problem occurs in the electrical charging system during engine operation. A problem occurs in the charging system.

16) FUEL LEVEL



YMK-2-12

This symbol is displayed when the fuel level in the fuel tank has reach 50% 18.2 gallons or less.

It also will be displayed if fuel level drops to a low level during operation. Add fuel if this symbol is displayed.

17) I.T.C.S. CONTROLLER CPU



YMK-2-33

This symbol is displayed when a problem exists with the I. T. C. S.-Intelligent Total Control System. This display will indicate a problem with the main I.T.C.S. Controller-CPU.

The CPU programming may just be temporarily out of order if this symbol is displayed, try turning off the key switch and back to the ON position. If machine operation is necessary, turn the KPSS release switch to the release position and machine operation will be possible until repair can be completed.

18) NO FUNCTION

19) HYDRAULIC TANK AIR PRESSURE

(SK430III, SK430LCIII ONLY)




19 H. AIRPRESS

This display occurs when the inner air pressure of the hydraulic tank is below  $0.25\text{kgf/cm}^2$  (3.6psi). Machine operation is not possible when this display is ON. If this symbol is displayed, contact your authorized KOBELCO Dealer Service Dept.

20) NO FUNCTION

21) HYDRAULIC OIL FILTER



21 H. OIL FLTR

This symbol is displayed when the hydraulic oil filters are clogged and the hydraulic oil temperature is normal. Replace the filter elements. Examine the filters for the cause of the contamination.

22) ATTACHMENT BOOST PRESSURE



22 HEAVY LIFT

This symbol is displayed when the attachment power boost switch in the right operating lever button is pushed. The symbol displayed is only to show when this system is activated, no problem exists when this symbol appears.

23) REPLACE ENGINE OIL



23 OIL SUPPLY

This symbol is displayed every 250 hours of machine operation time. It appears every 250 hours to remind the operator that the engine oil needs changed.

- Replace the engine oil filter elements at the same time
- To reset this display, press buzzer stop switch twice.

24) ENGINE STOPPED



24 OIL PRES

If engine oil pressure is not correct for three seconds during engine running, or 13 seconds after starting of engine rotation, the engine is automatically stopped.

On that occasion, the display on the left appears followed by a circle  $\odot$ . The display continues for about ten seconds, and during this period the engine can not be restarted. Check the engine oil level and for oil leakage.

25) STEPPING (GOVERNOR) MOTOR FAIL



25 S/M FAIL

This symbol is displayed when a problem exists in the electrical circuit for the E/G accel stepping motor assy (governor motor).

The symbol will be displayed when the stepping motor does not automatically index, or move, the engine throttle back to its starting point within 40 seconds after turning the key switch off and then back on. If the stepping motor does not index back to the starting point, it indicates a possible failure of the stepping motor limit switch or a fault in the wiring harness. When the motor fail symbol is displayed, engine

throttle control via the mechatronics system and stepping motor will not be possible. The engine accel potentiometer can be positioned manually to allow machine operation. The manual engine stop knob must be used then to shut down the engine. The following functions do not work when the motor fail symbol is displayed:

1. KPSS mode selection-H, S, FC, and B modes
2. Auto accel
3. Engine shut down via the key switch
4. Variable loading mode


26) STEPPING (GOVERNOR) MOTOR OFF



26 S/M OFF

This symbol is displayed when the electrical current to the stepping motor is stopped. The current supply is stopped if less than 1amp or more than 2amps is supplied to the stepping motor the coil for more than 13 seconds after the stepping motor fails to index, or move, back to the starting point. The current supply to the stepping motor is also stopped if 6amps or more is supplied for 3 seconds. If this button condition occurs, turn off key switch to prevent damage to the controller.

27) TIME DISPLAY



12:34


This mark is indicated for items to which no specific mark is assigned. The normal mark when the key is on. It is displayed about two seconds after the OK monitor mark disappears.

1.3 GREEN L.E.D. INDICATOR LAMPS

FLASHER		→ Swing flasher
SLOW		→ 1st speed travel
FAST		→ 2nd speed travel
AUTO ACCEL		→ Auto accel and decel

**▲** The swing flasher L.E.D. flashes when swing is engaged the swing flasher switch is on. If a swing flasher bulb is burnt out the swing flasher L.E.D. lamp will stay on steady.


● GAUGE  
28) HOUR METER



It indicates cumulative operating hours of the engine.

The last two digits indicate 1/10H and 1/100H, respectively.

1.4 FUEL GAUGE AND WATER TEMPERATURE GAUGE



**Fuel gauge**  
..... The fuel level is indicated by the position of the indicator lights.

**Water temp. gauge**  
..... A water temperature range of  $62\sim 105^{\circ}\text{C}$  ( $144\sim 221^{\circ}\text{F}$ ) is indicated by the position of the indicator lights.

### (3) ENGINE REVOLUTION DISPLAY

The multipurpose display can display the engine revolution.


- 1) Press buzzer stop switch 5 times to display the engine speed.
- 2) By pressing one more time, the display changes to CLOCK.
- 3) And by pressing the switch one more time the engine revolution is displayed.
- 4) Then repeat this procedure.

### (4) SERVICE DIAGNOSIS (By auto accel lamp)

The service diagnosis of mechatronics system can be performed by checking the flickering condition of auto accel lamp.

- 1) Engine start
- 2) By continuously pressing the buzzer stop switch, the failure contents are displayed with flickering of lamp on and after 6 of 10 seconds.
- 3) If the lamp is continuously lit, the operation is normal.
- 4) The lamp goes off by releasing the switch.

And in case failures simultaneously occur on two or more places, the flickering of lamp will be continued.





### SERVICE DIAGNOSIS TABLE


Table 2

Code	Contents	Lamp ON/OFF state table						Checking and corrective action
		ON	OFF	ON	OFF	ON	OFF	
0	Engine stops or the speed is less than 420rpm.	X						Check the wiring up to the revolution sensor.
1	Error data or not adjusted in ROM.	X						Perform A adjustment and B adjustment.
2	In indexing stepping (governor) motor starting point or impossible to index	X						Check the stepping (governor) motor limit switch and also the wiring.
3	Judged engine rotates in reverse direction.	X						Check ECU of pressure switch, S-C water temperature switch and wiring.
4	Failed to adjust the mechatronics controller.	X						Perform A adjustment and B adjustment.
5	Incorrect current applied to solenoid valve (Power shift) (Load model)	X						Check the wiring up to the solenoid valve.
6	Incorrect current on stepping motor (Less than 1A or 2A or more)	X						Check the wiring up to the stepping motor.
7	Stepping (governor) motor abnormally rotated	X						Check the mounting state of stepping motor, link, rod, etc.
	In normal state	X	X	X	X	X	X	
				0.32sec.			5.13sec.	

### 1.3 CONTROL LEVER OPERATION




(1) **Lever Lock (Remote Control Cut Lever) Operation.**  
 If the rod lever of lever lock (1) is pulled up, the limit switch is turned off. This cuts off the lever lock of the electromagnet selector valve electrically which cuts off the primary pilot pressure of the remote control valve of the attachment. This serves as a safety unit that does not actuate the machine by lever action. Furthermore, if the lever is pulled up jerkily, the striker is disengaged which in turn causes the control box to spring up 25°, thereby making access to the machine easier.



(2) **Travel Operation**  
 Traveling forward means where the forward movement of the front idler of lower travel body accords with the forward direction of the operator :

Lever (2) push forward	Advance
Lever (2) pull toward yourself	Retreat


However, Where the moving direction of the front idler of the lower travel body does not accord with the forward movement of the operator, the lever operation must be reversed.



Procedure for adjusting the limit switch

Fig. 2

(3) **Attachment Operation (ISO operating method)**



## 1.4 ENGINE CONTROL




Fig. 3 Control

### (1) Starting and Stopping the Engine

(Refer to Operation of Switches.)

The engine can be started and stopped with the engine key.

To start the engine, turn the engine key to START. Let your hand off from the key after the engine starts.

To stop the engine, turn the engine key to OFF. The engine stops about four seconds later.

### (2) Engine Revolution Control

(Refer to Operation of Switches.)

The accel potentiometer which is of dial rotary switch type holds a set revolution.

The operating sequence is: Change the rotary switch. → Electric resistance of potentiometer changes. → Controller → Governor motor (2) (accelerator) Control → Governor lever (12) rotates → Rod end assy operates. → E/G governor control → E/G revolution changes.

### (3) Auto Accel Control

(Refer to Operation of Switches.)

When the auto accel select switch is on, a set accel revolution and a set rotation time of the accel potentiometer are repeated, depending upon whether or not the auto accel is neutral.

### (4) Manual Engine Stop (3)


Pull manual engine stop knob.

— Engine stops.


Return manual engine stop knob

— Returns after engine stops.

In case the engine does not stop even if the engine key is brought to OFF, pull the manual engine stop knob located under the lower righthand side of the seat stand. This pulls the engine stop lever directly to the stop side, consequently stopping the engine.



VIEW AA ROD END ASS'Y



VIEW BB

Fig. 4 Operator seat




Fig. 5 Detail of emergency E/G stop knob control cable (3)



## 2. MECHATRONIC CONTROL

### 2.1 KPSS CONTROLLER (C-1)

#### (1) Mechatronic Adjustment

Where any of the components listed in the table below is replaced, always perform Mechatronic Adjustment A or B. (marked ○)


Parts to be replaced	Adjustment A	Adjustment B
Mechatronic controller	○	○
Governor motor	○	—
Solenoid proportionate reducing valve for loading mode	—	○

Conditions Common to Mechatronic Adjustments A and B


Keep the engine key OFF when turning the controller switch in the mechatronic controller (C-1) to either Adjust Prohibit or Permit.

If you turn the controller switch to Permit and turn the engine key to ON, the auto accel lamp lights continuously. After confirming that the lamp is out, execute the following steps:

- 1) Adjustment A (Setting E/G revolution)  
Refer to Maintenance Standard and Test procedure.
- 2) Adjustment B (Set the loading mode).  
Refer to Maintenance Standard and Test procedure.



C-1: KPSS CONTROLLER




Detail of Grommet Inside

VIEW III

Fig. 6 Mounting position of mechatronic controller (C-1)

#### (2) Harness



12PAF-AMP → C-1

2L 52L	1K 54L	1M 56A	2N 57	1U 55	1V 58A
F	DL	UR	V	OB	WG
2L 57	1K 52	1M 54	2N 51	1U 53	1V 56A
GV	O	B	LO	90	LR

18PAF-AMP → C-1

2B 58C	1U 58B	2C 57	1N 56	2D 51	1S 53	1W 58	2E 51	1H 58
WL	GW	PG	R	Green	Black	YI	BY	G
1U 58A	2C 57	1N 56	2D 51	1S 53	1W 58	2E 51	1H 58	1J 57
68	60	WB	WG	Red	White	VE	3P	B

3PAF-090 → C-1



Fig. 7 C-1 Controller harness and connector

However, see the connector from the engaged surface.

(3) Mechatro (KPSS) Controller IN/OUT Diagram






Fig. 8

(4) KPSS Controller and I/O Signals


No.	Wire color	Signal Name	In / Out
A 1	CY	Radiator coolant temperature signal	In
A 2	O	E/G oil pressure	In
A 3	B	Mechatronics adjustment start signal	In
A 4	LO	S mode signal	In
A 5	BO	II mode signal	In
A 6	LR	ATT boost signal & Heavy lift signal	In
A 7	P	Auto accel signal	In
A 8	OL	Buzzer stop signal	In
A 9	LB	Steering pressure signal	In
A 10	V	Stepping (governor) motor (Starting point of limit switch)	In
A 11	OB	Cluster gauge receiving (Serial communication)	In
A 12	VG	Cluster gauge sending (Serial communication)	Out
B 1	GR	Throttle and Loading (Potentiometer power source ⊕)	Out
B 2	GO	Throttle lever position signal	In
B 3	WR	Loading mode position signal	In
B 4	1.25WG	Battery relay drive signal	Out
B 5	Red	Stepping motor coil B phase	Out
B 6	White	Stepping motor coil B phase	Out
B 7	YR	KPSS release solenoid valve grounding ⊖	Out
B 8	RP	Loading mode solenoid valve grounding ⊖	Out
B 9	R	Controller grounding ⊖	Out
B 10	1.25WL	Key switch (M) terminal signal	In
B 11	GW	Throttle and Loading (Potentiometer grounding ⊖)	In
B 12	PG	Cluster gauge signal (CPU trouble)	Out
B 13	PL	Cluster gauge signal (Auto accel)	Out
B 14	Green	Stepping motor coil A phase	Out
B 15	Black	Stepping motor coil A phase	Out
B 16	YL	KPSS release solenoid valve power source ⊕	Out
B 17	BY	Loading mode solenoid valve power source ⊕	Out
B 18	G	KPSS controller power source ⊕	In



KPSS CONTROLLER CONNECTOR AND I/O SIGNALS



CN 1B (18 PAM)										CN 1A (12 PAM)					
18	17	16	15	14	13	12	11	10		ⓐ	ⓑ	ⓒ	ⓓ	ⓔ	
9	8	7	6	5	4	3	2	1		ⓕ	ⓖ	ⓗ	ⓘ	ⓙ	



No.	Wire color	Signal Name	In / Out
C 1	Red	Revolution sensor	Out
C 2	White	Revolution sensor	In
C 3	Gr-R	Shield ⊖	In
C 4	—	—	—
C 5	—	—	—



(5) Controller Resistance Value Measuring Procedure

After replacing controller, check the resistance value without fail before turning it on again. After turning key switch OFF, remove the CN1B and perform measurement on the harness side.

	(Standard value)	(Situation at 0Ω)
CN1B Between 1 and 11	1KΩ	(Potentiometer / Short circuit)
CN1B Between 1 and 9	1MΩ or more	(Potentiometer / Grounding)
CN1B Between 4 and 9	250Ω (~100Ω)	(Relay / Grounding)
CN1B Between 5 and 6	5.7Ω ± 10%	(Stepping motor / Short circuit)
CN1B Between 14 and 15	5.7Ω ± 10%	(Stepping motor / Short circuit)
CN1B Between 5 and 9	1MΩ or more	(Stepping motor / Grounding)
CN1B Between 14 and 9	1MΩ or more	(Stepping motor / Short circuit)
CN1B Between 7 and 16	13.5Ω ± 0.7Ω	(Solenoid valve / Short circuit)
CN1B Between 8 and 17	13.5Ω ± 0.7Ω	(Solenoid valve / Short circuit)
CN1B Between 7 and 9	1MΩ or more	(Solenoid valve / Grounding)
CN1B Between 8 and 9	1MΩ or more	(Solenoid valve / Grounding)
CN1B Between 18 and 9	4Ω	(Power source / Grounding)

2.2 CLUSTER GAUGE CONTROLLER (C-2)

(1) Location of controller



C-2 CLUSTER GAUGE CONTROLLER  
VIEW B

Fig. 10 Fitting place of controller (C-2)

(2) Harness





Fig. 11 C-2 Controller harness

16PAF-040→C-2

208	207	206	205	204	203	202	201
G	Y	BL	D	BS	A	R	HY
216	215	214	213	212	211	210	209
W	GR	BR	BW	VW	Y	CH	I

CN2

16	15	14	13	12	11	10	9
8	7	6	5	4	3	2	1



CN1

1	2	3	4	5	6	7	8	9	13	20	21	27	23	24	
10	11	12	13	14	15	16	17	18	19	25	26	27	28	29	30

5PAF-AMP→C-2

132	131	130
129	128	127
126	125	124
GR		

(For SK310III, SK310LIII)  
16PAF-AMP→C-2

132	131	130	129	128	127	126	125	124	123	122	121	120
119	118	117	116	115	114	113	112	111	110	109	108	107
106	105	104	103	102	101	100	99	98	97	96	95	94
93	92	91	90	89	88	87	86	85	84	83	82	81
80	79	78	77	76	75	74	73	72	71	70	69	68
67	66	65	64	63	62	61	60	59	58	57	56	55
54	53	52	51	50	49	48	47	46	45	44	43	42
41	40	39	38	37	36	35	34	33	32	31	30	29
28	27	26	25	24	23	22	21	20	19	18	17	16
15	14	13	12	11	10	9	8	7	6	5	4	3
2	1											

(For SK430III, SK430LIII)  
16PAF-AMP→C-2

132	131	130	129	128	127	126	125	124	123	122	121	120
119	118	117	116	115	114	113	112	111	110	109	108	107
106	105	104	103	102	101	100	99	98	97	96	95	94
93	92	91	90	89	88	87	86	85	84	83	82	81
80	79	78	77	76	75	74	73	72	71	70	69	68
67	66	65	64	63	62	61	60	59	58	57	56	55
54	53	52	51	50	49	48	47	46	45	44	43	42
41	40	39	38	37	36	35	34	33	32	31	30	29
28	27	26	25	24	23	22	21	20	19	18	17	16
15	14	13	12	11	10	9	8	7	6	5	4	3
2	1											

12PAF-AMP→C-2

132	131	130	129	128	127	126	125	124	123	122	121	120
119	118	117	116	115	114	113	112	111	110	109	108	107
106	105	104	103	102	101	100	99	98	97	96	95	94
93	92	91	90	89	88	87	86	85	84	83	82	81
80	79	78	77	76	75	74	73	72	71	70	69	68
67	66	65	64	63	62	61	60	59	58	57	56	55
54	53	52	51	50	49	48	47	46	45	44	43	42
41	40	39	38	37	36	35	34	33	32	31	30	29
28	27	26	25	24	23	22	21	20	19	18	17	16
15	14	13	12	11	10	9	8	7	6	5	4	3
2	1											

Fig. 12 C-2 Controller connector pin location and harness connector. However, see the connector from the engaged surface.

(3) Cluster Gauge Controller IN/OUT




Fig. 16 Cluster gauge controller wiring diagram

#### 14) Service Diagnostic Check by Multi Display

It is possible to diagnose the operating status of mechatronics system, and then display the status on the multi-purpose display.


- 1) Keep the buzzer stop switch pressed and turn key switch ON.
- 2) Press the buzzer stop switch 5 times to display.
- 3) And later, the status of 24 items are displayed in order, each time switch is pressed.
- 4) By turning key switch OFF, the display is cleared.

H mode, in engine rotation

The display shown with a range means that the display is not stable.

The figure shows the target value, so, it differs depending on models.

\* Figures are displayed, but the data has no relation.



No.	DIAGNOSIS DISPLAY	CONTENTS OF DISPLAYS	SK310III SK310L/III	SK430III SK430L/III	REMARKS
1	P/No	Controller P/No	2480U393F4	2480U393F5	
2	S1 wtmp	Thermo switch temperature	OPEN	←	
3	S2 oprs	E/G Oil pressure switch	OPEN	←	
4	S3 cpu	Mechatronics IP connector	CLOS	←	
5	S4 smad	S mode select switch	CLOS	←	S mode
			OPEN	←	H.F.C.D mode
6	S5 hmod	H mode select switch	CLOS	←	H mode
			OPEN	←	S.F.C.D mode
7	S6 att	ATT Boost switch	OFF OPEN	OPEN	
			ON CLOS		
8	S7 des	Auto accel pressure switch	OPEN	←	Decel SW ON
			CLOS	←	Decel SW OFF
			CLOS	←	Lever operating
9	S8 bzip	Buzzer stop switch	OPEN	←	
10	S9 jpin	Controller inside switch	OPEN	←	
11	S10 keys	Key switch BR terminal	CLOS	←	
12	S11 lims	Stepping motor limit switch	OPEN	←	
13	S12 boocu	Steering pressure switch	OPEN	←	Lever neutral
			OPEN	←	Steering
14	AD1 accel	Accel potentiometer	40	40	Low
			215	215	High
			2	1	Up
15	AD2 boom	Loading potentiometer	95	97	In
			255	255	Down
16	AD3 mctA	Stepping motor A phase current value	33~38	33~38	
17	AD4 motB	Stepping motor B phase current value	33~38	33~38	
18	AD5 isvP	KPSS solenoid valve current value (Current value measured by controller)	10~12	10~12	E/G Low no load
			20~32	20~32	E/G Low arm relief
			7~8	7~8	E/G High no load
19	AD6 isvB	Loading solenoid current value (Current value measured by controller)	7~8	7~5	E/G High arm relief
			38~47	38~47	
20	11 pump	KPSS solenoid valve current value mA (Controller instructed value)	215~230mA	215~230mA	E/G Low no load
			590~640mA	590~640mA	E/G Low arm relief
			150mA	150mA	E/G High no load
			150mA	150mA	E/G High arm relief
21	12 boom	Loading solenoid current value mA (Controller instructed value)	100mA (500mA)	100mA (800mA)	
22	POS	Stepping motor position	205	210	Low idle
			405	420	High idle
23	r.p.m	E/C revolution	862, 866	862, 508	Low idle
			1826, 1930	2186, 2190	High idle
24	18V	Source voltage 18V or more	OVER	←	

- (5) Explanation of mechatronic system circuit and service diagnosis monitor displays  
(Refer to I/O Chart on page 12 and Service Diagnosis Table on page 16.)

#### ■ KEY SWITCH

- 1) If the key switch (SW-1) is turned off, the voltage between the key terminal M and the C-1 controller terminal B10 becomes 0V.
- 2) The C-1 controller is capable of holding voltage for four seconds after the key switch is turned OFF.
- 3) Therefore, the key switch relay R-5 and the battery relay (R-1) are excited for four seconds via terminal B4; the power is held for four seconds after the key switch is turned OFF.
- 4) "S10 kwys of eleven monitor items" indicates confirmation of the harness between the key switch terminal M and B10.

#### ■ AUTO ACCEL

- 1) The auto accel is turned off if the auto accel switch (SW-9) is released. As the result, the switch terminal KV and the C-1 controller terminal A7 put out negative signals. The controller judges by a negative signal that operation is underway.
- 2) If the auto accel switch is turned to the switch mark side, it is turned ON. If the operating lever is in neutral position and the pressure switch (SW-27) is off, the terminal A7 becomes open by which the decel revolution is set at 1050rpm.
- 3) If the operating lever is operated, the pressure switch is turned on. This turns out a negative signal from the terminal A7; the controller judges by a negative signal that operation is underway. As the result, the auto accel function operates. If the operating lever is in neutral position, a decel revolution is attained four seconds after the operating lever is brought to neutral.
- 4) With "S7 des" of the eight monitor items, the condition of the harness between the auto accel switch and the terminal A7 is displayed.

#### ■ ACCEL POTENTIOMETER AND GOVERNOR MOTOR

- 1) If the accel dial is operated, the potentiometer (SE-4) rotates. The C-1 controller senses input voltage variations through the terminal B2 of the C-1 controller.

- 2) The controller computes the input voltage at B2 and causes the governor motor (M-1) to rotate. It determines the rotating angle of the governor motor by giving a fixed 1.5A current (as pulse signals) to phase A (B14 terminal), phase  $\bar{A}$  (B15 terminal), phase B (B5 terminal) and phase  $\bar{B}$  (B6 terminal). This provides a rotating angle according to an accel dial position.
- 3) The limit switch in the governor motor serves as the basis of an angle at which the governor motor changes from an off to on condition.
- 4) Fault code 2 indicates that the limit switch has operated.  
Fault code 6 indicates that the governor motor is loaded with fixed current.  
Fault code 7 indicates that the governor motor is rotating.
- 5) "S11 lims" of twelve monitor items indicates the condition of the harness between the limit switch and terminal A10.
- 6) "AD1 accel" of fourteen monitor items indicates confirmation of operation of the accel potentiometer.
- 7) "AD3 motA" of sixteen monitor items indicates confirmation of the fixed current load at phase A of the governor motor.
- 8) "AD4 motB" of seventeen monitor items indicates confirmation of the fixed current load at phase B of the governor motor.
- 9) "POS" of twenty-two items indicates confirmation of the rotating angle of the governor motor.
- 10) "rpm" of twenty-three monitor items indicates confirmation of the engine revolution.

#### ■ OPERATION MODE SELECT SWITCH AND GOVERNOR MOTOR

- 1) If the operation mode select switch (SW-10) is in the H-mode, terminal A5 of the C-1 controller senses a negative signal. The controller judges the negative signal as H-mode.
- 2) The governor motor (M-1) drives the governor lever to a position 0.2mm ahead of the Hi Idle set halt.
- 3) In the S-mode, the A4 terminal senses a negative signal by which the governor motor is driven at the S-mode revolution.
- 4) In the FC-mode, terminals A4 and A5 cease to sense the negative signal by which the governor motor is driven at the FC mode revolution.

- 5) In the D-mode, terminal A5 senses a negative signal via a diode, so that the C-1 controller provides the same recognition as the H-mode.
- 6) "S5 smod" of six monitor items indicates confirmation of the harness between terminal 1 of the mode select switch and terminal A5 of the C-1 controller.
- 7) "S4 smod" of five monitor items indicates the confirmation of the harness between terminal 2 of the mode select switch and terminal A4 of the C-1 controller.

However, where different types of control are performed on revolutions, control is performed to select the lower of the revolutions.

#### ■ATT BOOST PRESSURE

- 1) If the ATT boost pressure switch (SW-3) is depressed the ATT boost pressure relay (R-6) is excited. At the same time the terminal A6 of the C-1 controller senses a negative signal.
- 2) The moment the ATT boost relay (R-6) is changed over, the ATT boost pressure mark is displayed on the multi display.
- 3) If terminal A6 of the C-1 controller senses a negative signal, 715mA is put out from terminal B16.
- 4) The 715mA drives the solenoid proportionate reducing valve (PSV-1) by way of the YL harness, the KPSS release switch and the YG harness, thereby providing power shift action (reduced horsepower) of the pump.
- 5) The return harness GrB and the harness YB of the solenoid proportionate reducing valve (PSV-1) are fed back to terminal B7.
- 6) The fault code 5 indicates that the operation of the solenoid proportionate reducing valve has been confirmed.
- 7) "S6 att" of seven monitor items indicates that the harness between the ATT boost pressure switch and terminal A6 has been confirmed.
- 8) "E1 pump" of twenty monitor items indicates a command current value from terminal B16 and the solenoid proportionate reducing valve (PSV-1).
- 9) "AD5 isvp" of eighteen monitor items indicates the feedback current value from the solenoid proportionate reducing valve to terminal B7.

#### ■KPSS RELEASE SWITCH, POWER SHIFT AND ATT BOOST PRESSURE

- 1) If the KPSS release switch (SW-2) is released, the power source 15 arrives at the solenoid proportionate reducing valve (PSV-1) via the resistor (62Ω) to give it a S-mode current value of 330mA.
- 2) The current is reduced to an earth level by way of the solenoid proportionate reducing valve, the GrD harness and the KPSS release switch.
- 3) If the KPSS is not released, the C-1 controller computes a set revolution from the rotating angle of the governor motor.
- 4) In the meantime, an actual revolution value is read from the engine revolution sensor.
- 5) The C-1 controller compares a set revolution with an actual revolution and computes the difference.
- 6) A current value according to the difference is put out from terminal B16 to perform power shift action. If the KPSS is released, power is shifted to the S-mode current level, thereby ceasing to feed back to terminal B7.
- 7) Also, if the KPSS is released, current ceases to flow from the ATT boost pressure relay (R-6) to the earth side, thereby disabling the ATT boost pressure action.

#### ■LOADING MODE POTENTIOMETER (OPTION)

- 1) If swing action is performed, the pressure switch (SW-30) operates which causes terminal A9 of the C-1 controller to sense a negative signal.
- 2) The C-1 controller senses, at terminal B3, an output voltage of the loading mode potentiometer (SE-6).
- 3) The output voltage increases if the potentiometer dial is turned clockwise.
- 4) The C-1 controller computes the input voltage and puts out a control current from terminal B17 so it acts upon the solenoid proportionate reducing valve (PSV-2).
- 5) Also, the control current is fed back to terminal B6 by way of the solenoid proportionate reducing valve and the BP harness.
- 6) "S12 beam" of thirteen monitor items indicates that the harness between the pressure switch and terminal A9, has been confirmed.



- 7) "AD2 boom" of fifteen monitor items indicates that the potentiometer (SE-5) operates.
- 8) "I2 boom" of twenty-one monitor items confirms a command current value from terminal B17.
- 9) "AD6 invB" of nineteen monitor items indicates confirmation of the feedback current value to terminal B8.

■ WATER TEMPERATURE SWITCH AND POWER SHIFT (SK310III SERIES ONLY)

- 1) When the water temperature of the radiator rises at 95°C (203.0°F), the water temperature switch (SW-28) operates. This causes the C-1 controller detects a negative signal at terminal A1. Announcing that a fault has occurred.
- 2) The C-1 controller puts out 330mA from terminal B16. The signal acts upon the electromagnetic proportionate reducing valve (PSV-1) by way of the KPSS release switch and the YR harness and causes power to shift to pick up the S-mode.
- 3) If the monitor item No.2 "S1 wtmp" is indicated, it means that the harness between the water temperature switch and terminal A1 have been confirmed.



### 3. MAIN ELECTRIC EQUIPMENT









#### 3.1 SUMMARY OF MAIN ELECTRIC EQUIPMENT





The main electric equipment are classified into the following ten groups in alphabetical order.

- |                       |          |             |                     |
|-----------------------|----------|-------------|---------------------|
| 1) Controller         | 4) Light | 7) Sensor   | 10) Pressure switch |
| 2) Diode              | 5) Motor | 8) Solenoid |                     |
| 3) Electric Equipment | 6) Relay | 9) Switch   |                     |





class	Item	Name	Part No.		class	Item	Name	Part No.	
Controller	C-1	KPSS Controller	2480U3274 (S-310) FE (SR-420)		Light	L-8	Hour Work Light (L)	2456U105F3	
	C-2	Cluster Controller	2480U371F2			L-9	Room Light	2456Z322F1	
	C-3	Flusher Unit	2480U306		Motor	M-1	Governor Motor	2406U197F4	
	C-4	A/C Amp.	YN32E00014F4			M-2	Wiper Motor	2475R704	
	C-5	Gauge Cluster	2489U276F5			M-3	Washer Motor	2427U900	
				M-4		Starter Motor	ME057900	STD	
				M-5		Alternator	ME049177		
Diode	D-1	Diode	YN21M1001F1		Relay	R-1	Battery Relay	2475R1470F1	
	D-2	Diode	↑			R-2	Starter Relay	YN24SU1002F1	
	D-3	Diode	↑			R-3	Heater Relay	ME067624	
	D-4	Diode	↑			R-4	Safety Relay	ME049233 YN21R1300F1	
	D-5	Diode	2475R132			R-5	Key Switch Relay	YN24S00031F1	
	D-6	Diode	↑			R-6	Relay Assy	YN24E00001F1	
	D-7	Diode	YN24E00001F1			R-7	Heater Cut Relay	YN24S00031F1	
	D-8	Diode	↑			R-8	Intermit Relay	2475R1306	
	D-9	Diode	↑			R-9	2-speed Relay	2479U1290	
	D-10	Diode	↑						
	D-11	Diode	2475R132		Sensor	SE-1	Revolution Sensor	YN21R215 YN21R1300F1	
	D-12	Diode	↑			SE-2	Thermo Sending Unit	2489U258F1	
	D-13	Diode	↑			SE-3	Fuel Sensor	2489U275	
	D-14	Diode	↑			SE-4	Acid Level Potenti	2450R430	
				SE-5		Variable Loading Potenti	2480U376F1		
Electric Equipment	E-1	Furn Box	YN51R00011F2		Solenoid	SV-1	Power Assist Solenoid	2436U1314F3	
	E-5	Horn (High)	2479U1009F1	567M ONLY		SV-2	EC Mode Solenoid	YF35V00009F1	
	E-6	Horn (Low)	2479U1009F2	↑		SV-3	2-speed Travel Solenoid	↑	
	E-7	Keenster	2484R166101			SV-4	Lower Lock Solenoid	↑	
	E-14	Air Horn	2447U2	5K4M ONLY		SV-5	Travel Flow Cut	2436U1314F2	SK10 ONLY
	E-15	Battery	240541478	STD					
Light	L-1	Swing Flusher (L)	2456U104F4		PSV	PSV-1	P.S.V. (KPSS)	2436R384F2	
	L-2	Swing Flusher (R)	2456U104F3			PSV-2	P.S.V. (Variable Loading)	↑	
	L-3	Room Work Light (L)	2456U74F3						
	L-4	Room Work Light (R)	↑						
	L-5	Work Light (L)	2456U110F1						
	L-6	Work Light (R)	↑						
	L-7	Hour Work Light (L)	2456U105F4						







File No. Name of part Part No. Use Applicable Machine	Specification	Description
C-1 KPSS Controller 2480U393F4 KPSS LC03801~ YC01101~		
C-1 KPSS Controller 2480U393F5 KPSS LS00701~ YS00601~	  <p>AMP Type MIC 172049-1</p>  <p>AMP Type Pulse lock connector 1-174491-7</p>	
C-2 Cluster controller 2480U371F2 Cluster gauge LC03801~ YC01101~ LS00701~ YS00601~	 <p>CN1</p>  <p>PARTS NO</p>  <p>CN2</p>  <p>CN3</p>	

File No. Name of part Part No. Use Applicable Machine	Specification	Description						
<p>C-3</p> <p>Controller</p> <p>2480U806</p> <p>Flasher Unit</p> <p>LC08801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Operating temp. range</td> <td>30°C-60°C</td> </tr> <tr> <td>Flashing frequency</td> <td>99±50 c/min</td> </tr> </table>	Rated voltage	DC 24V	Operating temp. range	30°C-60°C	Flashing frequency	99±50 c/min	
Rated voltage	DC 24V							
Operating temp. range	30°C-60°C							
Flashing frequency	99±50 c/min							
<p>C-4</p> <p>Controller</p> <p>YN22E00014P1</p> <p>Amplifier for air-conditioner</p> <p>LC08801~ YC01101~ LS00701~ YS00601~</p>								
<p>C-5</p> <p>Controller</p> <p>2460U276F5</p> <p>Gauge cluster</p> <p>LC08801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Rated voltage</td> <td>24V DC</td> </tr> <tr> <td>Working Voltage Range</td> <td>DC20V~30V</td> </tr> <tr> <td>Working Temp Range</td> <td>20~130°C</td> </tr> </table>	Rated voltage	24V DC	Working Voltage Range	DC20V~30V	Working Temp Range	20~130°C	  <p>VIEW I</p>
Rated voltage	24V DC							
Working Voltage Range	DC20V~30V							
Working Temp Range	20~130°C							



File No. Name of part Part No. Use Applicable Machine	Specification	Description																																																																																				
D-1~4,7~10  Diode  YN02D01001P1  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>7321-9332-60</td> </tr> <tr> <td>Rated current</td> <td>2.5A</td> </tr> </table>	Type	7321-9332-60	Rated current	2.5A																																																																																	
Type	7321-9332-60																																																																																					
Rated current	2.5A																																																																																					
D-5,6,11~14 19,20,21  Diode  2475R:32  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>7321-9332</td> </tr> <tr> <td>Peak reverse voltage</td> <td>400V</td> </tr> <tr> <td>Forward current</td> <td>3A</td> </tr> <tr> <td>Surge current</td> <td>20A</td> </tr> </table>	Type	7321-9332	Peak reverse voltage	400V	Forward current	3A	Surge current	20A																																																																													
Type	7321-9332																																																																																					
Peak reverse voltage	400V																																																																																					
Forward current	3A																																																																																					
Surge current	20A																																																																																					
E-1  Fuse box  YN73E00001F2  Fuse (Main):  LC03801~ YC01101~	<table border="1"> <tr> <td>Type</td> <td>7124-8043</td> </tr> <tr> <td colspan="4">* Fuse capacities and names of circuits</td> </tr> <tr> <th>No.</th> <th>CAPACITY</th> <th>NAME OF CIRCUIT</th> <th>No.</th> <th>CAPACITY</th> <th>NAME OF CIRCUIT</th> </tr> <tr> <td>2</td> <td>5A</td> <td>Nothing</td> <td>12</td> <td>5A</td> <td>Swing flapper</td> </tr> <tr> <td>3</td> <td>5A</td> <td>Nothing</td> <td>13</td> <td>5A</td> <td>Controller blower</td> </tr> <tr> <td>4</td> <td>5A</td> <td>Nothing</td> <td>14</td> <td>20A</td> <td>Wiper, washer</td> </tr> <tr> <td>5</td> <td>20A</td> <td>Blower</td> <td>15</td> <td>20A</td> <td>Blower</td> </tr> <tr> <td>6</td> <td>20A</td> <td>Blower</td> <td>26</td> <td>20A</td> <td>Rear work light</td> </tr> <tr> <td>7</td> <td>20A</td> <td>Blow</td> <td>27</td> <td>20A</td> <td>Work light (right &amp; left)</td> </tr> <tr> <td>8</td> <td>5A</td> <td>Back up</td> <td>28</td> <td>20A</td> <td>Air-conditioner, heater</td> </tr> <tr> <td>9</td> <td>5A</td> <td>Clearer (backup)</td> <td></td> <td></td> <td></td> </tr> <tr> <td>10</td> <td>20A</td> <td>Beam lamp</td> <td>29</td> <td>25A</td> <td>Spare (24V)</td> </tr> <tr> <td>11</td> <td>20A</td> <td>Starter switch</td> <td>30</td> <td>5A</td> <td>Spare (24V)</td> </tr> <tr> <td>12</td> <td>5A</td> <td>Controller (mechanical adjustment)</td> <td></td> <td></td> <td></td> </tr> </table>	Type	7124-8043	* Fuse capacities and names of circuits				No.	CAPACITY	NAME OF CIRCUIT	No.	CAPACITY	NAME OF CIRCUIT	2	5A	Nothing	12	5A	Swing flapper	3	5A	Nothing	13	5A	Controller blower	4	5A	Nothing	14	20A	Wiper, washer	5	20A	Blower	15	20A	Blower	6	20A	Blower	26	20A	Rear work light	7	20A	Blow	27	20A	Work light (right & left)	8	5A	Back up	28	20A	Air-conditioner, heater	9	5A	Clearer (backup)				10	20A	Beam lamp	29	25A	Spare (24V)	11	20A	Starter switch	30	5A	Spare (24V)	12	5A	Controller (mechanical adjustment)										
Type	7124-8043																																																																																					
* Fuse capacities and names of circuits																																																																																						
No.	CAPACITY	NAME OF CIRCUIT	No.	CAPACITY	NAME OF CIRCUIT																																																																																	
2	5A	Nothing	12	5A	Swing flapper																																																																																	
3	5A	Nothing	13	5A	Controller blower																																																																																	
4	5A	Nothing	14	20A	Wiper, washer																																																																																	
5	20A	Blower	15	20A	Blower																																																																																	
6	20A	Blower	26	20A	Rear work light																																																																																	
7	20A	Blow	27	20A	Work light (right & left)																																																																																	
8	5A	Back up	28	20A	Air-conditioner, heater																																																																																	
9	5A	Clearer (backup)																																																																																				
10	20A	Beam lamp	29	25A	Spare (24V)																																																																																	
11	20A	Starter switch	30	5A	Spare (24V)																																																																																	
12	5A	Controller (mechanical adjustment)																																																																																				
E-1  Fuse box  YN73E00001F2  Fuse (Main):  LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>7124-8043</td> </tr> <tr> <td colspan="4">* Fuse capacities and names of circuits</td> </tr> <tr> <th>No.</th> <th>CAPACITY</th> <th>NAME OF CIRCUIT</th> <th>No.</th> <th>CAPACITY</th> <th>NAME OF CIRCUIT</th> </tr> <tr> <td>1</td> <td>5A</td> <td>Nothing</td> <td>12</td> <td>5A</td> <td>Swing flapper</td> </tr> <tr> <td>2</td> <td>5A</td> <td>Nothing</td> <td>13</td> <td>5A</td> <td>Controller blower</td> </tr> <tr> <td>3</td> <td>5A</td> <td>Nothing</td> <td>14</td> <td>20A</td> <td>Wiper, washer</td> </tr> <tr> <td>4</td> <td>15A</td> <td>Nothing</td> <td>15</td> <td>20A</td> <td>Blower</td> </tr> <tr> <td>5</td> <td>15A</td> <td>Nothing</td> <td>16</td> <td>20A</td> <td>Rear work light</td> </tr> <tr> <td>6</td> <td>20A</td> <td>Blow</td> <td>17</td> <td>20A</td> <td>Work light (right &amp; left)</td> </tr> <tr> <td>7</td> <td>5A</td> <td>Air conditioner, overrider</td> <td>18</td> <td>20A</td> <td>Air-conditioner, heater</td> </tr> <tr> <td></td> <td></td> <td>Backlight</td> <td></td> <td></td> <td></td> </tr> <tr> <td>8</td> <td>5A</td> <td>Clearer (backup)</td> <td>19</td> <td>20A</td> <td>Spare (24V)</td> </tr> <tr> <td>9</td> <td>20A</td> <td>Beam lamp</td> <td>20</td> <td>5A</td> <td>Nothing</td> </tr> <tr> <td>10</td> <td>25A</td> <td>Starter switch</td> <td></td> <td></td> <td></td> </tr> <tr> <td>11</td> <td>5A</td> <td>Controller (mechanical adjustment)</td> <td></td> <td></td> <td></td> </tr> </table>	Type	7124-8043	* Fuse capacities and names of circuits				No.	CAPACITY	NAME OF CIRCUIT	No.	CAPACITY	NAME OF CIRCUIT	1	5A	Nothing	12	5A	Swing flapper	2	5A	Nothing	13	5A	Controller blower	3	5A	Nothing	14	20A	Wiper, washer	4	15A	Nothing	15	20A	Blower	5	15A	Nothing	16	20A	Rear work light	6	20A	Blow	17	20A	Work light (right & left)	7	5A	Air conditioner, overrider	18	20A	Air-conditioner, heater			Backlight				8	5A	Clearer (backup)	19	20A	Spare (24V)	9	20A	Beam lamp	20	5A	Nothing	10	25A	Starter switch				11	5A	Controller (mechanical adjustment)				
Type	7124-8043																																																																																					
* Fuse capacities and names of circuits																																																																																						
No.	CAPACITY	NAME OF CIRCUIT	No.	CAPACITY	NAME OF CIRCUIT																																																																																	
1	5A	Nothing	12	5A	Swing flapper																																																																																	
2	5A	Nothing	13	5A	Controller blower																																																																																	
3	5A	Nothing	14	20A	Wiper, washer																																																																																	
4	15A	Nothing	15	20A	Blower																																																																																	
5	15A	Nothing	16	20A	Rear work light																																																																																	
6	20A	Blow	17	20A	Work light (right & left)																																																																																	
7	5A	Air conditioner, overrider	18	20A	Air-conditioner, heater																																																																																	
		Backlight																																																																																				
8	5A	Clearer (backup)	19	20A	Spare (24V)																																																																																	
9	20A	Beam lamp	20	5A	Nothing																																																																																	
10	25A	Starter switch																																																																																				
11	5A	Controller (mechanical adjustment)																																																																																				





File No. Name of part Part No. Use Applicable Machine	Specification	Description												
E-5,6 Horn 2479U1009F1(High) 2479U1009F2(Low) Alarm LC08801~ YC01101-	<table border="1"> <tr><td>Type</td><td></td></tr> <tr><td>Rated voltage</td><td>DC 24V</td></tr> <tr><td>Operated voltage range</td><td>DC22~28V</td></tr> <tr><td>Sound volume</td><td>110±5 dB</td></tr> <tr><td>Basic frequency</td><td>390±20 HZ (High) 350±20 HZ (Low)</td></tr> <tr><td>Insulation resistance</td><td>1MΩ / DC 500V</td></tr> </table>	Type		Rated voltage	DC 24V	Operated voltage range	DC22~28V	Sound volume	110±5 dB	Basic frequency	390±20 HZ (High) 350±20 HZ (Low)	Insulation resistance	1MΩ / DC 500V	 <p>Stamp H High sound (2479U1009F1)FL L Low sound (2479U1009F2)FL</p> <p>Drain 2-Hole</p>
Type														
Rated voltage	DC 24V													
Operated voltage range	DC22~28V													
Sound volume	110±5 dB													
Basic frequency	390±20 HZ (High) 350±20 HZ (Low)													
Insulation resistance	1MΩ / DC 500V													
E-7 Resistor 2484R166D1,D2 Resistor LC08801~ YC01101~ LS00701~ YS00601-	<table border="1"> <tr><td>Type</td><td>CRW MA 30W</td></tr> <tr><td>Nominal resistance value</td><td>D1 62Ω</td></tr> <tr><td></td><td>D2 51Ω</td></tr> </table>	Type	CRW MA 30W	Nominal resistance value	D1 62Ω		D2 51Ω							
Type	CRW MA 30W													
Nominal resistance value	D1 62Ω													
	D2 51Ω													
E-14 Air Horn 2447U2 Alarm LS00701~ YS00601-	<table border="1"> <tr><td>Rated Air-pressure</td><td>3~8kgf/cm<sup>2</sup></td></tr> <tr><td>Sound volume</td><td>115dB</td></tr> <tr><td>Operated temperature range</td><td>-40 ~ +60°C</td></tr> <tr><td>Basic frequency</td><td>555±10Hz 430±10Hz</td></tr> </table>	Rated Air-pressure	3~8kgf/cm <sup>2</sup>	Sound volume	115dB	Operated temperature range	-40 ~ +60°C	Basic frequency	555±10Hz 430±10Hz	 <p>2-11 x 16 hole</p> <p>Apply sealant</p>				
Rated Air-pressure	3~8kgf/cm <sup>2</sup>													
Sound volume	115dB													
Operated temperature range	-40 ~ +60°C													
Basic frequency	555±10Hz 430±10Hz													
E-15 Battery 2484U178(STD) Power source LC08301~ YC01101~ LS00701~ YS00601-	<table border="1"> <tr><td>Parts No.</td><td>2484U178</td></tr> <tr><td>Type</td><td>130F51 (F16D-12)</td></tr> <tr><td>Capacity</td><td>104Ah / 5HR 130Ah / 20HR</td></tr> </table>	Parts No.	2484U178	Type	130F51 (F16D-12)	Capacity	104Ah / 5HR 130Ah / 20HR							
Parts No.	2484U178													
Type	130F51 (F16D-12)													
Capacity	104Ah / 5HR 130Ah / 20HR													














File No. Name of part Part No. Use Applicable Machine	Specification	Description						
<p>L-1.2</p> <p>Light</p> <p>2456U104F4 (L.H) 2456U104F3 (R.H)</p> <p>Swing flasher</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Type</td> <td></td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Bulb</td> <td>25W × 2 × 2 pairs/machine</td> </tr> </table>	Type		Rated voltage	24V	Bulb	25W × 2 × 2 pairs/machine	
Type								
Rated voltage	24V							
Bulb	25W × 2 × 2 pairs/machine							
<p>L-3.4</p> <p>Light</p> <p>2456U74F3</p> <p>Boom working light</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td colspan="2">HALOGEN SEALED BEAM DATA</td> </tr> <tr> <td>Watts</td> <td>70</td> </tr> <tr> <td>Volts</td> <td>24</td> </tr> </table>	HALOGEN SEALED BEAM DATA		Watts	70	Volts	24	
HALOGEN SEALED BEAM DATA								
Watts	70							
Volts	24							
<p>L-5,6</p> <p>Light</p> <p>2456U116F1</p> <p>Working light</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td colspan="2">HALOGEN SEALED BEAM DATA</td> </tr> <tr> <td>Watts</td> <td>70</td> </tr> <tr> <td>Volts</td> <td>24</td> </tr> </table>	HALOGEN SEALED BEAM DATA		Watts	70	Volts	24	
HALOGEN SEALED BEAM DATA								
Watts	70							
Volts	24							
<p>L-7,8</p> <p>Light</p> <p>2456U105F4 (L.H) 2456U105F3 (R.H)</p> <p>Rear working light</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Type</td> <td></td> </tr> <tr> <td>Rated voltage</td> <td>10; 24V</td> </tr> <tr> <td>Bulb</td> <td>25W × 2 × 2 pairs/machine</td> </tr> </table>	Type		Rated voltage	10; 24V	Bulb	25W × 2 × 2 pairs/machine	
Type								
Rated voltage	10; 24V							
Bulb	25W × 2 × 2 pairs/machine							








File No. Name of part Part No. Use Applicable Machine	Specification	Description												
<p>L-9</p> <p>Light</p> <p>2456Z322F1</p> <p>Roofs light</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>voltage</td> <td>DC 24V</td> </tr> <tr> <td>Bulb</td> <td>2W X 1</td> </tr> </table>	voltage	DC 24V	Bulb	2W X 1									
voltage	DC 24V													
Bulb	2W X 1													
<p>M-1</p> <p>Motor</p> <p>2406U197F4</p> <p>Governor</p> <p>LC03501~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Drive voltage</td> <td>DC24V</td> </tr> <tr> <td>Current</td> <td>1.5A / Phase</td> </tr> <tr> <td>Number of phases</td> <td>4 Phases</td> </tr> <tr> <td>Excitation method</td> <td>2-phase excitation</td> </tr> <tr> <td>Step angle</td> <td>0.086° (output shaft)</td> </tr> <tr> <td>IM resistance of coil</td> <td>5.7Ω ± 10% (at 25°C)</td> </tr> </table>	Drive voltage	DC24V	Current	1.5A / Phase	Number of phases	4 Phases	Excitation method	2-phase excitation	Step angle	0.086° (output shaft)	IM resistance of coil	5.7Ω ± 10% (at 25°C)	
Drive voltage	DC24V													
Current	1.5A / Phase													
Number of phases	4 Phases													
Excitation method	2-phase excitation													
Step angle	0.086° (output shaft)													
IM resistance of coil	5.7Ω ± 10% (at 25°C)													
<p>M-2</p> <p>Motor</p> <p>2479R704</p> <p>Wiper</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Type</td> <td>Motor OFF</td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> </table> <p>Connections diagram</p>	Type	Motor OFF	Rated voltage	24V									
Type	Motor OFF													
Rated voltage	24V													
<p>M-3</p> <p>Motor</p> <p>2427U900S2</p> <p>Washer</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Tank capacity</td> <td>9.2ℓ (0.6H gal)</td> </tr> </table>	Rated voltage	24V	Tank capacity	9.2ℓ (0.6H gal)									
Rated voltage	24V													
Tank capacity	9.2ℓ (0.6H gal)													





File No. Name of part Part No. Use Applicable Machine	Specification	Description						
<p>M-4</p> <p>Motor (5.5KW)</p> <p>ME067990</p> <p>Starter (STD)</p> <p>LC09801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Maker P.No</td> <td>ME067990</td> </tr> <tr> <td>Rated Voltage</td> <td>24V</td> </tr> <tr> <td>Output</td> <td>5.5KW</td> </tr> </table>	Maker P.No	ME067990	Rated Voltage	24V	Output	5.5KW	
Maker P.No	ME067990							
Rated Voltage	24V							
Output	5.5KW							
<p>M-5</p> <p>Alternator</p> <p>ME049177</p> <p>Generator</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Type</td> <td>Alternating current</td> </tr> <tr> <td>Rated Voltage</td> <td>24V</td> </tr> <tr> <td>Output</td> <td>30A (600W)</td> </tr> </table>	Type	Alternating current	Rated Voltage	24V	Output	30A (600W)	
Type	Alternating current							
Rated Voltage	24V							
Output	30A (600W)							

File No. Name of part Part No. Use Applicable Machine	Specification	Description												
<p>R-1</p> <p>Relay</p> <p>2479R1470F1</p> <p>Battery</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Rated voltage / current</td> <td>At start 24V 300A (30sec.) At charge 28V 120A 1hour/normal</td> </tr> <tr> <td>Exciting current</td> <td>0.4A or below / 24V</td> </tr> <tr> <td>Contact pressure</td> <td>2kg or over</td> </tr> <tr> <td>Closing voltage</td> <td>15V or over</td> </tr> <tr> <td>Opening voltage</td> <td>4V or over</td> </tr> <tr> <td>Insulation resistance</td> <td>1MG or over / 500V megger</td> </tr> </table>	Rated voltage / current	At start 24V 300A (30sec.) At charge 28V 120A 1hour/normal	Exciting current	0.4A or below / 24V	Contact pressure	2kg or over	Closing voltage	15V or over	Opening voltage	4V or over	Insulation resistance	1MG or over / 500V megger	<p>SECONDARY SIDE      PRIMARY SIDE</p>  <p>YAZAKI CONNECTOR 7923-3020</p> <p>SUMITOMO CONNECTOR 5187-2311</p>
Rated voltage / current	At start 24V 300A (30sec.) At charge 28V 120A 1hour/normal													
Exciting current	0.4A or below / 24V													
Contact pressure	2kg or over													
Closing voltage	15V or over													
Opening voltage	4V or over													
Insulation resistance	1MG or over / 500V megger													
<p>R-2</p> <p>Relay</p> <p>ME050939</p> <p>YN24SL1002P1</p> <p>Starter</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Maker P/No.</td> <td>ME050939</td> </tr> </table>	Maker P/No.	ME050939	 <p>STARTER</p>										
Maker P/No.	ME050939													
<p>R-3</p> <p>Relay</p> <p>ME067624</p> <p>Heater</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Maker P/No.</td> <td>ME067624</td> </tr> <tr> <td>Rated voltage &amp; current</td> <td>DC24V 2.5A</td> </tr> <tr> <td>Power</td> <td>61A</td> </tr> </table>	Maker P/No.	ME067624	Rated voltage & current	DC24V 2.5A	Power	61A	 <p>CB104</p> <p>M6x1.0</p>						
Maker P/No.	ME067624													
Rated voltage & current	DC24V 2.5A													
Power	61A													
<p>R-4</p> <p>Relay</p> <p>ME049233</p> <p>YN24SU1001P1</p> <p>Voltage sensing (Safety relay)</p> <p>LC03801~ YC01101~ LS00701~ YS00601~</p>	<table border="1"> <tr> <td>Maker P/No.</td> <td>ME049233</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> </table>	Maker P/No.	ME049233	Rated voltage	DC 24V	 <p>MITSUBISHI CONNECTOR MHR052397</p> <p>ME049233</p> <p>W-L-S      E-G-S</p> <p>W-G-R      P-W-Y</p>								
Maker P/No.	ME049233													
Rated voltage	DC 24V													





File No. Name of part Part No. Use Applicable Machine	Specification	Description								
R-5,7  Relay  YN24S00001P1  Key switch Heater cut  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Maker's part No.</td> <td>488 006 8010</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V/10A</td> </tr> <tr> <td>Insulation resistance</td> <td>More than 1MΩ/500V megger</td> </tr> </table>	Maker's part No.	488 006 8010	Rated voltage	DC 24V/10A	Insulation resistance	More than 1MΩ/500V megger			
Maker's part No.	488 006 8010									
Rated voltage	DC 24V/10A									
Insulation resistance	More than 1MΩ/500V megger									
R-6  Relay  YN24E00001P1  Relay Assy.  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> </table> <p>CIRCUIT DIAGRAM</p> 	Rated voltage	DC 24V							
Rated voltage	DC 24V									
R-8  Relay  2479R1366  Intermit relay  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Manufacturers mfg. No.</td> <td>8-880010-4187</td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Intermittent action</td> <td>Wiper action; 1 cycle, 3 second pause</td> </tr> <tr> <td>Continuous action</td> <td>—</td> </tr> </table>	Manufacturers mfg. No.	8-880010-4187	Rated voltage	24V	Intermittent action	Wiper action; 1 cycle, 3 second pause	Continuous action	—	
Manufacturers mfg. No.	8-880010-4187									
Rated voltage	24V									
Intermittent action	Wiper action; 1 cycle, 3 second pause									
Continuous action	—									
R-9  Relay  2479U129U  2 speed travel  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td></td> </tr> <tr> <td>Operating voltage range</td> <td>20~36V</td> </tr> <tr> <td>Relay capacity</td> <td>A</td> </tr> </table>	Type		Operating voltage range	20~36V	Relay capacity	A			
Type										
Operating voltage range	20~36V									
Relay capacity	A									






File No. Name of part Part No. Use Applicable Machine	Specification	Description															
SE-1  Sensor  MC845235  E/G revolution  LC03801~ YC01101~ LS00701~ YS00601~	 <p style="text-align: center;">Output 2V or more</p>	 <p>CONNECTOR YAZAKI MR28873 SCOTT PIPPL-V CONNECTOR MITSUBISHI 7018-3020 3PAM</p>															
SE-2  Sensor  2489U266F1  Thermo sending unit  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="418 805 930 1054"> <tr> <td>Type</td> <td colspan="2">51400 KW08H0</td> </tr> <tr> <td>Type</td> <td colspan="2">Thermister element</td> </tr> <tr> <td>Electric performance</td> <td colspan="2"></td> </tr> <tr> <td>Temperature (°C)</td> <td>85±0.2 (149.0±0.4°F)</td> <td>115±0.3 (239.0±1.1°F)</td> </tr> <tr> <td>Resistance value (Ω)</td> <td>1760±204</td> <td>384±15</td> </tr> </table>	Type	51400 KW08H0		Type	Thermister element		Electric performance			Temperature (°C)	85±0.2 (149.0±0.4°F)	115±0.3 (239.0±1.1°F)	Resistance value (Ω)	1760±204	384±15	
Type	51400 KW08H0																
Type	Thermister element																
Electric performance																	
Temperature (°C)	85±0.2 (149.0±0.4°F)	115±0.3 (239.0±1.1°F)															
Resistance value (Ω)	1760±204	384±15															
SE-3  Sensor  2489U276  Fuel level  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="418 1236 930 1553"> <thead> <tr> <th colspan="2">Plant operating standard</th> </tr> <tr> <th>Float</th> <th>Resistance value Ω</th> </tr> </thead> <tbody> <tr> <td>FULL</td> <td><math>10 \frac{10.1}{0.5}</math></td> </tr> <tr> <td>3/4</td> <td>(19)</td> </tr> <tr> <td>1/2</td> <td>32±3</td> </tr> <tr> <td>1/4</td> <td>(49.5)</td> </tr> <tr> <td>EMPTY</td> <td><math>90 \frac{10.1}{0.5}</math></td> </tr> </tbody> </table> <p>FUEL METER</p> 	Plant operating standard		Float	Resistance value Ω	FULL	$10 \frac{10.1}{0.5}$	3/4	(19)	1/2	32±3	1/4	(49.5)	EMPTY	$90 \frac{10.1}{0.5}$		
Plant operating standard																	
Float	Resistance value Ω																
FULL	$10 \frac{10.1}{0.5}$																
3/4	(19)																
1/2	32±3																
1/4	(49.5)																
EMPTY	$90 \frac{10.1}{0.5}$																
		 <p style="text-align: center;">VIEW A</p>															

















File No. Name of part Part No. Use Applicable Machine	Specification	Description										
SE-4  Sensor  2480R430  Accel lever potentio  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>6V</td> </tr> <tr> <td>Total resistance</td> <td>2K<math>\Omega</math></td> </tr> <tr> <td>Effective electric angle</td> <td>90°</td> </tr> <tr> <td>Number of Notch</td> <td>10</td> </tr> </table> <p>VOLTAGE (V) vs. ANGLE (°)</p> 	Rated voltage	6V	Total resistance	2K $\Omega$	Effective electric angle	90°	Number of Notch	10	 <p>3PAM-090 SUMITOMO 6187-3231 TERMINAL 1500-0105 WIRESAL 7160-5234</p>		
Rated voltage	6V											
Total resistance	2K $\Omega$											
Effective electric angle	90°											
Number of Notch	10											
SE-5  Sensor  3480U376F1  Variable loading potentio  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>WALSW 2K<math>\Omega</math>K</td> </tr> <tr> <td>Power rating</td> <td>0.75W</td> </tr> <tr> <td>Mechanical rotating angle</td> <td>150° ± 5°</td> </tr> <tr> <td>Electrical rotating angle</td> <td>140° ± 5°</td> </tr> <tr> <td>Insulation resistance</td> <td>100M<math>\Omega</math> or more (DC 500V megger)</td> </tr> </table>	Type	WALSW 2K $\Omega$ K	Power rating	0.75W	Mechanical rotating angle	150° ± 5°	Electrical rotating angle	140° ± 5°	Insulation resistance	100M $\Omega$ or more (DC 500V megger)	 <p>CLICK MECHANISM (11 STEPS) CONNECTOR SUMITOMO 6187-3231</p> <p>STARTING POINT</p> <p>1: GND AV × 0.5F 2: OUT AV × 0.5F 3: VCC AV × 0.9C</p> <p>VIEW A</p>
Type	WALSW 2K $\Omega$ K											
Power rating	0.75W											
Mechanical rotating angle	150° ± 5°											
Electrical rotating angle	140° ± 5°											
Insulation resistance	100M $\Omega$ or more (DC 500V megger)											
SV-1  Solenoid  2486L1314F3  Power boost  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Power consumption</td> <td>12W</td> </tr> <tr> <td>Working pressure</td> <td>130 kgf/cm<sup>2</sup></td> </tr> <tr> <td>Max. flowrate</td> <td>162 l/min (at P port)</td> </tr> </table> 	Rated voltage	DC 24V	Power consumption	12W	Working pressure	130 kgf/cm <sup>2</sup>	Max. flowrate	162 l/min (at P port)	 <p>SUMITOMO 090 CONNECTOR M(2P) HOUSING M(6187-2311) TERMINAL (1500-0105)</p>		
Rated voltage	DC 24V											
Power consumption	12W											
Working pressure	130 kgf/cm <sup>2</sup>											
Max. flowrate	162 l/min (at P port)											
SV-2,3,4  Solenoid  YN36V00009F1  PC Mode 2-speed travel Lever lock  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Working pressure</td> <td>85 kgf/cm<sup>2</sup></td> </tr> </table>  <p>SYMBOL</p>	Rated voltage	DC 24V	Working pressure	85 kgf/cm <sup>2</sup>							
Rated voltage	DC 24V											
Working pressure	85 kgf/cm <sup>2</sup>											








File No. Name of part Part No. Use Applicable Machine	Specification	Description												
SV-5 Solenoid 2436U1814F2 Travel Flow Cut LC03801- YC01101~	<table border="1" data-bbox="416 365 911 546"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Power consumption</td> <td>12W</td> </tr> <tr> <td>Working pressure</td> <td>140 kgf/cm<sup>2</sup></td> </tr> <tr> <td>Max. flowrate</td> <td>102 l/min (at P port)</td> </tr> </table> <div data-bbox="571 569 724 739" style="text-align: center;">  <p>Circuit</p> </div>	Rated voltage	DC 24V	Power consumption	12W	Working pressure	140 kgf/cm <sup>2</sup>	Max. flowrate	102 l/min (at P port)	 <p>SUMITOMO 090 CONNECTOR M12P; HOUSING M(6187-2311) TERMINAL 11500-01051</p> <p>O RING SEAL</p>				
Rated voltage	DC 24V													
Power consumption	12W													
Working pressure	140 kgf/cm <sup>2</sup>													
Max. flowrate	102 l/min (at P port)													
PSV-1.2 PSV 2436R584F2 KPSS Variable Loading LC03801- YC01101~ LS00701- YS00601~	<table border="1" data-bbox="416 796 911 1079"> <tr> <td>Type</td> <td>KDEE-3K</td> </tr> <tr> <td>Max. working pressure (P port)</td> <td>140 kgf/cm<sup>2</sup></td> </tr> <tr> <td>Max. secondary pressure (A port)</td> <td>40 kgf/cm<sup>2</sup></td> </tr> <tr> <td>Max. flow</td> <td>6 l/min</td> </tr> <tr> <td>Rated current</td> <td>0.8A</td> </tr> <tr> <td>Coil resistance</td> <td>13.6Ω (20°C)</td> </tr> </table> <div data-bbox="512 1090 807 1204" style="text-align: center;">  <p>SYMBOL</p> </div>	Type	KDEE-3K	Max. working pressure (P port)	140 kgf/cm <sup>2</sup>	Max. secondary pressure (A port)	40 kgf/cm <sup>2</sup>	Max. flow	6 l/min	Rated current	0.8A	Coil resistance	13.6Ω (20°C)	 <p>SUMITOMO F-W090 CONNECTOR (water proof) M12P HOUSING 6181-0070 TERMINAL 1500-0105</p>
Type	KDEE-3K													
Max. working pressure (P port)	140 kgf/cm <sup>2</sup>													
Max. secondary pressure (A port)	40 kgf/cm <sup>2</sup>													
Max. flow	6 l/min													
Rated current	0.8A													
Coil resistance	13.6Ω (20°C)													



File No. Name of part Part No. Use Applicable Machine	Specification	Description																																																
SW-1 Switch YN50S00002P1 Key LC03801~ YC01101~ LS00701~ YS00601~	Connection table <table border="1" data-bbox="427 392 877 672"> <tr> <td></td> <td>T</td> <td>B</td> <td>G<sub>1</sub></td> <td>G<sub>2</sub></td> <td>ACC</td> <td>M</td> <td>ST</td> </tr> <tr> <td>H</td> <td>○</td> <td>○</td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>OFF</td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> <td></td> </tr> <tr> <td>ACC</td> <td>○</td> <td>—</td> <td>—</td> <td>○</td> <td></td> <td></td> <td></td> </tr> <tr> <td>ON</td> <td>○</td> <td>—</td> <td>—</td> <td>○</td> <td>○</td> <td></td> <td></td> </tr> <tr> <td>START</td> <td>○</td> <td>—</td> <td>—</td> <td>○</td> <td>○</td> <td>○</td> <td></td> </tr> </table>		T	B	G <sub>1</sub>	G <sub>2</sub>	ACC	M	ST	H	○	○						OFF								ACC	○	—	—	○				ON	○	—	—	○	○			START	○	—	—	○	○	○		
	T	B	G <sub>1</sub>	G <sub>2</sub>	ACC	M	ST																																											
H	○	○																																																
OFF																																																		
ACC	○	—	—	○																																														
ON	○	—	—	○	○																																													
START	○	—	—	○	○	○																																												
SW-2 Switch 2479Z1447 KPSS Release LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 772 893 817"> <tr> <td>Type</td> <td>S-32</td> </tr> </table>	Type	S-32																																															
Type	S-32																																																	
SW-3 Switch YN03M01164P1 ATT. boost LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 1198 893 1243"> <tr> <td>Type</td> <td>Buried in right grip</td> </tr> </table>	Type	Buried in right grip																																															
Type	Buried in right grip																																																	
SW-4 Switch YN03M01088P1 Travel 1,2-speed LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 1635 893 1680"> <tr> <td>Type</td> <td>Buried in travel lever</td> </tr> </table>	Type	Buried in travel lever																																															
Type	Buried in travel lever																																																	





File No. Name of part Part No. Use Applicable Machine	Specification	Description																													
SW-5 Switch YN50S01001P1 Lever lock LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 347 901 403"> <tr> <td>Type</td> <td>Omron D4MC-502II</td> </tr> </table> <p data-bbox="438 459 646 481">CONNECTION TABLE</p> 	Type	Omron D4MC-502II	 <p data-bbox="1085 672 1420 716">YAZAKI 2P HOUSING 7122-222B TERMINAL 7114-2020</p>																											
Type	Omron D4MC-502II																														
SW-6 Switch YN03M01165P1 Horn LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 772 901 828"> <tr> <td>Type</td> <td>Burled in left grip</td> </tr> </table>	Type	Burled in left grip	 <p data-bbox="917 974 1332 1064">SUMITOMO DENSO HOUSING ITEM No. : 6050-1081 (2P MALE) SUMITOMO DENSO TERMINAL ITEM No. : 823U-42B2</p>																											
Type	Burled in left grip																														
SW-7 Air-conditioner switch 24100275S3 (YN20M0108RP1) Air-conditioner LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 1198 901 1254"> <tr> <td>Type</td> <td>58580-4D160</td> </tr> </table>	Type	58580-4D160	<p data-bbox="949 1198 1340 1243">BLOWOUT HOLE SELECT SWITCH    INNER / OUTER AIR SELECT SWITCH</p>  <p data-bbox="1268 1288 1444 1332">BLOWOUT TEMP. SET SWITCH</p> <p data-bbox="981 1568 1324 1590">BLOWER SWITCH    A/C SWITCH</p>																											
Type	58580-4D160																														
SW-8 Heater switch 2479U325 Heater Option LC03801~ YC01101~ LS00701~ YS00601~	<table border="1" data-bbox="391 1624 901 1736"> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Load used</td> <td>135W DC motor</td> </tr> </table> <p data-bbox="470 1769 710 1792">CONNECTION TABLE</p> <table border="1" data-bbox="470 1803 805 1993"> <tr> <td></td> <td>B</td> <td>C</td> <td>Lo</td> <td>Hi</td> </tr> <tr> <td></td> <td></td> <td>80W</td> <td>52W</td> <td>135W</td> </tr> <tr> <td>OFF</td> <td>○</td> <td></td> <td></td> <td></td> </tr> <tr> <td>I</td> <td>○</td> <td>○</td> <td>○</td> <td></td> </tr> <tr> <td>II</td> <td>○</td> <td>○</td> <td></td> <td>○</td> </tr> </table>	Rated voltage	DC 24V	Load used	135W DC motor		B	C	Lo	Hi			80W	52W	135W	OFF	○				I	○	○	○		II	○	○		○	 <p data-bbox="1220 1780 1444 1825">HOUSING 172133-4(G) TERMINAL 170540-1</p>
Rated voltage	DC 24V																														
Load used	135W DC motor																														
	B	C	Lo	Hi																											
		80W	52W	135W																											
OFF	○																														
I	○	○	○																												
II	○	○		○																											

File No. Name of part Part No. Use Applicable Machine	Specification		Description							
SW-9 Switch 2479U1190F7 Auto accel LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Switch mechanism</td> <td>Center spring return</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ or below / DC 500V megger</td> </tr> <tr> <td>Switch mark</td> <td>            Auto accel. action            Auto accel. release         </td> </tr> </table>	Switch mechanism	Center spring return	Rated voltage	DC 24V	Insulation resistance	1MΩ or below / DC 500V megger	Switch mark	 Auto accel. action Auto accel. release	 <p>CONNECTOR (with lock) YAZAKI 7122-2229 equivalent</p>
Switch mechanism	Center spring return									
Rated voltage	DC 24V									
Insulation resistance	1MΩ or below / DC 500V megger									
Switch mark	 Auto accel. action Auto accel. release									
SW-10 Switch 2479U1348F2 Mode select LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>2479U1348F2</td> </tr> <tr> <td>Number of select positions</td> <td>4 (R, S, PC, D)</td> </tr> <tr> <td>Full rotation angle</td> <td>135°</td> </tr> <tr> <td>Mode position</td> <td>  </td> </tr> </table>	Type	2479U1348F2	Number of select positions	4 (R, S, PC, D)	Full rotation angle	135°	Mode position		 <p>6P MALE YAZAKI CN CONNECTOR 7122-2252</p> <p>YAZAKI 7122-2446</p>
Type	2479U1348F2									
Number of select positions	4 (R, S, PC, D)									
Full rotation angle	135°									
Mode position										
SW-11 Switch 2479U1190F19 Swing flasher LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Switch mechanism</td> <td>Alternate</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ or more / DC 500V megger</td> </tr> <tr> <td>Switch mark</td> <td>            Swing flasher         </td> </tr> </table>	Switch mechanism	Alternate	Rated voltage	DC 24V	Insulation resistance	1MΩ or more / DC 500V megger	Switch mark	 Swing flasher	 <p>CONNECTOR (with lock) YAZAKI 7122-2228 equivalent</p>
Switch mechanism	Alternate									
Rated voltage	DC 24V									
Insulation resistance	1MΩ or more / DC 500V megger									
Switch mark	 Swing flasher									
SW-12 Switch 2479U1578F1 Working light LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>Alternate</td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Switch mark</td> <td>  </td> </tr> </table>	Type	Alternate	Rated voltage	24V	Switch mark		 <p>CONNECTOR (with lock) YAZAKI 7122-2237-90 equivalent</p>		
Type	Alternate									
Rated voltage	24V									
Switch mark										

File No. Name of part Part No. Use Applicable Machine	Specification	Description																	
SW-13  Switch  2479H1191F1  Buzzer stop Time adjust  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>Under spring return</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ or over / DC 500V megger</td> </tr> <tr> <td>Switch mark</td> <td>            ① Buzzer stop            ② Clock         </td> </tr> </table>	Type	Under spring return	Rated voltage	DC 24V	Insulation resistance	1MΩ or over / DC 500V megger	Switch mark	 ① Buzzer stop ② Clock	CONNECTOR (with lock) YAZAKI 7122~2227 equivalent Red (R) 									
Type	Under spring return																		
Rated voltage	DC 24V																		
Insulation resistance	1MΩ or over / DC 500V megger																		
Switch mark	 ① Buzzer stop ② Clock																		
SW-14  Switch  2479U1278F2  Wiper & Washer  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td></td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Voltage drop</td> <td>0.1V or below (under rated condition)</td> </tr> <tr> <td>Insulation resistance</td> <td>200MΩ (1K) 500V megger (between insulated terminals and between terminals and frame)</td> </tr> <tr> <td>Rotating torque</td> <td>0.8±0.5kgfcm (0.0879±0.0512 ft-lbs)</td> </tr> <tr> <td>Noted item</td> <td>           Between P and L;            Between B and I;            intermittent relay output            Between B and II;            Between B1 and W;            washer motor         </td> </tr> </table>	Type		Rated voltage	24V	Voltage drop	0.1V or below (under rated condition)	Insulation resistance	200MΩ (1K) 500V megger (between insulated terminals and between terminals and frame)	Rotating torque	0.8±0.5kgfcm (0.0879±0.0512 ft-lbs)	Noted item	Between P and L; Between B and I; intermittent relay output Between B and II; Between B1 and W; washer motor	 CONNECTOR (with lock) YAZAKI 7122~2262 equivalent 					
Type																			
Rated voltage	24V																		
Voltage drop	0.1V or below (under rated condition)																		
Insulation resistance	200MΩ (1K) 500V megger (between insulated terminals and between terminals and frame)																		
Rotating torque	0.8±0.5kgfcm (0.0879±0.0512 ft-lbs)																		
Noted item	Between P and L; Between B and I; intermittent relay output Between B and II; Between B1 and W; washer motor																		
SW-15  Switch  2479U1190F16  Buzzer stop (Travel alarm)  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>Alternate</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ or more / 500V megger</td> </tr> <tr> <td colspan="2" style="text-align: center;">           CONNECTION  <table border="1"> <thead> <tr> <th>Terminal</th> <th>L</th> <th>RW</th> </tr> </thead> <tbody> <tr> <td>Switch OFF</td> <td></td> <td></td> </tr> <tr> <td>Switch ON</td> <td>○</td> <td>○</td> </tr> </tbody> </table> </td> </tr> </table>	Type	Alternate	Rated voltage	DC 24V	Insulation resistance	1MΩ or more / 500V megger	CONNECTION <table border="1"> <thead> <tr> <th>Terminal</th> <th>L</th> <th>RW</th> </tr> </thead> <tbody> <tr> <td>Switch OFF</td> <td></td> <td></td> </tr> <tr> <td>Switch ON</td> <td>○</td> <td>○</td> </tr> </tbody> </table>		Terminal	L	RW	Switch OFF			Switch ON	○	○	CONNECTOR (with lock) YAZAKI 7122~2228 equivalent Red (R) 
Type	Alternate																		
Rated voltage	DC 24V																		
Insulation resistance	1MΩ or more / 500V megger																		
CONNECTION <table border="1"> <thead> <tr> <th>Terminal</th> <th>L</th> <th>RW</th> </tr> </thead> <tbody> <tr> <td>Switch OFF</td> <td></td> <td></td> </tr> <tr> <td>Switch ON</td> <td>○</td> <td>○</td> </tr> </tbody> </table>		Terminal	L	RW	Switch OFF			Switch ON	○	○									
Terminal	L	RW																	
Switch OFF																			
Switch ON	○	○																	

File No. Name of part Part No. Use Applicable Machine	Specification	Description								
SW-18 (OPT.)  Switch  2479L1190F21  Extra breaker  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>Alternate</td> </tr> <tr> <td>Rated voltage</td> <td>DC 24V</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ or over (DC 500V megger)</td> </tr> <tr> <td>Switch mark</td> <td>EXTRA</td> </tr> </table>	Type	Alternate	Rated voltage	DC 24V	Insulation resistance	1MΩ or over (DC 500V megger)	Switch mark	EXTRA	
Type	Alternate									
Rated voltage	DC 24V									
Insulation resistance	1MΩ or over (DC 500V megger)									
Switch mark	EXTRA									
SW-20  Switch  MC840219  E/G oil pressure  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Maker P. No</td> <td>MC840219</td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Open circuit oil pres.</td> <td>0.5kgf/cm<sup>2</sup> MIN</td> </tr> <tr> <td>Contact type</td> <td>Normally closed</td> </tr> </table>	Maker P. No	MC840219	Rated voltage	24V	Open circuit oil pres.	0.5kgf/cm <sup>2</sup> MIN	Contact type	Normally closed	
Maker P. No	MC840219									
Rated voltage	24V									
Open circuit oil pres.	0.5kgf/cm <sup>2</sup> MIN									
Contact type	Normally closed									
SW-21  Switch  ME054661  E/G oil filter  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Maker P. No</td> <td>ME054661</td> </tr> </table>	Maker P. No	ME054661							
Maker P. No	ME054661									
SW-22  Switch  2446R336S11  Air filter  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Maker parts No</td> <td>80001-141</td> </tr> </table>	Maker parts No	80001-141							
Maker parts No	80001-141									

File No. Name of part Part No. Use Applicable Machine	Specification	Description										
SW-23 Switch YN02PU1003P1 E/C water Temp. (105°C (221.0°F)) LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Maker P.No.</td> <td>ME009810</td> </tr> </table>	Maker P.No.	ME009810									
Maker P.No.	ME009810											
SW-24 Switch 2427U203S6 E/C coolant level LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Sub tank</td> <td>           Total water volume            Full 3.6ℓ (0.90gal)            1.1ℓ 1.6ℓ (0.40gal)            LOW level 0.43ℓ (0.11gal)         </td> </tr> <tr> <td>Switch location</td> <td>Remaining liquid level 0.43 ± 0.14 (0.11 ± 0.026gal)</td> </tr> <tr> <td>Contact type</td> <td>Normally closed</td> </tr> </table>	Sub tank	Total water volume Full 3.6ℓ (0.90gal) 1.1ℓ 1.6ℓ (0.40gal) LOW level 0.43ℓ (0.11gal)	Switch location	Remaining liquid level 0.43 ± 0.14 (0.11 ± 0.026gal)	Contact type	Normally closed					
Sub tank	Total water volume Full 3.6ℓ (0.90gal) 1.1ℓ 1.6ℓ (0.40gal) LOW level 0.43ℓ (0.11gal)											
Switch location	Remaining liquid level 0.43 ± 0.14 (0.11 ± 0.026gal)											
Contact type	Normally closed											
SW-25 Switch MC840577 E/C oil level LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Mitsubishi part No.</td> <td>MC040577</td> </tr> <tr> <td>Rated voltage</td> <td>24V</td> </tr> <tr> <td>Rated current</td> <td>0.3A or below</td> </tr> <tr> <td>Contact type</td> <td>Normally closed</td> </tr> </table>	Mitsubishi part No.	MC040577	Rated voltage	24V	Rated current	0.3A or below	Contact type	Normally closed	NIPPON KOKU DENSI PART No. 120-1832-000 W/H052355 		
Mitsubishi part No.	MC040577											
Rated voltage	24V											
Rated current	0.3A or below											
Contact type	Normally closed											
SW-26 Switch 2459R303F1 Hyd. oil level LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Type</td> <td>471931-2680</td> </tr> <tr> <td>Contact resistance</td> <td>Less than 500mΩ (Between connector terminal and body)</td> </tr> <tr> <td>Insulation resistance</td> <td>1MΩ More than 100 260V when switch is OFF)</td> </tr> <tr> <td>Switch capacity</td> <td>Less than 0.3A</td> </tr> <tr> <td>Other</td> <td>Do not use one that dropped</td> </tr> </table>	Type	471931-2680	Contact resistance	Less than 500mΩ (Between connector terminal and body)	Insulation resistance	1MΩ More than 100 260V when switch is OFF)	Switch capacity	Less than 0.3A	Other	Do not use one that dropped	
Type	471931-2680											
Contact resistance	Less than 500mΩ (Between connector terminal and body)											
Insulation resistance	1MΩ More than 100 260V when switch is OFF)											
Switch capacity	Less than 0.3A											
Other	Do not use one that dropped											

File No. Name of part Part No. Use Applicable Machine	Specification	Description																
SW-27,29,30  Pressure switch  2479U1378  Auto accel Swing 1 Pedal Lever  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Contact type</td> <td>Normal open</td> </tr> <tr> <td>Medium used</td> <td>Hydraulic oil</td> </tr> <tr> <td>Operating pressure range</td> <td>0-50 kgf/cm<sup>2</sup> (0-711 psi)</td> </tr> <tr> <td>Operating temperature range</td> <td>-30~130°C (-22~266°F)</td> </tr> <tr> <td>Contact open/close capacity (DC)</td> <td>Voltage 10-30V Current 10mA-3.5A (provided power is 50W or below)</td> </tr> <tr> <td>Insulation resistance</td> <td>Between terminals (when open), body</td> </tr> <tr> <td>Operating pressure</td> <td>8.0±0.6 kgf/cm<sup>2</sup> (85±7 psi)</td> </tr> <tr> <td>Reset pressure</td> <td>4.0±0.4 kgf/cm<sup>2</sup> (57±6 psi)</td> </tr> </table>	Contact type	Normal open	Medium used	Hydraulic oil	Operating pressure range	0-50 kgf/cm <sup>2</sup> (0-711 psi)	Operating temperature range	-30~130°C (-22~266°F)	Contact open/close capacity (DC)	Voltage 10-30V Current 10mA-3.5A (provided power is 50W or below)	Insulation resistance	Between terminals (when open), body	Operating pressure	8.0±0.6 kgf/cm <sup>2</sup> (85±7 psi)	Reset pressure	4.0±0.4 kgf/cm <sup>2</sup> (57±6 psi)	 <p>SUMITOMO DENSO CONNECTOR (MODEL 050 WATERPROOF CONNECTOR) 2-POLE MALE HOUSING 6187-2311 equivalent</p>
Contact type	Normal open																	
Medium used	Hydraulic oil																	
Operating pressure range	0-50 kgf/cm <sup>2</sup> (0-711 psi)																	
Operating temperature range	-30~130°C (-22~266°F)																	
Contact open/close capacity (DC)	Voltage 10-30V Current 10mA-3.5A (provided power is 50W or below)																	
Insulation resistance	Between terminals (when open), body																	
Operating pressure	8.0±0.6 kgf/cm <sup>2</sup> (85±7 psi)																	
Reset pressure	4.0±0.4 kgf/cm <sup>2</sup> (57±6 psi)																	
SW-28  Switch  ME049263 2479R2348  Hyd. oil temp (96°C (203°F))  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Operating temperature</td> <td>ON 5°C (33°F) OFF 10°C (50°F)</td> </tr> </table>	Operating temperature	ON 5°C (33°F) OFF 10°C (50°F)															
Operating temperature	ON 5°C (33°F) OFF 10°C (50°F)																	
SW-31  Switch  24100U1436F1  Hyd. oil filter  LC03801~ YC01101~ LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V 8A</td> </tr> <tr> <td>Circuit prog.</td> <td>140µg/cm<sup>2</sup></td> </tr> <tr> <td>Differential press.</td> <td>1.05kgf/cm<sup>2</sup></td> </tr> <tr> <td>Oil Temp</td> <td>+50~120°C (+58~248°F)</td> </tr> <tr> <td>Contact point</td> <td>Normal open</td> </tr> </table>	Rated voltage	DC 24V 8A	Circuit prog.	140µg/cm <sup>2</sup>	Differential press.	1.05kgf/cm <sup>2</sup>	Oil Temp	+50~120°C (+58~248°F)	Contact point	Normal open							
Rated voltage	DC 24V 8A																	
Circuit prog.	140µg/cm <sup>2</sup>																	
Differential press.	1.05kgf/cm <sup>2</sup>																	
Oil Temp	+50~120°C (+58~248°F)																	
Contact point	Normal open																	
SW-33  Switch  2479R2287  Hyd. Tank Air Press. SW.  LS00701~ YS00601~	<table border="1"> <tr> <td>Rated voltage</td> <td>DC 24V 4A</td> </tr> <tr> <td>Set pressure</td> <td>0.25±0.05kgf/cm<sup>2</sup></td> </tr> <tr> <td>Max. working press.</td> <td>10.5kgf/cm<sup>2</sup></td> </tr> <tr> <td>Contact point</td> <td>Normal close</td> </tr> </table>	Rated voltage	DC 24V 4A	Set pressure	0.25±0.05kgf/cm <sup>2</sup>	Max. working press.	10.5kgf/cm <sup>2</sup>	Contact point	Normal close									
Rated voltage	DC 24V 4A																	
Set pressure	0.25±0.05kgf/cm <sup>2</sup>																	
Max. working press.	10.5kgf/cm <sup>2</sup>																	
Contact point	Normal close																	





# KOBELCO

## SHOP MANUAL

Hook code No. **55LC25<sub>05E</sub>**

**SK310**   
**SK310<sub>LC</sub>** 

### ELECTRIC SYSTEM

#### TABLE OF CONTENTS

1. ELECTRIC CIRCUIT DIAGRAM .....	1
2. HARNESS	
2.1 Upper Harness .....	3
2.2 Instrument panel Harness Right and Left .....	10
2.3 Instrument panel Harness Main .....	12
2.4 Cab Harness .....	15
3. CONNECTION TABLE OF HARNESSES ACCORDING TO WIRE NUMBERS ....	16

**LC25**



Applicable Machines

LC03801~

YC01101~

Revision	Date of Issue	Remarks
First edition	March, 1995	SSL,C2505E K


# 1. ELECTRIC CIRCUIT DIAGRAM









UPPER HARNESS ASSY (2/2)




DETAIL OF ENGINE




VIEW N (DETAIL OF ALTERNATOR)




DETAIL W (HEATER RELAY)




VIEW V



DETAIL Y



VIEW W




DETAIL Z

TO BE CONNECTED WITH E/O BUS W/ALTERNATOR

M-1: TO GOVERNOR MOTOR


P-8: TO HEATER RELAY



DETAIL X


No.	NAME	QTY	No.	NAME	QTY
2	BATTERY RELAY	1	19	LOCK WASHER	2
3	HORN ASSY (HIGH)	1	20	WASHER	2
4	HORN ASSY (LOW)	1	21	CAPSCREW	2
6	BATTERY CABLE	1	22	NUT	2
7	BATTERY CABLE	1	23	LOCK WASHER	6
8	BATTERY CABLE	1	24	NUT	6
9	BATTERY CABLE	1	25	LOCK WASHER	6
10	HARNESS: RIGHT SIDE	1	26	WASHER	6
11	HARNESS: LEFT SIDE	1	27	CAPSCREW	2
12	HARNESS: UNDER FLOOR	1	29	CLIP	1
13	HARNESS: E/O FRONT	1	30	CLIP	6
14	HARNESS: E/O REAR	1	31	WASHER	4
15	HARNESS: 2 LIGHT	1	32	CLIP	1
16	HARNESS: GROUNDING	1	33	CLIP	1
17	SEMS BOLT	1	34	PLUG	1
18	NUT	2	35	PLUG	1

2.1.1 GROUNDING HARNESS (2-16)




2.1.2 BOOM WORKING LIGHT HARNESS (2-15)

(1) Two Light Harness




2.1.3 BATTERY CABLE


(1) Battery Cable (2-6)



(2) Battery Cable (2-7)




(2) Battery Cable (2-8)




2.1.4 CABLE

(1) Battery ~ Starter motor (2-9)




2.1.5 UNDER FLOOR HARNESS (2-12)







2.1.6 LEFT SIDE HARNESS (2-11)




2.1.7 RIGHT SIDE HARNESS (2-10)





2.1.8 ENGINE SUB HARNESS (FRONT)




2.1.9 ENGINE SUB HARNESS (REAR)



2.2 INSTRUMENT PANEL HARNESS ASSY RIGHT AND LEFT



VIEW I








DETAIL OF B (HOW TO CLAMP HARNESS)

No.	NAME	QTY
1	HARNESS: INST PANEL R/L	1
2	CLIP	3
3	PLATE	1
4	CAPSCREW	2
5	LOCK WASHER	6
6	NUT	4
7	CLIP	3
8	CLIP	2













2.3 INSTRUMENT PANEL HARNESS ASSY. MAIN




No.	NAME	QTY
1	HARNESS: INST-PANEL	1
3	CLIP	4
4	SEMS BOLT	3
5	CAPSCREW	1
6	LOCK WASHER	4
7	NUT	3
8	CLIP	5








2.4 CAB HARNESS



No	NAME	QTY
56	HARNESS : WIPER	1
57	HARNESS : DOOR SW.	1
59	WIPER MOTOR	1
63	ROOM LAMP	1
65	ANTENNA	1
106	DOOR SWITCH	1
157	HARNESS	1
157-12	HARNESS : ROOM LAMP	?



### 3. CONNECTION TABLE OF HARNESSES ACCORDING TO WIRE NUMBERS

#### (1) HOW TO USE CONNECTION TABLE OF HARNESS

1) Search a number wiring

Search the failed electric device in the electric diagram and find the number of wiring.

2) Search a harness name and connector name

Find the number of wiring in Connection Table of Harness.

Then search the name of harness and connector.

3) Search the location of a wiring number

4) Confirm the color of wire and gauge on the actual machine.

No.	Gauge & Color of wire	From		Connector at inst. Panel		To	
		Equipment	No.	Name of connector	No.	Equipment	
1	0.75YL	Fuse box	E-1	7PAF-HD — 18PAM-HD		Inst. Panel L/R	
2	0.75RW	↑	E-1	7PAF-HD — 18PAM-HD		↑	
3	0.75GO	↑	E-1	18PAM-HD — CB104	(R-1)	12V power source	
4	0.75RG	Fuse box	E-1	18PAM-HD — CB104	(E-4)	(Cigarette lighter)	
5	0.75YR	*	E-1	18PAM-HD — 18PAM-HD		Inst. Panel L/R	
6A	0.75L			J/B-15PAF — 18PAM-HD	E-1	Fuse box	
6B	↑			• 17PAF-PA	R-6	Relay Assy.	
6C	•			• 17PAF-FA	R-6	↑	
6D	•			• 17PAF-FA	R-6	↑	
6E	↑			• 6PAM-HD		Inst. Panel L/R	
7A	0.75GY			J/B-10PAF — 18PAM-HD	E-1	Fuse box	
7B	↑			• 6PAF		A/C	
7C	↑			• 18PAM-HD		Inst. Panel L/R	
8	0.75RL	Fuse box	E-1	18PAM-HD — 18PAF-AMP	C-2	Cluster gauge	
9	0.75RB	*	E-1	18PAM-HD — 6PAF		To Cab	
10A	1.25WR			J/B-10PAF — 18PAM-HD	E-1	Fuse box	
10B	•			• 18PAM-HD		Inst. Panel L/R	
10C	•			• 5PAF	R-5	Key Switch Relay	
11A	0.75G			J/B-10PAF — 18PAM-HD	E-1	Fuse box	
11B	↑			• 18PAF-AMP	C-1	Controller	
11C	•			• 4PAF		For Check	
12	0.75RY	Fuse box	E-1	18PAM-HD — 13PAM-ES		Inst. Panel L/R	
13	0.75Y	Fuse box	E-1	18PAM-HD — 18PAF-AMP	C-2	Cluster gauge	

No.	Gauge & Color of wire	From		Connector at Inst. Panel		To	
		Equipment	No.	Name of connector	No.	Equipment	
14A	0.75GR			J/B-15PAF	• 13PAM-HD	E-1	Fuse box
14B	↑				• 6PAM-DS		Inst. Panel L/R
14E	↑				• 6PAF		Cab
14F	↑				• 5PAF	R-8	Intermt relay
15A	0.75LW			J/C-GRAY	• 18PAM-IID	E-1	Fuse box
15B	↑				• 18PAM HD		Inst. Panel L/R
15C	↑				• 12PAM-IID		Under floor
15D	↑				• 6PAF (N)	R-9	2-speed relay
15E	↑				• 6PAF (B)	R-9	"
15F	↑				• 2PAF	R-7	Resistor
16	0.75WV	Fuse box	E-1	18PAM-HD	— 13PAM-DS		Inst. Panel L/R
17A	0.75WL			J/B-10PAF	• 18PAM-HD	E-1	Fuse box
17B	↑				• 17PAF-PA	R-6	Relay Assy.
17C	↑				• 17PAF-PA	R-6	↑
18A	1.25L			J/C-GRAY	• 18PAM-HD	E-1	Fuse box
18B	↑				• 6PAF		A/C
18C	"				• 3PAF		Heater
19	1.25GW	Fuse box	E-1	18PAM-HD	— 2PAF		24V Power reserve
20	0.75R	↑	E-1	18PAM-IID	— 13PAM-DG		Inst. Panel L/R
21	2R	↑	E-1	7PAF-HD	— 3PAM-HD		Side R
22	5Y	↑	E-1	7PAF-HD	— 3PAM-HD		"
23	0.75YV	↑	E-1	7PAF-HD	— 18PAM-HI		Inst. Panel L/R
24	0.75WG	↑	E-1	7PAF-IID	— 18PAM-IID		↑
25	1.25W	↑	E-1	7PAF-HD	— 18PAM-HD		↑
26A	0.75WL			J/C GRAY	• 18PAM HD		↑
26B	↑				• 6PAF		A/C
26C	↑				• 18PAF AMP	C-1	Controller
26D	↑				• 4PAF	D-2	Diode
26E	↑				• 4PAF	D-3	"
26F	↑				• 4PAF	D-1	↑
27A	0.75BR			J/B-15PAF	• 18PAM-HD		Inst. Panel L/R
27B	↑				• 4PAF	D-3	Diode
27C	↑				• 12PAF-AMP	C-2	Cluster gauge
27D	↑				• 4PAF	D-4	Diode

No.	Gauge & Color of wire	From		Connector at Inst Panel		To			
		Equipment	No.	Name of connector	No.	Equipment			
28A	0.75P	Inst Panel L/R		J/B-15PAF	18PAM-HD	Inst. Panel L/R			
28B	↑				4PAF			D-4	Diode
28C	↑				5PAF			R-7	Heater cut relay
28D	↑				5PAF			R-7	"
29	0.75Lg			18PAM-HD	20PAM-HD	Side L.			
30A	0.75W	Inst Panel L/R		J/B-10PAF	4PAF	D-2	Diode		
30B	↑				5PAF	R-5	Key switch relay		
30C	↑				14PAM-HD	Side R			
31A	0.75WG	Inst Panel L/R		J/C-ORANGE	18PAF-AMP	C-1	Controller		
31B	↑				4PAF	D-1	Diode		
31C	↑				5PAF	R-5	Key switch relay		
31D	↑				5PAF	R-4	Safety relay		
32	0.75WB	Side L		20PAM-HD	5PAF	R-7	Heater Cut relay		
33A	0.75WL	Inst Panel L/R		J/B-15PAF	20PAM-HD	Side L.			
33B	↑				5PAF	R-7	Heater Cut relay		
33C	↑				6PAF	R-4	Safety relay		
35	0.75WR	Side L		20PAM-HD	6PAF	R-4	↑		
36A	0.75UY	Inst Panel L/R		J/R-15PAF	6PAF	R-4	↑		
36B	↑				20PAM-HD	Side L			
36C	↑				18PAF-AMP	C-2	Cluster gauge		
36D	↑				18PAM-DS	Inst. Panel L/R			
51	0.75V	Controller	C-1	12PAF-AMP	10PAM-HD	Side L			
52A	0.75P	Controller		J/B-10PAF	12PAF AMP	C-1	Controller		
52B	↑				12PAM-HD	Under Floor			
52C	↑				16PAM-HD	Inst. Panel L/R			
53	0.75GY	Controller	C-1	12PAF-AMP	20PAM-HD	Side L			
54	0.75E	↑	C-1	12PAF-AMP	4PAF				
55	0.75OB	↑	C-1	12PAF-AMP	4PAF		For Check		
56A	0.75OL	Inst Panel L/R		J/B-10PAF	12PAF-AMP	C-1	Controller		
56B	↑				12PAF AMP	C-2	Cluster gauge		
56C	↑				16PAM-HD	Inst. Panel L/R			
57	0.75C	Controller	C-1	12PAF AMP	4PAF	D-7	Diode		
58A	0.75GW	↑	C-1	18PAF-AMP	16PAM-HD	Inst. Panel L/R			
58	0.75GO	↑	C-1	18PAF-AMP	16PAM-HD		↑		
60A	0.75GB	↑	C-1	18PAF-AMP	16PAM-HD		↑		
61	0.75WR	↑	C-1	18PAF-AMP	16PAM-HD		↑		

No.	Gauge & Color of wire	From		Connector at inst. Panel		To.	
		Equipment	No.	Name of connector	No.	Equipment	
62	2-Shield Red	Controller	C-1	3PAF-090 — 10PAM-HD		Side L	
63	2-Shield White	↑	C-1	3PAF-090 — 10PAM-HD		↑	
64	0.75LR	↑	C-1	12PAF-AMP — 4PAF	D-6	Diode	
65A	0.75GrP			J/3-10PAF — 4PAF	D-8	↑	
65B	↑			9PAF	SW-2	Release SW	
65C	↑			16PAM-HD		Inst. Panel L/R	
66A	0.7520			J/3-10PAF — 12PAF-AMP	C-1	Controller	
66B	↑			4PAF	D-10	Diode	
66C	↑			16PAM-HD		Inst. Panel L/R	
67	0.75LD	Controller	C-1	12PAF-AMP — 4PAF	D-9	Diode	
68	0.75Y	Inst. Panel L/R		16PAM-HD — 4PAF	D-9	↑	
69A	0.75LB			J/3-10PAF — 12PAF-AMP	C-1	Controller	
69B	↑			20PAM-HD		Side L	
69C	↑			6PAF	C-3	Flasher unit	
81	4-Shield Green	Controller	C-1	18PAF-AMP — 16PAM-HD		Side L	
82	4-Shield Black	↑	↑	18PAF-AMP — 16PAM-HD		Side L	
83	4-Shield Red	↑	↑	18PAF-AMP — 16PAM-HD		Side L	
84	4-Shield White	↑	↑	18PAF-AMP — 16PAM-HD		Side L	
85A	0.75VG			L/O-ORANGE — 12PAF-AMP	C-1	Controller	
85B	↑			4PAF		For Check	
85C	↑			12PAF-AMP	C-2	Cluster gauge	
86	0.75PI	Controller	C-1	18PAF-AMP — 18PAF-AMP	C-2	↑	
87	0.75PG	↑	C-1	18PAF-AMP — 18PAF-AMP	C-2	↑	
88	0.75YB	↑	C-1	18PAF-AMP — 9PAF	SW-2	Release SW	
89	0.75YL	↑	C-1	18PAF-AMP — 9PAF	SW-2	↑	
90	0.75GZ	Side R		8PAM-HD — 9PAF	SW-2	↑	
91	0.75YK	↑		8PAM-HD — 9PAF	SW-2	↑	
92	0.75WS	Resistor	E-7	2PAF — 9PAF	SW-2	↑	
93	0.75BY	Controller	C-1	18PAF-AMP — 8PAM-HD		Side R	
94	0.752P	↑	C-1	18PAM-AMP — 8PAM-HD		↑	
101	0.75PB	Cluster gauge	C-2	12PAF-AMP — 16PAM-HD		Inst. Panel L/R	
102A	0.75GA			J/3-15PAF — 18PAF-AMP	C-2	Cluster gauge	
102B	↑			4PAF	D-7	Diode	
102C	↑			20PAM-HD		Side L	
103	0.75YG	Cluster gauge	C-2	18PAF-AMP — 20PAM-HD		↑	
104	0.75RG	↑	C-2	18PAF-AMP — 20PAM-HD		↑	

No.	Gauge & Color of wire	From		Connector at inst. Panel		To	
		Equipment	No.	Name of connector	No.	Equipment	
105	0.75YB	Cluster gauge	C-2	18PAF-AMP — 20PAM-HD		Side L	
106	0.75YL	"	C-2	18PAF-AMP — 20PAM-HD		"	
107	0.75YV	"	C-2	18PAF-AMP — 20PAM-HD		"	
108	0.75GY	"	C-2	18PAF-AMP — 8PAM-HD		Side R	
109	0.75YR	"	C-2	12PAF-AMP — 20PAM-HD		Side L	
110	AV90.85YW	"	C-2	12PAF-AMP — 14PAM-HD		Side R	
111	AV90.85YO	"	C-2	12PAF-AMP — 14PAM-HD		"	
112	0.75GB	"	C-2	5PAF-AMP — 8PAM-HD		"	
113A	0.75BW			J/C-ORANGE — 18PAF-AMP	C-2	Cluster gauge	
113B	↑			• 12PAM-HD		Under floor	
113C	↑			• 6PAF	R-6	2 speed relay	
114	0.75BrW	Cluster gauge	C-2	18PAF-AMP — 6PAF	C-3	Flusher unit	
115A	0.75GrL			J/C-ORANGE — 12PAF-AMP	C-2	Cluster gauge	
115B	↑			• 17PAF-PA	R-6	Relay Assy.	
115C	"			• 12PAM-HD		Under floor	
116A	0.75RY			J/B-15PAF — 12PAF-AMP	C-2	Cluster gauge	
116B	↑			• 17PAF-PA	R-6	Relay Assy.	
116C	↑			• 14PAM-HD		Side R	
117A	0.75V			J/B-15PAF — 12PAF-AMP	C-2	Cluster gauge	
117B	↑			• 12PAM-HD		Under floor	
117C	↑			• 4PAF	D-10	Dash	
117D	↑			• 16PAM-HD		Inst. Panel L/R	
118	0.75VW	Signal reverse unit		3PAF — — — — 13PAM-DS		↑	
120	0.75VG	Cluster gauge	C-2	18PAF-AMP — 3PAF		Signal reverse unit	
121	0.75BL	Relay Assy.	R-6	17PAF-PA — 9PAF	SW-2	Release SW	
122	0.75GrR	Inst. Panel L/R		13PAM-DS — 6PAF	C-3	Flusher unit	
123A	0.75BrY			J/B-15PAF — 6PAF	C-3	↑	
123B	"			• 14PAM-HD		Side R	
123C	↑			• 20PAM-HD		Side L	
124A	0.75BrR			J/R-15PAF — 6PAF	C-3	Flusher unit	
124B	↑			• 14PAM-HD		Side R	
124C	"			• 20PAM-HD		Side L	
125A	0.75RG			J/B-15PAF — 13PAM-DS		Inst. Panel L/R	
125B	"			• 17PAF-PA	R-6	Relay Assy.	
125C	"			• 17PAF-PA	R-6	"	

No.	Gauge & Color of wire	From		Connector at inst. Panel		To	
		Equipment	No.	Name of connector	No.	Equipment	
126A	0.75RB			5/B-15PAF	17PAF-PA	R-6	Relay Assy.
126B	*				14PAM-HD		Side R
126C	*				12PAM-HD		Under floor
126D	*				6PAF		A/C
127A	0.75LY	Side R		14PAM-HD	17PAF-PA	R-6	Relay Assy.
128	0.75BrR	Inst. Panel L/R		6PAM-HD	6PAF	R-8	Intermit Relay
129	0.75Bz	*		6PAM-HD	6PAF	R-8	↑
130	0.75BzW	Cab		6PAF	6PAF	R-8	↑
131	0.75BrB	*		6PAF	6PAF	R-8	↑
132	0.75O	Under floor		12PAM-HD	6PAF	R-9	2-speed travel relay
133A	0.75WV			1/B-15PAF	6PAM-HD		Inst. Panel L/R
133B	*				5PAF	(R-10)	(Travel Alarm relay)
133C	↑				5PAF	(R-10)	↑
134	0.75EG	Side R		4PAM-HD	5PAF	(R-10)	↑
135	0.75LR	Under floor		12PAM-HD	5PAF	(R-10)	*
151B	0.75G	↑		12PAM-HD	16PAM-HD		Inst. Panel L/R
152B	0.75Lg	↑		12PAM-HD	16PAM-HD		*
153A	0.75RW			1/B-15PAF	13PAM-DS		*
153B	*				14PAM-HD		Side R
153C	↑				20PAM-HD		Side L
154	0.75LgB	Inst. Panel L/R		6PAM-HD	12PAM-HD		Under floor
155	0.75PL	Side L		20PAM-HD	6PAF		A/C
157	1.25LY	Inst. Panel L/R		15PAM-HD	3PAF		Heater
158	1.25LB	↑		15PAM-HD	3PAF		*
159	0.75GrG	↑		18PAM-HD	2PAF	(E-9)	(Speaker L)
160	0.75VG	↑		18PAM-HD	2PAF	(E-10)	(Speaker R)
161	0.75VR	Side R		14PAM-HD	13PAM-DS		Inst. Panel L/R
162	0.75VY	↑		14PAM-HD	13PAM-DS		↑
163	0.75Gr	↑		14PAM-HD	13PAM-DS		↑
164	0.75GrB	↑		14PAM-HD	13PAM-DS		↑
165	0.75PG	Inst. Panel L/R		16PAM-HD	17PAF-PA	R-6	Relay Assy.

No.	Gauge & Color of wire	From		Connector at inst. Panel	To	
		Equipment	No.	Name of connector	No.	Equipment
201	0.50BY	Inst. Panel L/R		16PAM-TS — 16PAF-040	C-2	Cluster group
202	0.50P	†		16PAM-TS — 16PAF-040	C-2	†
203	0.50R	†		16PAM-TS — 16PAF-040	C-2	*
204	0.50BG	†		16PAM-TS — 16PAF-040	C-2	*
205	0.50O	†		16PAM-TS — 16PAF-040	C-2	*
206	0.50EL	†		16PAM-TS — 16PAF-040	C-2	†
207	0.50V	*		16PAM-TS — 16PAF-040	C-2	†
208	0.50G	*		16PAM-TS — 16PAF-040	C-2	†
209	0.50L	*		16PAM-TS — 16PAF-040	C-2	†
210	0.50LR	*		16PAM-TS — 16PAF-040	C-2	†
211	0.50V	†		16PAM-TS — 16PAF-040	C-2	†
212	0.50VW	†		16PAM-TS — 16PAF-040	C-2	†
213	0.50BW	†		16PAM-TS — 16PAF-040	C-2	†
214	0.50BR	*		16PAM-TS — 16PAF-040	C-2	†
215	0.50GR	†		16PAM-TS — 16PAF-040	C-2	†
216	0.50W	†		16PAM-TS — 16PAF-040	C-2	†
231	0.50LW	A/C		14PAM-HD — 14PAF-HD		Inst. Panel L/R
232	0.50WR	*		14PAM-HD — 14PAF-HD		Inst. Panel L/R
233	0.50BrW	*		14PAM-HD — 14PAF-HD		Inst. Panel L/R
234	0.50GW	*		14PAM-HD — 14PAF-HD		Inst. Panel L/R
235	0.50RG	*		14PAM-HD — 14PAF-HD		Inst. Panel L/R
236	0.50RR	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
237	0.50B	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
238	0.50RL	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
239	0.50LB	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
240	0.50YR	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
241	0.50GR	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
242	0.50YL	*		14PAM-HD — 14PAF-HD		Inst. Panel L/R
243	0.50WG	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R
244	0.50YG	†		14PAM-HD — 14PAF-HD		Inst. Panel L/R



No.	Gauge & Color of wire	From		Connector at inst. Panel	To	
		Equipment	No.	Name of connector	No.	Equipment
E01	1.25B	Side R		11PAF-GND — 16PAM-HD		Inst. Panel L/R
E02	0.75B		J/C-GRAY — 17PAF-PA	R-6	Relay Assy	
E03	1.25B		11PAF-GND — J/C-GRAY			
E04	↑		11PAF-GND — J/C-GRAY			
E05	5B		3PAM-HD — LA305			
E06	0.75B		J/C-GRAY — J/C-GRAY			
D07	↑		J/C-GRAY — 5PAF-AMP	C-2	Cluster gauge	
E	0.75B		11PAF-GND — 18PAF-AMP	C-1	Controller	
E	↑		11PAF-GND — 18PAF-AMP	C-2	Cluster gauge	
E	↑		11PAF-GND — 6PAF	R-4	Safety relay	
E	↑		11PAF-GND — 6PAF	R-9	2-speed relay	
E	1.25B		11PAF-GND — 6PAF		A/C	
E	0.75B		11PAF-GND — 9PAF	SW 2	Release SW	
R	↑		11PAF-GND — 5PAF	R-5	Key SW relay	
E	↑		11PAF-GND — 16PAM-HD		Inst. Panel L/R	
E	↑		J/C-GRAY — 6PAF	C-3	Flasher controller	
E	↑		6PAF	R-8	Intermit relay	
E	↑		4PAF		For check	
E	↑		17PAF-PA	R-6	Relay Assy	
E	1.25B		2PAF		Power source	
E	0.75B	FEMALE	(E-4)	Cigarette Lighter		
R	↑	CA101	(E-11)	12V power source		
K	↑	2PAF	(E-10)	(Speaker R)		
K	↑	2PAF	(E-9)	(Speaker L)		
E	↑	1PAM				
E	↑	6PAF		Cab		
E	↑	3PAF		Signal reverse unit		
SH		Side L		10PAM-HD — 3PAF-DX	C-1	Controller
SH1				10PAM-HD — J/C-GRAY		



# KOBELCO

## SHOP MANUAL

# SK310

# SK310LC

### — AIR-CONDITIONER SYSTEM —

#### TABLE OF CONTENTS

1. CONSTRUCTION .....	1	5. CHARGING REFRIGERANT	
2. CONSTRUCTION OF MAIN COMPONENTS		5.1 Precautions to be Exercised in Operation ....	18
2.1 Intake Unit .....	2	5.2 Operation Procedure .....	19
2.2 Air-Conditioner Unit .....	3	5.3 Charging Procedure .....	20
2.3 Receiver Dryer .....	4	6. ELECTRIC CIRCUIT	
3. FUNCTION		6.1 Electric Circuit Diagram and Connectors ....	24
3.1 Mechanism of Cooling Circuit ..	5	6.2 Checking Functional Parts ...	26
3.2 Cooling Circuit .....	7	7. TROUBLESHOOTING	
3.3 Component Parts .....	8	7.1 Cooling Circuit .....	27
4. DISASSEMBLY AND REASSEMBLY		7.2 Electric System .....	29
4.1 Precautions to be Exercised in Operation ....	12		
4.2 Disassembly and Reassembly of Unit Casing .....	13		
4.3 Replacing Thermistor .....	13		
4.4 Replacing Evaporator and Expansion Valve ...	14		
4.5 Replacing Water Valve .....	14		
4.6 Replacing Air Mix Motor Actuator	15		
4.7 Replacing Mode Motor Actuator	16		
4.8 Replacing Mode Link .....	16		
4.9 Replacing Intake Motor Actuator	16		
4.10 Replacing Blower Motor ....	17		
4.11 Replacing Resistors .....	17		

**LC26**

## Applicable Machines

LC03801~

YC01101~

## PREFACE

In place of a conventional special air-conditioner using refrigerant R12, we have developed a special air-conditioner using a new refrigerant R134a that has little effect upon global environment and does not destroy the ozone layer of the earth. Since R134a differs from conventional R12 in terms of characteristics, it can not be applied to conventional air-conditioners. This manual summarizes basic knowledge and precautions to be exercised in servicing the R134a special air-conditioner.

Revision	Date of Issue	Remarks
First edition	March, 1995	S5LC2605E K

# 1. CONSTRUCTION




Fig. 1

No.	NAME	Q'ty	No.	NAME	Q'ty	No.	NAME	Q'ty
1-1	INTAKE UNIT	1	17	SEMS BOLT M6	2	22	DUCT HOSE A	1
1-2	AIR-CONDITIONER UNIT	1	12	SEMS BOLT M8	2	23	DUCT HOSE B	1
2	DRAIN HOSE	1	13	COMPRESSOR	1	24	DUCT HOSE C	1
3	DRAIN HOSE	1	14	V-BELT	1	25	GRILL	2
4	S HOSE	1	15	PANEL	1	26	GRILL	2
6	HOSE CLAMP	2	16	HARNESS A	1	27	PULLEY	1
6	D HOSE	1	16-1	FUSE 1A	3	28	NUT M10	1
7	L HOSE	1	17	CONTROL AMP.	1	29	SPRING WASHER	1
8	L HOSE	1	18	CONDENSER	1	30	SPRING WASHER	1
9	RECEIVER DRYER	1	19	HARNESS B	1	31	BOLT	1
10	FASTENING METAL	1	20	DUCT A	1	32	SLIDE SHAFT	1
10	RECEIVER DRYER	1	21	DUCT B	1	33	PULLEY STOPPER	1

## 2. CONSTRUCTION OF MAIN COMPONENTS

### 2.1 INTAKE UNIT




Fig. 2

No.	NAME	Q'ty	No.	NAME	Q'ty	No.	NAME	Q'ty
1	FAN CASING LH	1	11	HARNESS	1	20	CLAMP	2
2	FAN CASING RH	1	11-1	DIODE 1B	5	21	HARNESS CLAMP	1
3	CONNECTING OPENING	1	12	LINK ROD	1	22	SEMS BOLT	3
4	OUTER AIR FILTER	1	13	DAMPER LEVER	1	23	SEMS BOLT	1
5	INNER AIR FILTER	1	14	INTAKE DAMPER	1	24	MACHINE SCREW	4
6	HOLDER	2	15	RELAY	4	25	MACHINE SCREW	2
7	COOLING HOSE	1	16	WASHER	3	26	MACHINE SCREW	4
8	BLOWER MOTOR	1	17	CLAMP	9	27	MACHINE SCREW	4
9	ACTUATOR	1	18	ROD CLAMP	1			
10	RESISTOR	1	19	ROD HOLDER	1			

## 2.2 AIR-CONDITIONER UNIT




Fig. 3 (1/2)

No.	NAME	Q'ty	No.	NAME	Q'ty	No.	NAME	Q'ty
1	EVAPORATOR	1	18	PIPE RETAINER	1	35	NUT	2
2	HEATER COVER	1	19	PIPE RETAINER	1	37	SPACER	2
3	UNIT CASING LOWER	1	20	ACTUATOR	1	38	ROD CLAMP	4
4	UNIT CASING UPPER	1	21	ACTUATOR	1	39	THERMOWELL STAY	1
5	UPPER DUCT	1	22	VALVE	1	40	BAND	2
6	LOWER DUCT	1	23	VALVE	1	41	ROD HOLDER	2
7	DUCT HOSE	1	24	THERMISTOR	1	42	SENSOR HOLDER	1
8	THERMAL INSULATION MATERIAL	1	25	HARNESS	1	43	CLAMP	1
9	GASKET	1	26	SPRING	1	44	CORD RETAINER	2
10	GASKET	1	27	VALVE ROD	1	45	HARNESS CLAMP	1
11	DUCT RETAINER	1	28	MODE LINK	1	46	BIND SCREW M3	8
12	THERMOWELL	1	29	LINK ROD	1	47	BIND SCREW M4	1
13	ACTUATOR BRACKET	1	30	LINK ROD	1	48	BIND SCREW M4	8
14	ACTUATOR BRACKET	1	31	DAMPER SHAFT	1	49	MACHINE SCREW	3
15	INLET PIPE	1	32	MODE DAMPER	1	50	MACHINE SCREW	15
16	HEATER HOSE	1	33	AIR MIX DAMPER	1	51	MACHINE SCREW	4
17	HOSE BAND	2	34	DAMPER BASE	1	52	MACHINE SCREW	3
			35	DAMPER SHAFT	1	53	MACHINE SCREW	11

Fig. 3 (2/2)

### 2.3 RECEIVER DRYER





Fig. 4

No.	NAME	Q'ty
1	PRESSURE SWITCH	1
2	SIGHT GLASS	1
3	DESICCANT	1
4	SUCTION PIPE	1
5	FILTER	1
6	RECEIVER TANK	1



### 3. FUNCTION

#### 3.1 MECHANISM OF COOLING CIRCUIT

##### (1) Mechanism of Cooling

In the cooling process, the refrigerant that flows through the cooling circuit changes its phases from liquid to gas and vice versa during which process heat is transferred from the low temperature part (compartment) to the high temperature part (outside of the vehicle).

##### 1) Kind of Refrigerant

Many kinds of refrigerants that change in that way are available, but the following requirements are needed for use in such applications:

- Latent heat of vaporization (heat of vaporization) is large.
- It is easy to liquefy (condense). (It does not require very high pressure for condensation.)
- It is easy to gasify (evaporate). (It evaporates sufficiently at not too low pressure, i.e. cools down an object.)
- It has small specific heat. (Since the refrigerant itself is cooled by the expansion valve, the loss resulting from it must be held down to a minimum.)
- It has a high critical temperature and a low solidification point.
- It is stable chemically and does not corrode and permeate into the circuit parts.
- It is free from toxicity, objectionable odor, flammability and explosiveness and excels in thermal conductivity and electric insulation.
- It has small specific volume.
- It is easy to find out leakage.

Out of refrigerants meeting the above-mentioned requirements, ones having characteristics that suit the intended cooling unit are chosen and used. If a refrigerant other than those designated is used, sufficient refrigeration will not be performed or the equipment in which the refrigerant is used may be broken. Therefore, always use a designated refrigerant for the cooling unit.

Table 1 shows the principal characteristics of the R134a refrigerant that is used in this machine.

Table 1

Item	R134a
Chemical formula	CH <sub>2</sub> FCF <sub>3</sub>
Molecular weight	102.03
Boiling point	-26.19°C (-15.14°F)
Critical temperature	101.14°C (214.05°F)
Critical pressure	4.065MPa (41.45kgf/cm <sup>2</sup> +1)
Critical density	511kg/m <sup>3</sup> (31.9lb/ft <sup>3</sup> )
Density of saturated liquid [25°C (77.0°F)]	1206kg/m <sup>3</sup> (75.3lb/ft <sup>3</sup> )
Specific volume of saturated vapor [25°C (77°F)]	0.0310m <sup>3</sup> /kg (0.496ft <sup>3</sup> /lb)
Latent heat of vaporization [0°C (32°F)]	197.5KJ/kg (47.19kcal/kg)
Flammability	Nonflammable
Ozone destruction coefficient	0

\*1: 1MPa (mega pascal) equals 10.1972kgf/cm<sup>2</sup> (145psi)

(2) Characteristics of Refrigerant (See Fig.5.)

In general, the fluid (general term of gas and liquid) has the following qualities:

- 1) As a gas under certain pressure is cooled down, it begins to condensate at a certain temperature to take a liquid state. The temperature at which condensation begins is unique to each substance (fluid) at a given pressure. The temperature determined by a given pressure is called saturation temperature.




Fig. 5 Pressure-temperature characteristics of R134a

Note ; 1PMa = 145psi

- 2) Inversely to 1) above, the pressure at which a gas condenses for a temperature is determined. This pressure is called saturation pressure.

Fig.5 illustrates the relationships between the saturation temperature and the saturation pressure in the case of refrigerant R134a used in the air-conditioner. At the temperature and the pressure on the lower righthand side of the curve in Fig.5, the refrigerant take a gaseous state, while at the temperature and the pressure on the upper left-hand side of the curve, the refrigerant takes a liquid state.

Let us think of a case where an air-conditioner is operated in the midst of summer. As the refrigerant evaporates, it absorbs evaporation heat from the air of the compartment. In order to cool the inside of the compartment down to 25°C (77°F), the refrigerant must transform (evaporate) from a liquid to a gaseous state at a lower temperature. It can be seen from Fig.5 that R134a under a pressure above the atmospheric pressure is capable of cooling the inside of the compartment sufficiently. (If a refrigerant that requires a pressure below the atmospheric pressure to cool it to a required temperature is used, air is mixed into the circuits, thereby deteriorating the performance of the cooling unit.) In the process in which gaseous refrigerant is brought back to a liquid state, the refrigerant is cooled and condensed by the outer air exceeding 35°C (95°F).

Accordingly the refrigerant is capable of condensing at a pressure exceeding 10.2kgf/cm²G (145psi-G), as seen from Fig.5.

### 3.2 COOLING CIRCUIT

Fig.6 illustrates the cooling circuit of the car air-conditioner.

In this circuit diagram, the portion that cools the air of the compartment is the evaporator. The object air is cooled off by utilizing the fact that the refrigerant takes heat off the surrounding area as evaporation heat as it evaporates in the cooling circuit. Since the part at which vaporization of the refrigerant takes place is the evaporator, cooled air is constantly delivered to the circumference of the evaporator by the blower fan. In the meantime, liquid refrigerant (slightly wet vaporized refrigerant) is fed into the evaporator, when "cooling" effect is attained. For instance, in order to cool the air to 15°C (59°F), the refrigerant can not absorb evaporation heat from the air unless it evaporates at a temperature lower than 15°C (59°F). For that purpose, it can be seen from Fig.5 that the pressure of the refrigerant in the evaporator must be less than 5.2kgf/cm<sup>2</sup>G (74psi-G).

Furthermore, the cooling effect deteriorates unless the feed rate of the refrigerant is controlled so that all of the refrigerant supplied to the evaporator vaporizes and turns into dry vapor.

Consequently, the cooling circuit is so constructed that the evaporator can cool down an object (air in this case) sufficiently (i.e. so as to decrease the pressure in the evaporator) and that an adequate amount of refrigerant can be fed to the evaporator.

The feed rate of the refrigerant is controlled by the expansion valve, but the pressure in the evaporator is held low by the throttling action of the expansion valve and the suction action of the compressor. The compressor acts as a pump that allows the refrigerant to circulate. The compressive action of the compressor and the heat exchange (heat radiation) action of the condenser transform the refrigerant in a dry vapor state back to a liquid state.




Fig. 6 Construction of cooling circuit

### 3.3 COMPONENT PARTS

#### (1) Evaporator (See Fig.7.)

The evaporator is an important heat exchanger that absorbs the heat of the compartment air (object) by the utilization of the latent vaporization heat of the low-temperature, low-pressure liquid-state refrigerant. Therefore, it is necessary that satisfactory heat transfer between the object and the refrigerant take place in the evaporator.

To that end, the evaporator is equipped with fins on the air side in order to increase the heat transfer area of the air side and thereby perform excellent thermal transfer between the refrigerant and the air.

The humidity in the air condenses as the air cools down and adheres to the outside of the evaporator as water drops. The cooling effect deteriorates if the water drops freeze. Therefore, how to discharge water is an important point.

The amount of refrigerant supplied to the evaporator is controlled by the expansion valve which is described in the following. In order to attain proper control, it is necessary to reduce the pressure drop of the refrigerant of the evaporator. Accordingly, reducing the pressure drop is one element that makes the evaporator attain its full performances.

#### (2) Expansion Valve

In order for the evaporator to fulfill its performances, a proper amount of low-pressure low-temperature liquid refrigerant must be fed to the evaporator.

If the feed rate is too low, the refrigerant completes vaporization early in the evaporator which results in deterioration of the cooling effect. If the feed rate is too high, unvaporized liquid refrigerant returns to the compressor (liquid back). This not only deteriorates the cooling effect, but also damages the compressor valves.




Fig. 7 Evaporator

The expansion valve feeds the flowing high-pressure high-temperature liquid refrigerant to the evaporator as low-pressure low-temperature liquid refrigerant (damp vapor of low dryness). The expansion valve controls the feed rate of the refrigerant at the same time.

Fig.8 illustrates how the external temperature sensing expansion valve is constructed. The thermowell in this illustration is installed on the surface of the outlet tube of the evaporator and senses indirectly the temperature of the refrigerant at the outlet of the evaporator. The thermowell and the capillary are filled with R134a in saturated state. The internal pressure of the R134a varies with temperature being sensed. This pressure variation changes the force acting upon the diaphragm.

The high-pressure high-temperature liquid refrigerant that is fed from the receiver side reduces the pressure abruptly as it passes through the valve (throttling action). On that occasion, part of the refrigerant evaporates by the very heat of the refrigerant and cooled off. The result is that low-pressure low-temperature damp refrigerant vapor is fed to the evaporator.

The opening of the valve is determined by the equilibrium between the pressure (low) of the evaporator side, the action of the adjust spring and the pressing force of the diaphragm (the temperature of the refrigerant at the outlet of the evaporator to be sensed by the thermowell). The feed rate is controlled automatically so that under the pressure in the evaporator, the refrigerant is properly overheated (3-8 degrees) and goes out of the evaporator. This action is carried out by sensing the refrigerant temperature at the outlet of the evaporator as against the inlet pressure of the evaporator and consequently controlling the feed rate of the refrigerant.

This means that if the refrigerant pressure drop in the evaporator is excessive, it is difficult to control the overheating or the feed rate of the refrigerant. For this reason, the smaller the pressure drop of the evaporator, the better.




Fig. 8 Expansion valve

It is the temperature sensing expansion valve with an external pressure equalizer that controls more positively the overheat of the refrigerant and the feed rate of the refrigerant to the evaporator by sensing the pressure and the temperature at the outlet of the evaporator. The air-conditioner of this machine employs such a temperature sensing expansion valve with an external pressure equalizer.

(3) Compressor (See Fig.9.)

The compressor performs the following three functions in the cooling circuit:

- 1) Suction action
- 2) Pumping action
- 3) Compressive action

- 1) The suction action, as combined with the throttling action, works to decrease the refrigerant pressure in the evaporator. This permits the refrigerant to vaporize at low temperature in order to perform cooling effect.
- 2) The pumping action serves to cause all the refrigerant to circulate in the cooling circuit. This enables continuous cooling.
- 3) The compressive action, as combined with the action of the condenser which is mentioned hereunder, transforms vaporized refrigerant back to a liquid state again.

The saturation temperature gets higher as the pressure increases. For instance, it becomes possible to cool down the refrigerant by the use of an outer air of 35°C (95°F) and liquefy it. The compressive action of the compressor works to turn low pressure vaporized refrigerant to high pressure vapor refrigerant. The condenser then serves to cool down the refrigerant. However, since the compressive action takes place only for a short period, the refrigerant hardly exchanges heat with outer air. That is to say, it takes a near form of thermally insulated compression, so that the refrigerant discharged by the compressor turns into high-temperature high-pressure vapor and is delivered to the condenser.




Fig. 9 Compressor

(4) Condenser (See Fig 10)

This is a heat exchanger that cools the vaporized refrigerant at high temperature and high pressure by the use of outer air and condenses the refrigerant. The direction in which heat moves is from the refrigerant to air, the opposite to the case of the evaporator. Fins are equipped on the outer air side to improve thermal transfer. If the refrigerant is not cooled well by the condenser, the air in the compartment can not be cooled sufficiently by the evaporator. For that purpose, it is necessary to secure ventilation required for the cooling of the refrigerant.




Fig. 10 Condenser

(5) Receiver Dryer (See Fig.11.)

1) Receiver Tank

On the air-conditioner, the revolution of the compressor varies greatly which causes the proper flow of refrigerant in the cooling circuit to vary. It is the receiver tank that receives the variations. When the cooling circuit does not need much refrigerant, the receiver tank stores extra refrigerant temporarily and supplies it when the cooling circuit needs much refrigerant. The receiver tank also stores an extra amount of refrigerant to be used for filling balance and supplement small amounts of leakage of the refrigerant through penetration into rubber hoses.

2) Dryer

If water is mixed in the cooling circuit, it deteriorates the compressor valves and oil, corrodes the metallic parts of the circuit or clogs the circuit as the water freezes in the expansion valve. It is desirable that the amount of water mixed in the refrigerant should be held below a concentration of 30ppm. The air-conditioner uses a molecular sieve as desiccant suited for the circuit, in order to absorb water content that intrudes into the circuit when the dryer is installed or when refrigerant is charged.

3) Sight Glass

This is a peep window with which the refrigerant level in the circuit is determined, the only means of confirming the inside of the circuit visually.

4) Filler




Fig. 11 Receiver dryer

5) Pressure Switch

This machine employs pressure switches of high/low pressure type.

The pressure switch protects the circuit by cutting off the power supply to the compressor when high pressure increases abnormally high (more than  $32\text{kgf/cm}^2$  (450psi)).

The pressure switch also detects the leakage of refrigerant by cutting the power supply to the compressor when the pressure of the circuit falls below  $2\text{kgf/cm}^2$  (28psi).

## 4. DISASSEMBLY AND REASSEMBLY

### 4.1 Precautions to be Exercised in Operation

#### (1) Special Refrigerator Oil

This air-conditioner uses special refrigerator oil SP20 for use with new refrigerant R134a. Oils other than SP20 may not be used. Since SP20 tends to absorb moisture and may corrode paint and resin, the following points must be noted:

- 1) Keep open all pipe connections on a new compressor and the component parts of the installed refrigeration circuit.  
(Remove valves and caps at the pipe openings of the compressor, just before connecting pipes. If you have removed a pipe joint for repair, put a cap to both ports immediately.)
- 2) Use care so SP20 does not adhere to the painted surface and resin parts. In case SP20 has adhered to such surfaces, wipe it off immediately.
- (2) The receiver dryer is filled with desiccant to absorb moisture in the circuit. Therefore, remove the valve at the pipe port immediately before connecting pipes.

#### (3) Tightening Torque

##### 1) Pipe Joints (See Table 2.)

When connecting pipe joints, coat the O ring with special oil (SP20) and fasten to the tightening torque indicated in the table, using a double spanner.

##### 2) Screws and Bolts (See Table 3.)

#### (4) Amount of Oil for Compressor (See Table 4.)

The compressor SD7H (HD type) is filled with 240cc (15cu-in) of oil. If the oil volume is small, seizure at high revolution and shortening of service life will occur. If the oil volume is large, the cooling ability will be deteriorated.

Once the air-conditioner is operated, part of the oil is dispersed in the refrigeration circuit. Therefore, when replacing the parts in Table 4, adjust the oil level to that of table.

- (5) Before performing operation, stop the engine and turn off all power supplies to the equipment related to the air-conditioner.
- (6) After the operation is over, confirm that all faults have been repaired completely, by operating the air-conditioner.

Table 2

Unit: kgf·cm (ft·lbs)

Pipe Fastening Part	Tightening Torque
D hose and compressor (M8 bolt)	200~250 (14~18)
D hose and condenser	200~250 (14~18)
L hose and condenser	120~150 (8.7~11)
L hose and receiver dryer (M6 bolt)	80~120 (5.8~8.7)
L hose and air-conditioner unit	120~150 (8.7~11)
S hose and air-conditioner unit	300~350 (22~25)
Inlet of expansion valve	120~150 (8.7~11)
Outlet of expansion valve	200~250 (14~18)
Pressure sensing part of expansion valve	70~90 (5.0~6.5)

Table 3

Unit: kgf·cm (ft·lbs)

Screw Size	Tightening Torque
N4, T4 machine screw, M4	8~12 (0.58~0.87)
N5, T5 machine screw, M5	20~25 (1.4~1.8)
M6 (mounting part of L hose joint)	80~120 (5.8~8.7)
M6 (except mounting part of L hose joint)	100~120 (7.2~8.7)
M8 (mounting parts of S, D hose joints)	200~250 (14~18)
M8 (mounting part of A/C unit)	100~120 (7.2~8.7)
M8 (other than those mentioned above)	120~160 (8.7~12)
M10	400~550 (29~40)

Table 4

Part to be Replaced	Amount to be filled in
Evaporator	40cc (2.4cu-in)
Condenser	40cc (2.4cu-in)
Compressor	Drain out the volume of oil left in the compressor to be replaced, from the new compressor.



#### 4.2 DISASSEMBLY AND REASSEMBLY OF UNIT CASING (SEE FIG.12 AND 13.)

The figures in parentheses after the part names correspond to those in the structural drawings.

- (1) Dismantling Upper Duct  
Remove two M4 machine screws (51) and two M5 machine screws (53). Then separate duct retainer (11) and upper duct (5).
- (2) Dismantling the Upper Casing of Air-Conditioner Unit.
  - 1) Dismantle the upper duct according to para. (1) above.
  - 2) Remove two M4 machine screws (51) and two M5 machine screws. Then separate lower duct (6).
  - 3) Separate rod (20) from rod holder (41).

**⚠** On that occasion, do not remove rod clamp (38). In case it is taken off by mistake, adjust it according to para. 4.7.

- 4) Remove air mix actuator connector (15-1) and thermistor connector (24-1).
- 5) Remove four M4 screws (48) and dismantle motor actuator (21).
- 6) Remove 15 M5 machine screws (50) and then separate casing upper (4).

- (3) Mounting  
Mounting should be done in the reverse order of dismantling.

**⚠** Use care so as not to pinch thermistor cord (24-1) between the casing and other object.

#### 4.3 REPLACING THERMISTOR (SEE FIG. 14.)

- (1) Dismantling
  - 1) Dismantle the casing upper of the air-conditioner unit according to para 4.2.(2).
  - 2) Remove thermistor cord (24-2) from the groove (u) on the unit casing
  - 3) Draw out sensor holder (42) from evaporator (1).
  - 4) Remove thermistor (24) from sensor holder (42).
- (2) Mounting  
Mounting is done in the reverse order of dismantling, with attention paid to the following.
  - 1) When installing thermistor (24) to sensor holder (42), place them so only the sensor part (24-3) stands out as shown in the illustration. Use care so air mix damper (30) does not interfere with others.
  - 2) Take care so the cord of thermistor (24) is not pinched between casing (3) and other object.




Fig. 12 Air-conditioner unit




Fig. 13 Air-conditioner unit




Fig. 14 Replacing thermistor

**4.4 REPLACING EVAPORATOR AND EXPANSION VALVE (SEE FIG.15 AND 16.)**

**(1) Dismantling Expansion Valve.**

- 1) Remove the casing upper of the air-conditioner unit according to para 4.2(2).
- 2) Dismantle the assembly of evaporator (1) and expansion valve (22) from the casing, as shown in Fig.15.
- 3) Peel off thermal insulation material (8) of the temperature sensing part and separate thermowell stay (39). (See Fig.16.)
- 4) Loosen nuts (a), (b) and (c) and remove each of the pipos.

**(2) Dismantling Evaporator**

- 1) Perform Para. (1) above.
- 2) Remove M4 screw (47) and separate retainer (18).

**(3) Mounting**

Mounting should be done in the reverse order of dismantling, with attention paid to the following:

- 1) Install thermowell (22-1) as shown in the cross-sectional drawing (A-A)
- 2) Round off extra length of capillary tube (22-2) to about  $\varnothing 20$  (0.787in) beforehand.
- 3) When installing the assembly of the evaporator and the expansion valve to the casing, place them so retainer (18) is fixed to the casing
- 4) Since thermal insulation material (8) can not be re-used, replace it with the expansion valve at the same time.




Fig. 15 Replacing expansion valve




Fig. 16

**4.5 REPLACING WATER VALVE (SEE FIG.17.)**

**(1) Dismantling**

- 1) Turn the fan switch "ON" and bring the temperature control to COOL MAX (Only one LED on the operation panel lights.).
- 2) Release rod clamp (38-a).
- 3) Remove three M5 machine screws (49) and then dismantle water valve (23).

**(2) Mounting**

Mounting is performed in the reverse order of dismantling, with attention paid to the following:

- 1) Attach valve rod (27) to rod clamp (38-a) and turn lever (23-1) toward (A) till spring (27-1) is bent about 1mm (0.04in) Then install valve rod (27) to rod clamp (38-b).
- 2) Replace heater base (16) at the same time.




Fig. 17 Replacing water valve

#### 4.6 REPLACING AIR MIX MOTOR ACTUATOR (SEE FIG.17.)

##### (1) Dismantling

- 1) Release rod clamp (38-C).
- 2) Remove connector (15-1).
- 3) Remove four M4 machine screws (48) and separate motor actuator (21).

##### (2) Mounting

Mounting should be performed in the reverse order of dismantling, with attention paid to the following:

- 1) Turn damper lever (31-1) in the direction of (B) and mount rod (29) to rod clamp (38-C), while pressing the damper lever.
- 2) Make sure that the actuator lever has no play and that spring (27-1) is deflected about 1mm (0.04in).

**⚠** When replacing a new motor actuator, do not remove rod clamp (38-C) in any circumstances. In case you have removed the rod clamp by mistake, turn the fan switch to [I], [II] or [III], set the temperature control to COOL MAX (Only one LED on the operation panel lights.) and install it according to para. (2) above.

#### 4.7 REPLACING MODE MOTOR ACTUATOR (SEE FIG.18.)


##### (1) Dismantling

- 1) Release rod clamp (38).
- 2) Remove connector (25-2).
- 3) Remove four M4 machine screws (48) and dismantle motor actuator (21).

##### (2) Mounting

Mounting is performed in the reverse order of dismantling, with attention paid to the following:

- 1) Turn the link (28-1) of mode link ass'y (28) to the position in Fig.16. (So the mode damper closes the lower blowoff port.)
- 2) Attach mode link rod (29) by pulling it toward (A).

**⚠** Never remove rod clamp (38) except when replacing the motor actuator with a new one. In case you have removed it by mistake, turn the fan switch to [I], [II] or [III], set the blowoff mode to FACE [  ] and installed it according to para. (2) above.





Fig 18 Replacing motor actuator

#### 4.8 REPLACING MODE LINK (SEE FIG.19)

##### (1) Dismantling

- 1) Turn the fan switch to [I], [II] or [III] and set the blowoff mode to FACE [  ].
- 2) Remove three M5 small screws (53) and separate mode link (28).

##### (2) Mounting

Perform mounting in the reverse order of dismantling, with attention paid to the following:

- 1) Tighten the M5 small screws to torque of 10~15kgf-cm (0.72~7.8ft-lbs).
- 2) After mounting, make sure that the link rotates smoothly.




Fig. 19 Replacing mode link

#### 4.9 REPLACING INTAKE MOTOR ACTUATOR (SEE FIG.20.)



##### (1) Dismantling

- 1) Release rod clamp (18).
- 2) Remove connector (11-1).
- 3) Remove four M4 machine screws (24) and separate motor actuator (9).

##### (2) Mounting

Perform mounting in the reverse order of dismantling, with attention paid to the following:

- 1) Turn damper lever (13) toward (A) and install rod (12) to rod clamp (18) while pressing the damper lever.

-  Never dismantle rod clamp (18) except when replacing the motor actuator with a new one. In case you have removed the rod clamp by mistake, turn the fan switch to [I], [II] or [III], set the blowoff mode to inner air circulation [  ] and install the motor actuator according to para. 4.2) above.




Fig. 20 Replacing actuator

#### 4.10 REPLACING BLOWER MOTOR (SEE FIG.21.)

##### (1) Dismantling

- 1) Remove the upper duct according to para. 4.2 (1).
- 2) Remove connector (8-1).
- 3) Separate cooling hose (7) from blower motor (8).
- 4) Take off three M6 small screws (22).

**⚠** On that occasion, exercise care so as not to lose two harness clamps (20) that are fastened together with the blower motor.

- 5) Remove blower motor (8) upwards. Do not separate fan (8-1) from the blower rotor.

##### (2) Mounting

Mounting should be done in the reverse order of dismantling.

**⚠** If foreign matter enters the fan casing, the motor or the resistor may be broken. Use sufficient care so such trouble does not occur.




Fig. 21 Replacing blower motor

#### 4.11 REPLACING RESISTER (SEE FIG.22)

##### (1) Dismantling

- 1) Dismantle blower motor (8) according to para. 4.10.
- 2) Take off two M5 machine screws (25).
- 3) Lift up resistor (10) upward a little, remove connector (11-2) and take it out.

##### (2) Mounting

Mounting is done in the reverse order of dismantling.

**⚠** Never disassemble the resistor. Replace it if the fuse is blown.

**⚠** The resistor gets very hot. If foreign matter is put between the resistor and the heat sink, ignition may occur. Use care so such an accident does not occur.




Fig. 22 Replacing resistor

## 5. CHARGING REFRIGERANT

### 5.1 PRECAUTIONS TO BE EXERCISED IN OPERATION

- (1) Always assign a person in charge of handling refrigerant.

Refrigerant charge operation involves dangers as it handles high pressure gas. Always assign a person familiar with how work is done for handling refrigerant.

- ⚠ **Always wear protective goggles.** (You may lose your sight if the refrigerant gets in your eyes.)
- The refrigerant in liquid state is at very low temperature [approx.  $-26^{\circ}\text{C}$  ( $-15^{\circ}\text{F}$ )]. Therefore, handle it with care. (You may get a frostbite if the refrigerant is sprayed over your skin.)

### (2) Storage and Transportation

- 1) Hold the service can (hereinafter called can) less than  $40^{\circ}\text{C}$  ( $104^{\circ}\text{F}$ ). Since high pressure gas of R134a is filled in the can in a saturated liquefied state, the pressure in the can increases sharply as temperature rises. The can may blast as the result. It is for this reason why the can temperature must be kept below  $40^{\circ}\text{C}$  ( $104^{\circ}\text{F}$ ).
- 2) For storage, choose a cold dark place not exposed to direct sunlight.
- 3) If the can is placed near a fire source, it is subject to radiation heat and gets hot. This causes the inside pressure to rise and may cause the can to blow out. Therefore, never bring the can close to a fire.
- 4) The inside of the closed compartment gets very hot as the radiation heat of the sunlight enters the compartment. The areas of the compartment which are exposed to direct sunlight may rise to a dangerous temperature level. Therefore, do not bring the can into the compartment. Also, the inside of the trunk room may rise to a dangerous temperature level even in the summer time. Use sufficient care, therefore, taking the above into account.
- 5) Note that if the can has scratches, marks and distortion, the strength of the can will deteriorate.
  1. Do not drop or knock on the can.
  2. When transporting, loading or unloading cases and packages containing cans, do not throw or drop them.
- 6) Store cans beyond the reach of children.

### (3) Charging

- 1) When warming the can in which refrigerant is charged, do not fail to open the service can valve and the low pressure valve of the gauge manifold and warm the can in warm water of  $40^{\circ}\text{C}$  ( $104^{\circ}\text{F}$ ) or below (to an extent that you do not feel hot when you put your hand in the water.) If the can is put in hot water or heated by a direct fire, the pressure of the can may rise sharply, thereby blowing off the can.
- 2) When charging refrigerant while running the engine, do not open the high pressure valve (H) of the gauge manifold in any case.

### (4) Others

Re-use of service cans is prohibited by law; never use them again. Do not allow foreign matter to enter the air-conditioner circuit. Air, water and dust are detrimental to the refrigeration cycle. Install the components of the air-conditioner correctly and speedily. Pay full attention to the entry of water and dust.

- ⚠ **Be careful about overcharge of gas.**
- Fasten pipes to a specified torque.



## 5.3 CHARGING PROCEDURE

### 5.3.1 VACUUM MAKING OPERATION

#### (1) Connecting Gauge Manifold (See Fig.23.)

- 1) Close the high pressure valve (HI) and the low pressure valve (LO) of the gauge manifold.
- 2) Connect the charging hoses (rod and blue) with the service valves of the compressor.  
 Red hose: High pressure side (HI) of the gauge manifold → high pressure side (DIS) of compressor  
 Blue hose: Low pressure side (LO) of gauge manifold → low pressure side (SUC) of compressor

- ⚠ Take care so as not to mistake the high pressure side for low pressure side and push it in till a click is heard.
- Connect the end bent like "L" of the charging hose with the service valve of the compressor. If the charging hose is connected the opposite way, the mini valve of the compressor does not open. (See Fig.24.)




Fig. 23 Connecting gauge manifold




Fig. 24 Connecting piping with compressor

- 3) Connect the middle valve of the gauge manifold with the charging hose of the vacuum pump.

- ⚠ Some kinds of gauge manifolds are not equipped with an open/close valve in the center.

#### (2) Vacuum Making (See Fig.25.)

- 1) Open the high pressure valve (HI) and the low pressure valve (LO) of the gauge manifold.
- 2) Turn on the switch of the vacuum pump and make vacuum for more than 30 minutes.
- 3) When vacuum making for a specified duration is over (degree of vacuum: less than -750mmHg), close the high pressure valve and the low pressure valve of the gauge manifold
- 4) Then turn off the vacuum pump.




Fig. 25 Vacuum making operation



(3) Air-tightness Check

Close the high pressure valve and the low pressure valve of the gauge manifold, leave it as it is for more than five minutes and make sure that the gauge indication does not return toward 0.

**⚠** If the gauge indication swings toward 0, there is somewhere that is leaking. Retighten pipe joints, make vacuum again and make sure of no leakage.

5.3.2 GAS FILLING OPERATION

(1) Filling from High Pressure Side (See Fig.26.)

1) After making vacuum repeatedly, change the charging hose (yellow) of the gauge manifold from the vacuum pump to the service can.

2) Air purge

Open the service can valve. (However, close the high and low pressure valves of the gauge manifold.) Then push the mini valve of the side service port on the low pressure side of the gauge manifold, using a screwdriver or something, in order to let out the air in the charging hose by the pressure of the refrigerant. (See Fig.26.) (The operation ends when a hissing sound is heard.)

3) Open the high pressure valve of the gauge manifold and fill in refrigerant. (Fill in gaseous refrigerant to a gauge pressure of 1kgf/cm<sup>2</sup> (14psi).)

After charging, close the high pressure valve of the gauge manifold and the service and valve. (See Fig.27.)

**⚠** Do not run the compressor in any case. (Otherwise the refrigerant flow in reverse direction which causes the service can and the hoses to rupture. This is very dangerous.)

(2) Checking for Gas Leakage

Check for gas leakage in the cycle, using a gas leak detector (electric type). Retighten and correct leaking points.

**⚠** Always use R134a for the leak tester. (The presently used iron gas affects the sensitivity adversely.)




Fig. 26 Gas filling operation




Fig 27 Gas filling operation (High pressure side)

(3) Filling from Low Pressure Side (See Fig.28.)

- 1) Make sure that the high-pressure and low-pressure valves of the gauge manifold and the service can valve are closed.
- 2) Start the engine and run the revolution to  $1500 \pm 100$ rpm and fully open the cab door and the windows
- 3) Turn on the air-conditioner switch, set the fan switch to Max and the temperature control switch to cool Max.
- 4) When filling gas, set the discharge pressure of the compressor to  $14-16 \text{ kg/cm}^2$  ( $200-230 \text{ psi}$ ).
- 5) Open the low pressure valve of the gauge manifold and the service can valve and fill in refrigerant till air bubbles of the sight glass of the receiver go away (See Fig.29 : [Total amount of gas to be charged :  $1000 \pm 20 \text{ g}$  ( $2.2 \pm 0.1 \text{ lbs}$ )])
- 6) When refrigerant charge is over, close the low pressure valve of the gauge manifold and the service can valve.



- Do not open the high pressure valve of the gauge manifold in any circumstances.
- Never place the service can upside down. (The compressor valve may be scored because the refrigerant is sucked in a liquid state.)







Fig. 28 Gas filling operation (Low pressure side)



Fig. 29 Receiver dryer

(4) Criterion for Checking the Amount of Refrigerant Filled in

Judgment of refrigerant level through the sight glass of receiver dryer

Proper level	After A/C is turned on, only a little bubbles are seen and thereafter light milky white is seen.	
Overcharge	After A/C is turned on, no air bubbles are seen.	
Undercharge	After A/C is turned on, continuous air bubbles are seen.	

- ⚠**
- If the air-conditioner is run with scant refrigerant R134a, it has adverse effect on the compressor.
  - If the refrigerant is charged too much (overcharged), the cooling performance is deteriorated. Moreover, the circuit pressure gets abnormally high : Always keep a proper level.

(5) Dismantling Gauge Manifold

When the refrigerant level has been checked, disconnect the charging hoses from the compressor in the following manner :

- 1) Press the "L" shape metal fitting of the charging hose (blue) on the low pressure side against the service valve of the compressor so the refrigerant does not leak out and loosen the nut. As soon as the nut has been removed, disconnect the charging hose from the service valve.
- 2) Leave the high pressure side as it is till the high pressure gauge reading falls. [below  $10\text{kg/cm}^2\text{G}$  ( $140\text{psi-G}$ )].
- 3) Disconnect the charge hose (red) on the high pressure side the same way as on the low pressure side.









(4) Pressure Switch (Attached to Receiver Dryer)

1) Contents of checking (specification)

Low pressure side off pressure :

$2.0 \pm 0.2 \text{ kgf/cm}^2 \text{ G}$  ( $28 \pm 3 \text{ psi-G}$ )

Low pressure side return pressure :

OFF pressure  $+0.3 \text{ kgf/cm}^2$  (4.3psi) or below

High pressure side off pressure :

$32 \pm 2 \text{ kgf/cm}^2 \text{ G}$  ( $455 \pm 28 \text{ psi-G}$ )

High pressure side return pressure :

off pressure  $-6 \pm 2 \text{ kgf/cm}^2$  ( $-85 \pm 28 \text{ psi}$ )

2) Performance

Low pressure side : To prevent actuation of the compressor clutch where refrigerant is deficient.

High pressure side : To prevent actuation of the compressor clutch where pressure rises abnormally because of the clogging of the refrigeration circuit, etc.

(5) Thermistor (C18)

1) Contents of checking (specification)

Resistance across terminals

at  $0^\circ\text{C}$  ( $32^\circ\text{F}$ ) :  $7.2 \text{ k}\Omega$

at  $25^\circ\text{C}$  ( $77^\circ\text{F}$ ) :  $2.2 \text{ k}\Omega$

Note : Normally check that there is no shortcircuit or disconnection.

2) Performance

In order to prevent freezing of the evaporator, the blowoff air temperature of the evaporator is controlled by turning the compressor clutch on and off. The thermistor operates as the sensor of the control.

(6) Resister

1) Contents of checking

Resistance across terminals 1-2 :

$8.0 \Omega$  (blower 1)

Resistance across terminals 1-4 :

$2.5 \Omega$  (blower 2)

Resistance across terminals 1-3 :

$1.0 \Omega$  (not used)

2) Function

Lower the terminal-to-terminal voltage of the blower motor and adjust the revolution of the blower motor.




Fig. 33 Pressure switch






Fig. 34 Thermistor



AS VIEWED FROM A

Fig. 35 Resister




## 7. TROUBLESHOOTING

### 7.1 COOLING CIRCUIT


Symptom and Diagnosis		Cause	Remedy and Disposition		
Poor cooling	Both high and low pressures are high.	Air bubbles are seen through sight glass.	Oil oozes out of pipes and parts. Gas detector reacts.	Gas leaks from pipe joints and parts.	Retighten or replace faulty parts with new ones.
		No oozing of oil and on gas reaction. Gas has not been charged for more than one season.	Natural leaks from hose.	Charge gas.	
	No air bubbles seen through sight glass.	Expansion valve is not conditioned well. (Too much throttling)	Recondition or replace.		
		Expansion valve clogged.	Remove clogged stuff, replace receiver or expansion valve.		
		Low pressure circuit and evaporator clogged.	Remove clogged stuff, or replace faulty parts.		
		Cooling performance deteriorates at high speed continuous run. Air flow does not change.	Expansion valve is frozen. Water entered.	After vacuum making, refill refrigerant and replace receiver.	
		Air flow is small.	Air leaks from casing.	Clog with vinyl tape or packing compound.	
		Cylinder of compressor does not get hot. (liquid pack)	Thermowell of expansion valve is in poor contact.	Improve contact. Replace thermowell stay.	
	Low pressure is high.	Air bubbles are seen through sight glass.	Expansion valve is condition poorly. (too much open)	Readjust or replace.	
			Discharge of compressor is bad. (gasket or valve faulty)	Replace.	
		High pressure is low.	Cylinder of compressor gets very hot. Objectionable odor emitted.	Water cock is adjusted poorly or cock is faulty.	Check and readjust or replace.
	Hot air comes out of heater unit.	Air-tightness of outer air damper is faulty. (outer air intake type)	Repair.		
	High pressure is high	Air bubbles seen through sight glass.	Low pressure is low.	High pressure circuit upstream of receiver is clogged.	Remove clogged stuff or replace parts.
			Condenser is fouled or clogged.	Clean condenser.	
		Air bubbles are hard to escape even if water is poured over condenser. Receiver temperature is low.	Refrigerant is overcharged.	Discharge refrigerant to a proper level.	
Air is mixed			Refill refrigerant after vacuum making. Replace receiver.		
Cooling is poor at high speed continuous run. Air flow is low.	Frost deposited.	Thermistor is not cooled well.	Thermistor position incorrect.	Correct thermistor position.	
		Air leaks from casing.	Stuff with vinyl tape or packing compound.		
	Thermistor is cooled.	Thermostat faulty. (does not OFF)	Thermistor cord disconnected, etc.		
		Performance and functions are normal. If compressor is run for a long time with the air flow level set to M or L, frost deposit may occur.	Get users familiar with how to use it. Increase air flow.		


Symptom and Diagnosis	Cause	Remedy and Disposition		
Heater is faulty	Blowoff temperature is higher than suction air temperature by 5°C (41°F) when the air-conditioner switch is off and the control is set to COOL MAX.	Heater warm water valve is faulty, valve is conditioned poorly. Heater control wire is adjusted incorrectly. Replace or adjust valve.		
Noise	Compartment side	Blower motor fan	Fan interferes with casing or foreign matter enters casing.	Eliminate foreign matter. Adjust fan motor position.
		Sound of brushes. Metal or thrust washer interferes with others.	Some sound is inevitable. Replace ones making a large sound.	
	Gas sound (roaring sound)	Gas vibration sound (discharge of compressor or gas sucking sound of compressor)	No problem functionally	
	Expansion valve: hissing sound and gas flowing sound	Sound of expansion valve is unusual. Expansion valve is normal.	Replace expansion valve if blowing sound is heard. Some gas flowing sound is inevitable.	
	Sound that is made when the clutch is disengaged.	Clutch bearing or idle pulley bearing is faulty.	Replace.	
		Uneven contact of clutch armature, loosened belt or loosened screws.	Repair or replace clutch. Retighten screws.	
	Sound is made when compressor runs.	Sound of compressor is unusual.	Repair or replace if faulty.	
		Oscillation due to slack V-belt or loosened screws	Tension belt. Retighten screws.	
	Engine room	Water leaks or splashes.	Heater core is broken or hose ruptured.	Replace.
		Drain hole of casing or drain hose is clogged.	Clean.	
Others	Objectionable odor smells.	Tobacco smoke, dust and odor of the compartment get stuck to evaporator fins and stay there.	Clean evaporator or open door when humidity is high and set air flow to L. Run the compressor for 10 minutes at about 1500rpm and wash down with condensed water.	

Note: Re-connect the connectors removed for inspection, after repair is over.




Note: Reconnect connectors removed for inspection securely after repair.





- Note 1. Refit the connectors removed for inspection securely after repair.
- Note 2. The items marked \* can not be inspected unless refrigerant is filled up and atmospheric temperature is more than 0°C (32°F).



# SHOP MANUAL


model

**SK310**  
**SK310LC**

## TABLE OF CONTENTS

1. HYDRAULIC PUMP .....	<b>12</b>
2. CONTROL VALVE .....	<b>13</b>
3. OTHER VALVES .....	<b>14</b>
4. HYDRAULIC MOTOR .....	<b>15</b>
5. SWIVEL JOINT .....	<b>16</b>
6. HYDRAULIC CYLINDER .....	<b>17</b>
7. REDUCTION UNIT .....	<b>21</b>
8. ENGINE .....	<b>50</b>

○How to Index each Shop Manual Section  
The COMPONENTS of this shop manual consists of headings as shown above. Each section can be easily referred to by indexes appended to the margin of the page as indicated on the right. Please use the indexes for speedy reference.



# KOBELCO

# COMPONENTS

Book code No. S5LC3005E

SK310<sup>m</sup>  
SK310<sup>LCIII</sup> List of Shop Manual COMPONENTS Section

Index No.	Title	Book Code No.		
			Distribution Year - Month	
12	HYDRAULIC PUMP	<del>S5120405E②</del> 1995-03	S5120405E	Refer to II
	REGULATOR	<del>S5120406E②</del> 1995-03	S5120406E	Refer to II
	HYDRAULIC GEAR PUMP	<del>S5120411E②</del> 1995-03	S5120411E	Refer to II
13	PILOT VALVE (THROK)	<del>S5130457E②</del> 1995-03	S5130457E②	Refer to II
	CONTROL VALVE (SWING)	<del>S5130751E②</del> 1995-03	S5130751E	Refer to II
	CONTROL VALVE	S5130767E 1995-03		
	PILOT VALVE (TRAVEL)	S5130777E 1995-03		
14	HOLDING VALVE (ROOM LOCK)	<del>S5140711E②</del> 1995-03	S5140711E②	Refer to II
	MANIFOLD BLOCK	<del>S5140731E②</del> 1995-03	S5140731E	Refer to II
15	HYDRAULIC MOTOR (TRAVEL)	<del>S5150233E②</del> 1995-03	S5150233E②	Refer to II
	HYDRAULIC MOTOR (SWING)	<del>S5150437E②</del> 1995-03	S5150437E	Refer to II
16	SWIVEL JOINT	S5160122E② 1995-03		
17	HYDRAULIC CYLINDER	<del>S5170148E②</del> 1995-03	S5170148E	Refer to II
21	REDUCTION UNIT (TRAVEL)	<del>S5210203E②</del> 1995-03	S5210203E②	Refer to II
	REDUCTION UNIT (SWING)	<del>S5210327E②</del> 1995-03	S5210327E	Refer to II
50	ENGINE	<del>S5500023E</del> 1995-03	S5LC5001E	Refer to II
	Applicable Machines	LC03801- YC01101~		



# KOBELCO

## SHOP MANUAL

### CONTROL VALVE

#### TABLE OF CONTENTS

**13**

1. SPECIFICATIONS	
1.1 External Views .....	1
1.2 Specifications .....	1
2. CONSTRUCTION AND OPERATION	
2.1 Construction .....	3
2.2 Function .....	13
3. DISASSEMBLY AND REASSEMBLY	
3.1 General Precautions .....	29
3.2 Tools .....	20
3.3 Disassembly .....	30
3.4 Reassembly .....	40
4. MAINTENANCE STANDARDS	
4.1 Inspection of Components .....	44
5. TROUBLESHOOTING	
5.1 Control Valve .....	45
5.2 Relief Valve .....	47



## PREFACE



This valve is an integral multi-function structure containing direction control valves to control actuator motion by switching between circuits, relief valves to maintain circuit pressure within a safe pressure range, and port relief valves to prevent negative pressure.

Models	Applicable Machines	Notes	Models	Applicable Machines	Notes
SK3100E	LC03303~				
SK3100cLI	YC01101~				

Revision	Date of Issue	Remarks
First edition	March, 1995	S5130767E K

# 1. SPECIFICATIONS

## 1.1 EXTERNAL VIEWS



## 1.2 SPECIFICATIONS

Table 1

Item	Specification
Model	K3X15F306L (2436U2885FL)
Flow rate (6 bar/gal/min)	315×2 (85.2×5)
Max. pressure (kgf/cm <sup>2</sup> / psi)	350 (4980)
Main relief valve set pressure (kgf/cm <sup>2</sup> / psi)	300±5 (4270±50) / 335±5 (4760±70) at 200mm <sup>3</sup> /5.2gal/min
Port relief valve set pressure (kgf/cm <sup>2</sup> / psi)	350±5 (4970±50) at 300mm <sup>3</sup> /7.92gal/min
Miscellaneous set pressure (kgf/cm <sup>2</sup> / psi)	335±5 (4760±50) at 300mm <sup>3</sup> /7.92gal/min
Travel relief valve set pressure (kgf/cm <sup>2</sup> / psi)	350±5 (4970±50) at 1200mm <sup>3</sup> /31.7gal/min
Low pressure relief valve set pressure (kgf/cm <sup>2</sup> / psi)	32 <sup>-6</sup> / <sub>0</sub> (455 <sup>-8</sup> / <sub>0</sub> ) at 400mm <sup>3</sup> /10.6gal/min




Table 2

Part size	Tightening torque (kgf·cm / ft·lbf)	Part name	Description
F71	2250±250 (162±18)	P1	Pump P1 port
		P2	Pump P2 port
		Ab	Boom raise port
		Bb	Boom lower port
		Ac	Bucket dump port
		Rc	Bucket digging port
		Ar	Right travel port (forward)
		Bc	Right travel port (reverse)
		Al	Left travel port (forward)
		Bl	Left travel port (reverse)
		Aa	Arm digging port
		Ba	Arm extend port
		Aa2	Arm discharge return port
T2	Arm discharge return tank port		
PT3-4	1650±150 (119±11)	P3	Swing port
		PA	Arm conflux port
		PB	Boom conflux port
		(P4)	Option port
PF3-6	750±50 (54.2±3.8)	PAa	Arm digging pilot port
		PAb	Boom raise pilot port
		PAc	Bucket dump pilot port
		PBa	Arm extend pilot port
		PBc	Boom lower pilot port
		PBc	Bucket digging pilot port
		PAc	Right travel pilot port (forward)
		PBc	Right travel pilot port (reverse)
		PAc	Left travel pilot port (forward)
		PBc	Left travel pilot port (reverse)
		PAa2	Return pilot port for arm stretching
		Dr3	Drain port
		PF1-4	370±20 (26.7±1.4)
PB1	Boom raise conflux signal port		
Dr1	Drain port		
Dr2	Drain port		
Ps	Servo pressure port		
P1Sd	Variable recirculation cut-in Arm heavy digging		
P0p1	Option pilot port		
P0p2	Option pilot port		
P11	Negative control signal port		
P12	Negative control signal port		
P13	Swing pilot port		
PF1-9	170±20 (12.5±1.4)	P1s	Arm loading recirculation command port
		P1ga	Arm conflux sequence port (primary)
		P1gb	Arm conflux sequence port (secondary)
		P1gc	Arm conflux sequence port (secondary)
		PL1	Attachment boost pressure port
PL2	Attachment boost pressure port		
P1gd	Bucket conflux command port		
M10	380±10 (27.5±0.7)	T	Tank port

Fig. 1 External views of Control valve

## 2. CONSTRUCTION AND OPERATION

### 2.1 CONSTRUCTION (1) Control valve







Fig 2 (1/2) Sectional views of control valve




SECTION F-F  
ROOM CONFLUX CHANGEOVER VALVE



SECTION G-G




SECTION H-H




SECTION I-J



SECTION K-K



SECTION Q-Q  
ARM CONFLUX CHANGEOVER VALVE



SECTION R-R  
ARM T2

Table 3

Tightening torque kgf/cm. (l-lbs)	No.	NAME	Qty	Tightening torque kgf/cm. (l-lbs)	No.	NAME	Qty
	101	TRAVEL BLOCK	1		331H	SPRING SEAT (TRAVEL)	4
	102	CASING (A)	1		332	SPRING SEAT (ARM, BOOM, BUCKET)	6
	103	CASING (B)	1		333H	SPACER BOLT (TRAVEL)	2
	104	CASING (T2)	1	170 ± 20 (12.3 ± 1.4)	334H	STOPPER (TRAVEL)	2
100 ± 15 (7.2 ± 1.0)	152	PLUG	39		335	STOPPER (ARM, BUCKET)	3
375 ± 25 (27.1 ± 1.8)	153	PLUG	3	170 ± 20 (12.3 ± 1.4)	336	SPACER BOLT (ARM, BOOM, BUCKET)	4
750 ± 50 (54.2 ± 3.6)	154	PLUG	6		337	ROD (CONFLUX BYPASS CUT)	5
275 ± 25 (19.9 ± 1.8)	155	PLUG	4		338	STOPPER (BOOM)	1
220 ± 20 (15.9 ± 1.4)	157	PLUG	2		351	ORIFICE (Ø0.7(0.028"))	4
88 ± 12 (6.4 ± 0.8)	158	PLUG	6	170 ± 20 (12.3 ± 1.4)	353	PISTON (ARM COVER)	1
	161	O RING	12		354	SPRING (ARM COVER)	1
	162	O RING	9		371	SPRING (ARM, BOOM, BUCKET)	3
	163	O RING	3		372	SPRING (BUCKET)	1
	164	O RING	6		373	SPRING (ARM CONFLUX)	1
	166	O RING	2		374	SPRING (ARM CONFLUX)	2
1250 ± 250 (90.4 ± 18.1)	168	O RING	6		377	SPRING (ROOM CONFLUX)	1
	171	PLUG	1		391	SPOOL (ARM CONFLUX)	1
	172	O RING	1		511	POPPET (LOAD CHECK VALVE)	9
	201	SPRING COVER	4		512	BALL (SHUTTLE VALVE)	6
	202H	SPOOL COVER (TRAVEL)	2		513	POPPET	1
	203	SPOOL COVER	3		521	SPRING (LOAD CHECK VALVE)	10
	205	ARM COVE	1		541	SEAT L=18.7(SHUTTLE VALVE)	1
	207H	SPRING COVER (TRAVEL)	2		542	SEAT L=27.7(SHUTTLE VALVE)	2
750 ± 50 (54.2 ± 3.6)	251	PLUG	5		543	SEAT L=33.7(SHUTTLE VALVE)	1
	261	O RING	4		544	SEAT L=37.7(SHUTTLE VALVE)	2
	263	O RING	4		551	PLUG RO M27×1.5	12
	264	O RING	4	1650 ± 150 (119 ± 11)	552	PLUG RO M12×1.5	7
	265	O RING	5	113 ± 12 (8.2 ± 0.9)	553	PLUG RO 1	2
	266H	O RING	4	2250 ± 250 (163 ± 18)	561	O RING	12
275 ± 25 (19.9 ± 1.8)	273	SOCKET BOLT	24		562	O RING	7
	301H	SPOOL (TRAVEL)	2	750 ± 50 (54.2 ± 3.6)	563	O RING	2
	302	SPOOL (ARM)	1	750 ± 50 (54.2 ± 3.6)	601	MAIN RELIEF VALVE	2
	303	SPOOL (BOOM)	1	750 ± 50 (54.2 ± 3.6)	602	TRAVEL RELIEF VALVE	2
	304	SPOOL (BUCKET)	1	750 ± 50 (54.2 ± 3.6)	603	PORT RELIEF VALVE	3
	305	SPOOL (TRAVEL STRAIGHT)	1	750 ± 50 (54.2 ± 3.6)	604	PORT RELIEF VALVE	3
	306	SPOOL (BYPASS CUT)	1		611	LOW PRESSURE RELIEF VALVE (NEGATIVE CONTROL)	2
	307	SPOOL (BOOM CONFLUX)	1		612	POPPET	1
	308	ARM CONFLUX SEQUENCE	1	1650 ± 150 (119 ± 11)	711	PLUG RO 3/4	1
	309	SPOOL (ARM T2)	1	3200 ± 200 (231 ± 14)	712	O RING	1
	310	BYPASS CUT SPOOL	1	3200 ± 200 (231 ± 14)	973	SOCKET BOLT M18×1.5×235	2
	323	SPRING (ARM, BOOM T2)	3		974	SOCKET BOLT M:8×1.5×145	2
	324	SPRING (TRAVEL STRAIGHT)	1		975	NAMEPLATE	1
	325	SPRING (TRAVEL STRAIGHT)	1		976	SOCKET BOLT M:18×1.5×150	2
	326	SPRING (BYPASS CUT)	2				
	327	SPRING (BYPASS CUT)	2				
	328H	SPRING (TRAVEL)	2				
	329H	SPRING (TRAVEL)	2				
	330	SPRING (ARM T2)	1				

Fig. 2 (2/2) Sectional views of control valve

(3) Arm spool



Fig. 3

Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty	Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty
	302	SPOOL	1		338	O RING	1
	312	SUB SPOOL	1		341	BUSHING	1
	313	PISTON	1		342	SLEEVE (1)	1
	314	SLEEVE (2)	1		343	SPACER BOLT	1
	328	SPRING	1		349	STOPPER (1)	1
	329	SPRING	1		358	SPRING SEAT	1
	338	SPRING	1		359	PLUG	2

(3) Boom spool




Fig. 4

Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty	Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty
	303	SPOOL	1		330	SPRING	1
	315	PLUNGER 1	1		340	SPRING	1
	316	PLUNGER 2	1		345	ROD	1
	317	PLUNGER 3	1		352	PLUG	2
	320	SPRING	1				

(4) Recirculation cut sequence valve



Fig. 5

Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty	Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty
	440	O RING	1	750 ± 50 (54.2 ± 3.6)	446	SPOOL	1
	441	O RING	1		447	PLUG	1
	442	SPOOL	1	350 ± 50 (25.3 ± 3.6)	448	SPRING	1
	443	PISTON	2		449	STOPPER	1
	444	SLEEVE	1		450	O RING	1
	445	BUSHING	1				

(5) Main relief valve (two-step relief) (501)




Fig. 6

Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty	Tightening torque kgf·cm (ft·lbs)	No.	NAME	Q'ty
750 ± 50 (54.2 ± 3.6)	165	BACKUP RING	1	280 ± 30 (20.3 ± 2.2)	430	PISTON	1
	420	BODY	1		431	SPRING SEAT	1
	421	PLUG	1		432	FILTER	1
	422	ADJUSTING SCREW	1		433	POPPET	1
	423	O RING	1		434	SPRING	1
	424	O RING	1		435	SPRING SEAT	1
	425	O RING	1		436	O RING	1
	426	O RING	1		437	ADJUSTING SCREW	1
	427	PLUNGER	1		438	LOCK NUT	1
	428	SPRING	1		250 ± 30 (20.3 ± 2.2)	439	LOCK NUT
429	SEAT	1					

(6) Travel relief valve (602)




Fig. 7

Tightening torque kgf-cm (ft-lbs)	No.	NAME	Q'ty
750±50 (54.2±3.6)	101	BODY	1
	161	O RING	1
	162	O RING	1
	201	PLUG	1
750±50 (54.2±3.6)	261	O RING	1
	511	PLUNGER	1
	521	SPRING	1
	611	POPPET	1
	612	SPRING SEAT	1
	613	SPRING SEAT (2) *	1
	614	SPRING SEAT	1
	621	SPRING	1
	641	SEAT	1
	651	ADJUSTING SCREW	1
300±20 (21.7±1.4)	663	O RING	1
	671	LOCK NUT	1
	691	FILTER	1

(7) Port relief valve (603, 604)




Fig. 8

Tightening torque kgf-cm (ft-lbs)	No.	NAME	Q'ty
750±50 (54.2±3.6)	163	O RING	1
	164	BACKUP RING	1
	401	BODY	1
	402	O RING	1
750±50 (54.2±3.6)	403	O RING	1
	404	PLUG	1
	405	O RING	1
	406	PLUNGER	1
	407	SPRING	1
	408	SPRING	1
	409	SEAT 1	1
	410	POPPET	1
	411	SPRING SEAT	1
	412	SPRING	1
300±20 (21.7±1.4)	413	SEAT 2	1
	414	ADJUSTING SCREW	1
	415	O RING	1
	416	LOCK NUT	1
	417	SPRING SEAT	1
	418	SPRING SEAT	1
	419	FILTER	1

(8) Negative control (low pressure) relief valve (611)




Fig. 9

Tightening torque kgf-cm (ft-lbs)	No.	NAME	Q'ty
	470	POPPET	1
	471	SPRING	1
	472	BUSHING	1
	473	FILTER	1




Table 4

No.	Item
23	SOLENOID VALVE
28	SOLENOID VALVE
51	MAIN PASSAGE (RIGHT)
52	BYPASS CIRCUIT (RIGHT)
53	PARALLEL CIRCUIT (RIGHT)
54	MAIN PASSAGE (LEFT)
55	BYPASS CIRCUIT (LEFT)
56	PARALLEL CIRCUIT (LEFT)
60	SERVO PRESSURE CIRCUIT
61	NEGATIVE CONTROL SIGNAL CIRCUIT (P1)
62	NEGATIVE CONTROL SIGNAL CIRCUIT (P2)
63	SIDE BYPASS CIRCUIT (LEFT)
64	SIDE BYPASS CIRCUIT (RIGHT)
66	BOOM CONFLUX SIGNAL CIRCUIT
67	SWING SIGNAL CIRCUIT
71	NEGATIVE CONTROL ORIFICE
301H	TRAVEL SPOOL
302	ARM SPOOL
303	BOOM SPOOL
304	BUCKET SPOOL
305	TRAVEL STRAIGHT CHANGEOVER SPOOL
306	BYPASS NEUTRAL CUT SPOOL
307	BOOM CONFLUX SPOOL
308	ARM CONFLUX SEQUENCER
309	ARM T2 SPOOL
310	BYPASS NEUTRAL CUT SPOOL
351	ORIFICE
391	ARM CONFLUX SPOOL
511	POPPET (LOAD CHECK VALVE)
512	BALL
513	POPPET (FOR TRAVEL STRAIGHT RESTRICTION)
601	MAIN RELIEF VALVE
602	TRAVEL RELIEF VALVE
603	PORT RELIEF VALVE
604	PORT RELIEF VALVE
61	NEGATIVE CONTROL RELIEF VALVE
612	POPPET (LOGIC VALVE)



## 2.2 FUNCTION

### 2.2.1 AT NEUTRAL

#### (1) Minimum flow by negative control signal

##### 1) Main circuit in H, S, PC modes

When all spools are at neutral, the oil discharged by the hydraulic pump (P1) passes through the main path (51), the bypass circuit (52) that goes through the RH travel and boom, bucket spools and negative control relief (611) and returns to the hydraulic tank via the tank port (T).

The pressure upstream of negative control relief (611) rises to this set relief pressure. The pressure from the port Pi1 is admitted to the regulator (Pi1) of the hydraulic pump in order to control the maximum flow of the oil discharged by the hydraulic pump. (negative flow control)

Likewise, the oil discharged by hydraulic pump (P2) passes through the main path (54), the bypass circuit (55) that goes through the arm T2 and arm spools and the negative control relief valve (611) and is brought back to the hydraulic tank via the tank port (T).

The increased port Pi2 pressure by negative control relief (611) enters the pump regulator Pi2 and controls negative flow.

#### <Pilot circuit>

The oil discharged by gear pump (P3) enters port P5 (Refer to section F-F) and runs to the side bypass circuit (63, 64) by way of orifice (351), but is shut off to the lower stream as the travel spool circuit located in the uppermost stream is closed.




Fig. 11

## 2.2.2 TRAVEL

### (1) Travel independent (forward) by two pumps

#### 1) Main circuit

If pilot port PAr of the right travel spool is pressurized, bypass circuit (52) is shut off. The oil delivered by pump (P1) runs to the right travel motor from port (Ar).

Meanwhile, the oil returned from the right travel motor passes through port (Br), low pressure circuit (D) and tank port (T) and returns to the hydraulic tank.

In this case, since the negative control relief valve is located in the lowermost stream, shift of an upstream spool shuts off oil stream, i.e. negative flow control is cut off.

#### 2) Pilot circuit

Shift of travel spool (301H) allows servo pressure (60) to pass port (PS) and orifice (361) and connect with port (E). However, since the oil downstream is connected with the drain circuit, pressure does not rise and the travel straight changeover spool (305) does not change over. (See section B-B.)

If the pilot port PBr of the spool is pressurized, the oil runs in the opposite direction. The pump (P2)-left travel spool side falls in the same condition.




Fig. 12

(2) Travel straight in composite operation

1) Travel/Attachment

Travel straight action in composite operation is effected by pump (P2). Pump (P1) actuates the attachment by changing over the travel straight spool (306).

For instance, the boom and travel spools change over when travel forward and boom raising motions are performed.

The increased pressure of the side bypass circuit (63, 64) enters chamber E of section B-B and actuates spool (305).

<Pilot circuit>

The path from the bypass circuit to tank port T is shut off by shifting the neutral cut spool (306), (310). The increased neutral cut spool changeover pressure is admitted to port PS of the control valve.

The primary pilot pressure passes through the travel spool of the side bypass circuit and is shut off by the boom spool. The bypass circuit pressure thus raised by the shutoff enters chamber E, E' of section E-E, E'-E' and changes over neutral cut spool (306), (310).

<Main circuit>

When the travel straight spool is changed over, the hydraulic pressure discharged by pump (P1) is prevented from flowing into the main circuit and connects with the parallel circuit (53). (See section B-B.)


In the meantime, the pressure from pump (P2) is connected with the RH and LH main circuits. Pump (P1) actuates the attachment to perform boom raising action, while pump (P2) operates the RH and LH travel motors.

2) Travel and swing

If travel and swing motions are executed at the same-time, swing signal pressure closes poppet (612) of the logic valve and raises the side bypass circuit pressure.


In the same way that occurs in the travel and attachment operation, the increased side bypass circuit pressure changes over neutral cut spool (306), (310) and travel straight spool (305).

Shift of the travel straight spool causes pump (P1) to operate the swing motor and causes pump (P2) to actuate the RH and LH travel motors.




SECTION B-B

Fig. 13



SECTION E-E

Fig. 14



SECTION E'-E'

Fig. 15

(3) Function of travel straight valve in Fig. 16, travel straight spool (305) is pressed down to the bottom end by spring (324), (325). When only attachment or travel motion is performed, spool (305) is fixed by position [ I ]. If attachment and travel motions are carried out at same time, spool (305) shifts to take position [ II ] as the side bypass circuits (63), (64) pressure is increased




Fig. 16 Function of travel straight valve




Fig. 17

### 2.2.3 BUCKET ACTION

#### (1) Bucket digging action

If bucket digging motion is performed, secondary proportionate pilot pressure PA2 enters port (PBC) and transfers bucket spool (304) to the right.

When spool (304) is shifted, the oil discharged by pump (P1) enters parallel circuit (53) from bypass circuit (52), pushes check (511) open, goes out to port BC and is supplied to cylinder head (H).

In the meantime the oil which returns from the cylinder head passes through port (AC) and the notch in the outer circumference of the spool and returns to the hydraulic circuit by way of low pressure circuit (D) and tank port (T).

#### (2) Bucket discharge motion

In the same way as bucket digging motion, if bucket discharge motion is performed, secondary proportionate pilot pressure PB2 enters port (PAC) and shifts spool (304) to the left.

The oil discharged by pump (P1) enters parallel circuit (53), pushes poppet (511) open and is supplied to cylinder rod (R) from port (AC).

Meanwhile, the oil which returns from the cylinder head passes through port (BC) and the notch in the outer circumference of the spool and is brought back to the hydraulic tank from low pressure circuit (D) and tank port (T).




Fig. 18

#### (3) Bucket conflux

To speed up the bucket motion, the travel straight spool is changed over in single bucket operation to combine the pressure from P2.

If bucket motion is performed in the hydraulic circuit, the pilot pressure  $50\text{kg/cm}^2$  (71psi) is pressurized at port Pigd.

Since Pigd connects with side bypass circuit (53) and the circuit to Dr is shut off during bucket operation, the pilot pressure shifts the travel straight spool.

The result is that the oil discharged from P2 passes through the travel straight spool,

connects with the bypass path, enters the parallel circuit via check valve (513) and combines with the oil discharged from the P1 side.

During composite operation of bucket and attachment motions, the pilot pressure, which is not pressurized against port Pigd via the valve on external piping, functions the same way as in normal single operation.

During bucket discharge motion also, conflux function works the same way as in bucket digging motion.

## 2.2.4 BOOM ACTION

### (1) Boom raising 2-pump conflux motion

If boom raising operation is performed, secondary proportionate pilot pressure PA1 acts on port (PAb) and shifts the boom spool (303) to the left and at the same time the pressure passes through the solenoid proportionate reducing valve and acts upon pilot port (P1H) of the LH block end section and changes over LH neutral cut spool (310) via boom conflux changeover spool (307) (section F'-F) and shuttle ball (512).

The oil discharged by pump (P1) runs to bypass circuit (52) past main path (51), enters parallel circuit (50), pushes poppet (511) open, enters chamber E in boom spool (303) and chamber F in the boost check valve, presses the boost check valve leftward as illustrated, passes through the notch in the outer

circumference of spool (303) and is supplied to boom cylinder head (H) from port (Ab).

Meanwhile, the oil which returns from the cylinder rod passes through port (Bb) and the notch in the outer circumference of spool (303), runs to tank port (T) from low pressure circuit (14) and returns to the hydraulic tank.

On the other hand, the oil discharged pump (P2) runs to bypass circuit (55) of the LR block, but since LH neutral cut valve (306) is closed, the oil pushes check valve (511) open and enters parallel circuit (56).

However, since boom conflux changeover spool (307) is open, the pressure pushes check valve (511) open and is supplied to the cylinder head from boom conflux port (PB). (boom parallel conflux)




Fig. 19

(2) Fixed recirculation function for boom lowering  
 If boom lowering motion is performed, the secondary proportionate pilot pressure acts upon port (PBb), transfers boost spool (303) rightwards.

The pressurized oil discharged by pump (P1) enters parallel circuit (53), pushes poppet (511) open, enters the U-shape path, passes through the notch in the outer circumference of spool (303) and is supplied to the cylinder rod from port (Rb).

Meanwhile, the oil which returns from cylinder head (H) runs into spool (303) past port

(Ab) and the circular notch of spool (303). Since the oil thus returned is sufficiently pressurized by the weight of the boom, arm, etc., it passes through the inside of the spool, pushes the poppet on the left as illustrated, passes through the outer circumference of the spool and is supplied to the boom cylinder rod as hydraulic oil for boom lowering action. (fixed recirculation function for boom action)  
 Extra hydraulic oil pushes the boost check valve open and returns to the low pressure circuit (D).




Fig. 20

(4) Variable loading mode operation

Boom raising and swing speeds may be selectively controlled by turning the loading mode potentiometer.

If the loading mode potentiometer is turned clockwise, the electric current of the electromagnetic proportionate reducing valve falls which in turn lowers the PB1 port circuit pressure from the secondary pressure P2 port of the proportionate reducing valve. The amount of oil combined from notch A to B as the stroke of boom conflux spool (307) decreases. If the pressure controlled by the electromagnetic proportionate reducing valve falls, the oil combined from notch A to B is shut off.

Consequently, boom conflux action by the secondary pilot pressure of the electromagnetic proportionate reducing valve stops. This brings operating speed to a single swing speed even in simultaneous swing/boom operation.



Fig. 21 Loading mode potentiometer




Fig. 22 Boom conflux spool



## 2.2.5 ARM ACTION

### (1) Arm discharge 2-pump conflux function

If arm discharge action is performed, the secondary proportionate pilot pressure PB3 acts upon port (PBa) and port (PBa2) of the arm T2 section and shifts arm spool (302) and arm T2 spool (309) to the right.

At the same time, the secondary pressure acts upon pilot port (PA1) of the RH end section and changes over RH neutral cut spool (306) (section E'-E') via arm conflux changeover spool (301) (section Q-Q) and ball (512).

The pressurized oil discharged by pump (P2) runs to bypass circuit (55) past main path (54), pushes poppet (511) open, runs to parallel circuit (56), pushes poppet (511) open, goes through the notch in the outer circumference of spool (302) and is supplied to

the cylinder rod from port (Ba).

The pressurized oil discharged by pump (P1) pushes arm conflux check valve poppet (511) (section E'-E') by way of bypass circuit (52) of the RH block and arm conflux changeover spool (391) and is combined to the cylinder rod from arm conflux port (PA). (arm tandem conflux.)

In the meantime, the oil which returns from the cylinder head goes through port (Aa) and the outer circumference of arm spool (302) and returns to port T or the oil passes through port (Aa2) and the outer circumference of arm spool T2 (309), runs to tank port (T2) and returns to the tank.




Fig. 23

(2) Variable recirculation action for arm digging (at light load)

If you do arm digging operation, the secondary proportionate pilot pressure PA3 acts upon port (PAa) and moves arm spool (302) to the left. At the same time, a boost pressure of  $7\text{kgf/cm}^2$  (99.5psi) is constantly working on port (PiS). The pressure enters the spring chamber G of sub spool (312) inside arm spool (302) and pushes the arm spool to the left. The pressure also works on the variable restrictor.

The oil discharged by pump (P2) flows into bypass circuit (55) past main path (54), pushes poppet (511) open, runs into parallel circuit (56), pushes poppet (511) open, goes through the U-shape path and the notch in the outer circumference of arm spool (302) and is supplied to the cylinder head through port (Aa).

<Variable recirculation action for arm digging>

In the meantime, since the oil which returns from the cylinder rod is sufficiently pressurized by the weight of the arm, etc., the pressure is admitted to spool (302) from port (Ba) and pushes the arm check poppet rightwards via sub spool (312) as illustrated. Therefore the oil passes through the notch in arm spool (302) and the U-shape path and is supplied to the cylinder head once again as hydraulic oil for arm digging operation. This is what is called the variable recirculation function for arm action.

Part of the oil which returns from the cylinder rod passes through the slanted hole in sub spool (312) and is released to the hydraulic tank by way of low pressure circuit (D) and tank port (T). This is to avoid a rise in the cylinder inside pressure.




Fig. 24

(3) At arm digging (at heavy load)

The machine needs quick and strong power for arm digging operation. For this reason, oil streams by multiple pumps are combined to dissipate back pressure produced by the arm recirculation function.

First of all, sequence spool (303) is switched over automatically as pump pressure (P<sub>2</sub>) on the front side rises.

The sequence spool allows the sequence conflux action and the variable recirculation function cut action to work.

<Sequence conflux action>

The pump P2 circuit pressure is admitted to chamber Pd of the recirculation cut sequence valve. The pressure pushes piston (443) to the left as the P2 pump circuit pressure rises till it overcomes the spring action at which spool (303) is switched over.

If the spool is switched over, ports P<sub>1ga</sub> and P<sub>1gc</sub> that are connected to the secondary proportionate pilot pressure PA3 get through to each other, with the result that the pressure re-enters port P<sub>1gb</sub>.

The pilot pressure which has entered port P<sub>1gb</sub> switches over neutral cut spool (306) and travel straight spool (306) to put the streams by pumps P1 and P2 together.

<Variable recirculation function cut action>

If the sequence spool is pushed to the left end, port P<sub>1cd</sub> get through with side hole P and drain port Dr.

Consequently, the pressure of the variable recirculation command circuit flows from control valve port P<sub>1c</sub> to P<sub>1cd</sub> to Dr to tank in which process the pressure falls.

Since spring chamber G in the arm spool also gets through with port P<sub>1c</sub>, the pressure becomes the tank pressure.

Meanwhile, the main circuit pressure acting on the arm head (H) side is admitted to chamber E. It pushes piston (313) and transfers sub spool (312) in arm spool (302) to the left.

If sub spool (312) is transferred, it plugs up the arm recirculation hole in arm spool (302) to nullify the variable recirculation. As the result, all of the oil which returns from the cylinder head is brought back to the hydraulic tank.

<Main circuit>

The combined oil streams by pumps pushes poppet (511) open through parallel circuit (56) and goes out to the U-shape path.

The pressurized oil which has goes out to the U-shape path connects with port Aa on the notch in the outer circumference of spool (302) and is supplied to the cylinder head.

In the meantime, the oil which returns from the cylinder rod (R) side is not subject to variable recirculation and connects port Ba with path D in the notch of the outer circumference of arm spool (302).




Fig. 25

(4) Swing preferential action at arm digging

The swing control valve is a special valve provided separately. The pump port is connected with control valve port P3 and shares a parallel circuit with the arm operation section.

When arm digging and swing motions are performed at the same time, the proportionate secondary pilot pressure is admitted to chamber G in order to use stabilized oil for swing preferential action and shifts sub spool (312) to the left so as to perform forced recirculation that holds the recirculation circuit even if arm digging pressure rises.

The result is that the P2 pump oil is reduced to the cylinder side and is supplied preferentially for swing motion.

<Pilot circuit action>

Regarding the arm action, refer to the foregoing paragraph.

For arm digging/swing operation, the proportionate secondary pilot pressure is combined with the oil in port Pi3 through port Pi3.

The proportionate secondary pilot pressure which enters port Pi3 passes through restrictor (351) while pushing logic valve (312), is combined with the boost pressure coming from port PiS and pushes arm sub spool (312) to the right.

At the same time, the secondary pilot pressure which enters port Pi3 switches neutral cut valve (310) over by way of ball (312) in section E-E.

<Main circuit action>

If sub spool (312) is pushed hard to the left end by pilot circuit action, the oil which returns from the arm cylinder rod side passes through the oblique hole in the sub spool, with the result that the pressurized oil which has returned to tank port (T) from low pressure circuit (D) is hard to go back.

The result is that pressurized oil is preferentially supplied to the swing side through the recirculation circuit, even though the pressure on the arm cylinder head side rises above the swing operating pressure. This is called swing preferential circuit.




Fig 26

### 2.2.6 SWING ACTION (SEE FIG.30)

If swing action is performed, the higher of proportionate secondary pilot pressures is selectively chosen in the swing control valve, goes out of port P<sub>1</sub>, enters port P<sub>13</sub> of the control valve, actuates LH neutral cut valve (310) and closes bypass circuit (55).

The pressurized oil discharged by pump (P2) enters bypass circuit (55) past main path (54), but since LH neutral cut spool (310) is closed, the pressure pushes check valve (511) open, enters parallel circuit (56), gets out of port P<sub>3</sub> and is supplied to the swing motor via the swing control valve.

In the meantime, the oil which returns from the swing motor goes directly back to the hydraulic tank from the swing control valve and through the return circuit, instead of going through the control valve.

### 2.2.7 ATTACHMENT BOOST PRESSURE

When the attachment boost pressure button on the grip of the bucket control lever is pressured, the solenoid valve (28) for attachment boost pressure is actuated and pilot pressure flows to ports PL1 and PL2, raising the relief pressure of the main relief valve (601) to increase retraction power.




Fig. 27

### 2.2.8 ACTION OF MAIN RELIEF VALVE AND TRAVEL RELIEF VALVE

#### (1) Action of main relief valve

The main relief valve is built between the parallel circuit and the low pressure circuit and functions as follows.

- 1) Pressurized oil is filled up to the inside chamber A through restrictor hole (B) of main poppet (427)

Therefore, plunger (427) is seated securely against body (420).




Fig. 28

- 2) If the pressure in parallel circuit (P) reaches the action of spring (434), it passes through restrictor hole (B), pushes poppet (438) open and flows to low pressure circuit (R) via slit (D).




Fig. 29

- 3) When poppet (438) opens, the pressure in chamber A falls. This opens main poppet (427) and the pressure at port (P) runs directly to low pressure circuit (R). (The relief valve works.)




Fig. 30

- 4) Boost pressure  
If you press the attachment boost pressure button, pilot pressure enters the PL1 and PL2 port  
The pilot pressure pushes piston (430) to the left to increase the action of spring (434). This change a relief set pressure to high pressure.




Fig. 31

- (2) Action of travel relief valve  
The travel relief valve is located between the pump port and the low pressure path.  
The function is the same as para. 1) - 3) of the main relief valve and therefore left out herein.

### 2.2.9 ACTION OF PORT RELIEF VALVE

The port relief valve is located between the cylinder port and the low pressure path and functions as both a relief valve and an anti-cavitation check valve, as mentioned below.

(1) As a relief valve

1) Oil flows through passage A in seat 1 (409), then through throttling passage B in the main poppet (406), and fills interior chamber C, forcing the main poppet (406) securely against seat 1 (409).




Fig. 32

2) When the pressure at port P overcomes the set force of the spring (412), oil flows through throttling passage D, forcing the poppet (410) open, flows around the poppet (410), passing through passages E and F to the low pressure circuit R.




Fig. 33

3) As the poppet (410) opens, the pressure in chamber C drops, and the main poppet (406) opens, allowing oil at port P to flow to the low pressure circuit R.




Fig. 34

(2) As an anti-cavitation valve

If cavitation occurs at port P, oil from the low pressure circuit R is supplied to port P.

If the pressure at port P drops below that at low pressure port R, pressure acts on the area between the diameter of the seating portion of the main poppet (406) and the diameter of seat 1 (409), moving seat 1 (409) to the left.

Consequently, enough oil flows out from low pressure port R, passing between the main poppet (406) and seat 1 (409), and enters port P to fill the void.




Fig. 35

### 2.2.10 ACTION OF RECIRCULATION CUT SEQUENCE VALVE

When pump pressure (Pd) rises, piston (443) moves to the left. Spool 1 (442) and spool 2 (446) move to the left also.

When spool 1 (442) moves to the left, the arm contracting pilot pressure in port Pige enters the travel straight valve command pressure port past port Pige and changes over the travel straight valve spool.

When spool 2 (446) moves to the left, the recirculation signal circuit Pisd port connects with drain port Dr, whereby recirculation signal pressure falls.




Fig. 36

### 2.2.11 LOW PRESSURE RELIEF VALVE (NEGATIVE CONTROL RELIEF VALVE)

A low pressure relief valve is incorporated between the downstream passage from the center bypass, and the low pressure passage. It operates as described below.

- 1) When pressure at port P is below the set force of the spring (471), poppet (470) is positioned as shown in right figure. The poppet (470) has a pressure bearing part  $\varnothing A$  and  $\varnothing B$ . Part  $\varnothing A$  is canceled by damping chamber E. As the result the pressure bearing area equals  $\varnothing B - \varnothing A$ .
- 2) Under this condition, the oil at port P flows through throttling passage C to port R. This throttling passage C does not become clogged because a filter (473) is installed upstream.
- 3) When the pressure at port P overcomes the set force of the spring (471), the poppet (470) moves to the left; the oil at port P flows past the outer circumference of the poppet (470) to the low pressure circuit (R).




Fig. 37




Fig. 38



### 3. DISASSEMBLY AND REASSEMBLY

#### 3.1 GENERAL PRECAUTIONS

- 1) As all the hydraulic components are precisely machined, it is essential to carry out disassembly and reassembly in an especially clean location.
- 2) When handling the control valve, take special care to prevent the entry of foreign matter, such as dust or sand.
- 3) Cap each part of the control valve before removing the valve from the machine. Before disassembly, confirm that each cap is in place and then clean the exterior of the assembly. Use an appropriate workbench. Lay a clean sheet of paper, rubber mat, or the like over the workbench.
- 4) When carrying or moving the control valve, hold the body, and never put pressure on a lever, an exposed spool, or the end cover. Handle the valve with care.
- 5) Tests (for relief characteristics, leaks, overload valve setting, flow resistance, etc.) that are desired after disassembly and reassembly require hydraulic testing apparatus. For this reason, do not disassemble hydraulic units that you are capable of disassembling but cannot test or adjust. Prepare beforehand clean solvent, hydraulic oil, grease, etc. .

#### 3.2 TOOLS

Prepare the following tools before disassembling the control valve.

Table G

No.	Name	Qty	Remarks
a	Vise	1	
b	Box end wrench	1 of each size	22,24,27,30mm
c	Hex key wrench	1 of each size	4,5,6,8,10,12,14,17,19mm
d	Sealing tape	1	
e	Loctite #241	1	
f	Spatula	1	
g	Tweezers	1	
h	Single-ended wrench	1 of each size	32,41,46mm

### 3.3 DISASSEMBLY

The numbers in parentheses following each part name in the text correspond to the numbers in the external views in Fig. 2, 3, 4, 5, 6, 7, 8 and 9 in Section 2.1.

1) Place the control valve on the workbench with the ports facing upward.

- Disassemble the valve in a clean location, and be careful not to damage flange surfaces or plate mounting surfaces.
- "Top", "Right" and "Front" in the photographic illustrations represent the positions of the machine with valves.




Fig. 39 Outside view from top and front right




Fig. 40 Outside view from bottom and front left




Fig. 41 Outside view from bottom and rear right

### 3.3.1 BUCKET SPOOL

- 1) Remove the socket bolts (273) and remove the spring cover (201). Pull the spool assembly made up of the bucket spool (304), spring seat (332), springs (371,372), and stopper (335) from casing B (103).

- Take care not to damage casing B (103) when pulling the spool assembly from the casing.
- Mark the spool with a tag or the like to prevent it from being confused with other spools during reassembly; it differs in shape from the others, and has a particular direction in which it must be reinstalled.




Fig. 42 Drawing the bucket spool

- 2) Clamp the center of the bucket spool (304) in a soft-jaw vise. Remove the spacer bolt (336), then remove the spring seat (332), springs (371,372), and stopper (335) from the bucket spool (304).

- Take care not to make the vise too tight as it might deform the bucket spool (304).




Fig. 43 Removing the spring

### 3.3.2 BOOM SPOOL

- 1) Remove the socket bolts (273), then remove the spring cover (201). Pull the spool assembly made up of the boom spool (303), spring seat (332), springs (371,372), and stopper (335) from casing B (103).

- Take care not to damage casing B (103) when pulling the spool assembly from the casing.
- Mark the spool with a tag or the like to prevent it from being confused with other spools during reassembly; it differs in shape from the others, and has a particular direction in which it must be reinstalled.




Fig. 44 Drawing out the boom spool

- 2) Clamp the plug (352), located at the end of the spool assembly, in a vise. Remove the spacer bolt (336), then remove the spring seat (332), springs (371,323) and stopper (338) from the boom spool (303).




Fig. 45 Removing the spring

- 3) Do not disassemble the boom spool (303) any further, unless there is a particular problem with the spool.

If it definitely must be disassembled, follow this procedure:

- a) Clamp the center of the boom spool (303) in a soft-jaw vise, and using a hex and wrench 24mm (0.9in) across the flats, remove the plug (352)
- b) Disassemble plunger 1 (315), plunger 2 (316), plunger 3 (317), spring (boom lower) (320), spring (boom oil recirculation) (330), spring (boost check) (340), and rod (345).

- Take care not to make the vise too tight as it might deform the boom spool (303).




Fig. 46 Disparting the boom spool

### 3.3.3 ARM SPOOL

- 1) Remove the socket bolts (273) and remove the spring cover (201). Pull the spool assembly made up of the arm spool (302), spring seat (332), springs (371,323) and stopper (335) from casing A (102).

- Take care not to damage casing A (102) when pulling the spool assembly from the casing.
- Mark the spool with a tag or the like to prevent it from being confused with other spools during reassembly; it differs in shape from the others, and has a particular direction in which it must be reinstalled.




Fig. 47 Drawing out the arm spool

- 2) Clamp the plug (359), located at the end of the arm spool (302), in a vise. Remove the spacer bolt (336), then remove the spring seat (332), springs (371,323) and stopper (335) from the arm spool (302).
- 3) Do not disassemble the arm spool (302) any further, unless there is a particular problem with the spool.  
If it definitely must be disassembled, follow this procedure:

- a) Clamp the center of the arm spool (302) in a soft-jaw vise, and using a box end wrench 24mm (0.9in) across the flats, remove the plug (359) and bushing (341).

- Take care not to make the vise too tight as it might deform the arm spool (302).




Fig. 48 Removing the spring




Fig. 49 Disparting the arm spool

- b) Remove the plugs (359,341), then pull out the arm spool sub-spool (312) as an assembly. Remove the piston (319) along with the bushing (341).




Fig. 50 Drawing out the sub spool

- c) Clamp the arm spool sub-spool (arm) (312) in a soft-jaw vise. Remove the spacer bolt (343), then remove the spring (329) and spring seat (358).

- Take care not to damage the arm spool sub-spool (312).




Fig. 51 Drawing out the sub spool

- d) The assembly made up of the arm spool sub-spool (312), sleeve 2 (314), spring (arm oil recirculation) (328), sleeve 1 (343), stopper (349), and O ring (339) cannot be disassembled any further.

### 3.3.4 DISPARTING THE ARM T2 SPOOL

- 1) Loosen socket bolt (273), remove spring cover (201) and draw out from casing T2 (104) the spool assy that consists of spool (arm T2) (309), spring seat (332), springs (323,330) and stopper (335).

- When drawing out the spool assy from casing T2 (104), take care so as not to score casing B (103).
- Mark the spool with a tag or the like to prevent it from being confused with other spools during reassembly; it differs in shape from the others, and has a particular direction in which it must be reinstalled.

### 3.3.5 DISASSEMBLING THE TRAVEL SPOOL

- 1) Loosen socket bolt (278), remove spring cover (207H) and draw out from travel block (101) the spool assy that consists of spool (travel) (301H), spring seat (331H), springs (328H,329H) and stopper (334H).

- When drawing out the spool assy from travel block (101), use care so as not to damage travel block (101).
- Mark the spool with a tag or the like to prevent it from being confused with other spools during reassembly; it differs in shape from the others, and has a particular direction in which it must be reinstalled.




Fig. 52 Removing the travel cover

- 2) Clamp the center of the travel spool (301H) in a soft-jaw vise. Remove the spacer bolt (333H), then remove the spring seat (331H), springs (328H, 329H), and stopper (334H) from the travel spool (301H).

- Take care not to make the vise too tight as it might deform the travel spool (301H).



Fig. 53 Drawing out the travel spool

### 3.3.6 DISASSEMBLING THE SEQUENCE VALVE

Draw out arm conflux sequence valve (308).



Fig. 54 Drawing out the sequence valve

### 3.3.7 DISASSEMBLING THE TRAVEL PREFERENTIAL VALVE NEUTRAL CUT VALVE AND CONFLUX VALVE SPOOLS

- 1) Remove plug (251) and separate outer spring (324), inner spring (325) (for travel straight valve), outer spring (326), inner spring (327) (for neutral cut valve), outer spring (373) (for arm conflux valve), outer spring (377) (for boom conflux valve), inner spring (374) (for conflux valve), rod (337) (for neutral cut conflux).

- Mark the springs with a tag or the like to prevent them from being confused with the other springs during reassembly, as they differ in shape from the other springs.

- 2) Draw out the spool, utilizing the M4 screw at the end of the spool

- Mark the spools with a tag or the like to prevent them from being confused with each other during reassembly, as they differ in shape from each other.



Fig. 55 Drawing out the travel preferential valve




Fig. 56 Drawing out the RH neutral cut spool



Fig. 57 Boom conflux valve

### 3.3.8 RELIEF VALVE

- 1) Remove the main relief valve (601), travel relief valve (602) and port relief valve (603), (604) from the casing.




Fig. 58 Removing the upper right main relief valve

- Mark the port relief valve (603), (604) with a tag or the like to prevent them from being confused during reassembly, as they are the same in appearance and shape but differ in pressure setting (adjusted flow rate value).
- ◆ When removing the port relief valve (603), take care not to allow seat 1 (409) and spring (408) to slip off.
- ◆ Regarding the disassembly of the relief valves themselves, refer to the disassembly procedure outlined separately.




Fig. 59 Removing the lower left main relief valve

### 3.3.9 NEGATIVE CONTROL RELIEF VALVE (SEE FIG 9)

- 1) Remove the plug (551), and then remove the bushing (472), spring (471), and poppet (470).
- ◆ Take care not to lose the filter (473) installed on the poppet (470).




Fig. 60 Removing the travel relief valve



3.3.10 CHECK VALVE

1) Remove the plug (551), and then remove the poppets (511) and the spring (521).

- Remove all the check valves: seven are installed on the underside of the casing, and two on the side.
- The travel check valve is fitted with one special poppets (513). Mark them with a tag or the like to prevent them from being confused with each other.



Fig. 61 Removing poppet (511)

3.3.11 SHUTTLE VALVE

1) Remove the plug (552), and then remove the seats (541,542,543,544) and the ball (512).

- One shuttle valve is installed in the travel block (101), three in casing A (102), and two in casing B (103). Mark the shuttle valves with a tag or the like to prevent them from being confused with each other during reassembly, as their seats (541,542,543,544) differ in length from each other.




Fig. 62 Removing ball (512)

2) Remove plug (152) in casing A (102) and draw out orifice (351).

- Plug (152) is specially coated. At re-assembly, replace it with a new one.

3) Remove two plugs (153) in travel block (101) and take out orifice (351).



Fig. 63 Taking out the orifice

3.3.12 DISASSEMBLING OTHER COMPONENTS

1) Remove plug (552) in casing A (102) and take off poppet (logic valve) (612). (See section D-D)

- Use tweezers to remove the poppet (612).



Fig. 64 Removing the logic valve

### 3.3.13 CASING

- 1) Remove the socket bolts (973,974,976), and disassemble the assembly into travel block (101), casing A (102), casing B (103) and casing T2 (104).
- 2) Plugs not referred to in the above procedures are blind plugs for use in machining holes and as casting stoppers. Do not disassemble them unless there is a particular need to do so.



Fig. 65 Disassembling the casing

### 3.3.14 DISASSEMBLING THE MAIN RELIEF VALVE (SEE FIG. 6)

- 1) Body (420) and plug (421) are tight-fitted. Remove the plug by either pulling it by hand or prying it up with a screwdriver.

•The seat (429) and poppet (433) may pop out due to force of the springs (425,434). Be aware of this.

- 2) Remove the seat (429), spring (428) and plunger (427) from inside the body (420).
- 3) Loosen lock nut (439), separate adjust plug (422) from plug (421) and then draw out spring (434) and poppet (433).
- 4) Separate lock nut (438) and adjust screw (437) from adjust plug (422). Then separate spring seat (435) and piston (430).

### 3.3.15 DISASSEMBLING THE TRAVEL RELIEF VALVE (SEE FIG. 7)

- 1) With the body (601) in a vise, remove the plug (201).

•The poppet (611) and seat (641) may pop out due to the force of the springs (621,621).

- 2) Remove the seat (641), spring (621), and plunger (611) from inside the body (601).
- 3) Remove the lock nut (671) on plug (201), and the adjusting screws (651), then take out the spring seat (612), spring (621), and poppet (611).

### 3.3.16 DISASSEMBLING THE PORT RELIEF VALVE (SEE FIG. 8)

- 1) Draw out spring (408) and seat (409).
- 2) Hold body (401) in a vise and take off plug (404).

•Take care as poppet (410) and seat 2 (413) will pop up by the action of springs (407,412).

- 3) Draw out seat (413), spring (407), spring seat (417) and plunger (406) from inside body (401).

- 4) Separate lock nut (416) and adjust screw (414) from plug (404) and then draw out spring seat (411), spring (412) and poppet (410).

### 3.3.17 INSPECTION AFTER DISASSEMBLY

Thoroughly clean all disassembled parts with clean mineral oil, and dry them with compressed air. Place each part on a clean sheet of paper or cloth for inspection.

#### (1) Control valve

- 1) Inspect the entire surface of each part for burrs, scratches, cuts, and other defects.
- 2) Confirm that the sealing groove surface of the casing or the block is free of foreign matter, dents or rust.
- 3) If the check valve seat of the casing or the block has dents or damage on its surface, smooth it by lapping.

•Take care not leave lapping compound behind in the casing or block.

- 4) Confirm that the sealing part or the outer circumference of the sliding part of a manual spool is free of scratches, dents, and the like. Remove any small defects with an oil stone or rag moistened with lapping compound.
- 5) Manually confirm that all sliding and fitted parts move smoothly. Confirm that all grooves and passages are free of foreign matter.
- 6) Replace any broken or deformed spring with a new one.
- 7) Of a relief valve malfunctions, repair it by following the relief valve disassembly and reassembly procedures.
- 8) Replace all seals and O-rings with new ones.

#### (2) Relief valve

- 1) Confirm that the sealing face of each poppet and each seat edge is free of defects and is a uniform contact surface.
- 2) Manually confirm that the main poppet slides smoothly onto and off the seat.
- 3) Confirm that the outer circumference of the main poppet and the inner circumference of its seat are free of defects such as scratches.

- 4) Confirm that each spring is free of breakage, deformation, and excessive wear.
- 5) Confirm that the orifices of the main poppet and its seat are not clogged.
- 6) Replace all O rings with new ones.
- 7) Remove any slight defects found during the above inspection by lapping.
- 8) If any abnormal part is found, replace the relief valve as an assembly.

### 3.4 REASSEMBLY

- (1) Here, only the reassembly procedures are described. Regarding drawings, refer to the disassembly procedures.
- (2) The numbers in parentheses following each part in the descriptions correspond to those in the views in Fig.2,3,4,5,6,7,8 and 9 in section 2.1.
- (3) Precautions on reassembling seals
  - 1) Confirm that seals are free of forming defects or defects caused by poor handling.
  - 2) Apply an adequate coat of grease or hydraulic oil to seals and their mating parts.
  - 3) Do not stretch seals to the extent that they become permanently set.
  - 4) When installing O rings, do not roll them into place. Twisted O rings do not easily untwist by themselves after installation, and can cause oil leaks.
  - 5) Regarding the mounting bolts in various sections, tighten them to the tightening torques given in the sectional view of control valve (Fig. 2), using a torque wrench.

#### 3.4.1 CASING

- 1) Put O rings (161,162,163) on casing A (102), casing T2 (104) and casing B (103), and then join the casings to the travel block (101) with socket bolts (973,974,976) and tighten to the specified torque.

- Confirm that the mating surface is free of foreign matter such as dust, and that each O ring is securely installed in its O ring groove.

#### 3.4.2 PLUGS AND ORIFICES

- 1) Install the two orifices (351) in the travel block (101), and tighten the plug (153) to the specified torque.
- 2) Install the orifice (351) in the casing (102), and tighten the plug (152) to the specified torque.

- Since plug (152) is specially coated, be sure to install a new one at reassembly. As a stopgap measure, a commercial PT1/8" plug with 1.5 turns of sealing tape around it may be used. In that case, take care not to let any pieces of the sealing tape enter the casing.

- Use of sealing tape may cause the control valve to malfunction. Try as much as possible not to use tape.

- 3) Install the poppet (612) in casing A (102). Put an O ring (166) on the plug (153), and tighten the plug to the specified torque.

#### 3.4.3 RELIEF VALVE

- 1) Tighten the main relief valve (601), travel relief valve (602), and port relief valve (603), (604) to their respective casings to the specified torque.

- As the port relief valve (603), (604) are the same in appearance and shape, look at the tags attached at disassembly and take care not to confuse them at reassembly.

- Regarding the reassembly of the relief valves themselves, refer to the disassembly procedures in the preceding section.

#### 3.4.4 SHUTTLE VALVES

- 1) Insert a ball (512) in each casing, install the seats (541,542,543,544), put an O ring (562) on the plug (552) and tighten the plug to the specified torque.

- There is one shuttle valve in the travel block (101), three in casing A (102), and two in casing B (103). Their seats (541,542,543,544) differ in length.

- Take care not to confuse them.

#### 3.4.5 CHECK VALVES

- 1) Install the poppet (511) and spring (521), put an O ring (561) on the plug (551), and tighten the plug to the specified torque.

- Note that there are seven check valves on the underside of the casing, and two on the side.

#### 3.4.6 NEGATIVE CONTROL RELIEF VALVE

Install the poppet (470), spring (471) and bushing (472) in casing A (102) and casing B (103), put an O ring (561) on the plug (551) and tighten the plug to the specified torque.

#### 3.4.7 ASSEMBLING TRAVEL STRAIGHT VALVE SPOOL, BYPASS CUT VALVE SPOOL AND CONFLUX VALVE SPOOL

- 1) Place spools (305,306,307,310,391) in designated positions, insert springs (324, 326, 326, 327, 373, 374, 377) and red (337) fit O ring (265) to plug (251) and tighten them to specified torques

- Place conflux valve spools (307,391) and bypass cut valve spool (306,310) in correct positions.

#### 3.4.8 BUCKET SPOOL

- 1) Clamp the center of the bucket spool (304) in a soft-jaw vise, put the spring seat (332), springs (371,372) and stopper (335) in the spool, and tighten the spacer bolt (336) to the specified torque.

- Apply locktite #241 to the spacer bolt (336) before tightening it.

- Take care not to make the vise too tight as it might deform the bucket spool (304).

- 2) Install the spool assembly reassembled in step 1) above in casing B (103).

- Install the spool assembly in casing B (103) slowly and carefully. Never force the assembly in.

#### 3.4.9 ASSEMBLING THE ARM T2 SPOOL

- 1) Pinch the center of spool (arm T2) (309) in a mouth-piece attached vise, place spring seat (332), springs (323, 330) and stopper (335) in place and tighten spacer bolt (336) to a specified torque.

- Apply locktite #241 to the spacer bolt (336) before tightening it. Take care not to make the vise too tight as it might deform the arm T2 spool (309).

- 2) Install the spool assembly reassembled in steps 1) above in casing T2 (104).

- Install the spool assembly in casing T2 (104) slowly and carefully. Never force the assembly in.

#### 3.4.10 BOOM SPOOL (SEE FIG. 4)

- 1) Install plunger 1 (315), plunger 2 (316), plunger 3 (317), spring (boom lower) (320), spring (boom oil recirculation) (330), spring (boost check) (340), and the rod (343) in the boom spool (303), and tighten the plug (352).

- Take care that each part is installed in the correct location. Confirm that each plunger moves smoothly in the boom spool (303).

2) Clamp the plug (352) at the end of the boom spool (303) in a vise, then put the spring seat (332), springs (371,372) and stopper (338) in the spool, and tighten the spacer bolt (336) to the specified torque.

- Apply locktite #241 to the spacer bolt (336) before tightening it.

3) Install the spool assembly reassembled in step 1) and 2) above in casing B (103).

- Install the spool assembly in casing B (103) slowly and carefully. Never force the assembly in.

#### 3.4.11 ARM SPOOL (SEE FIG. 3)

1) Clamp the arm spool sub-spool (312) in a soft-jaw vise, install the spring (329) and spring seat (358) in the spool, and tighten the spacer bolt (343) to the specified torque.

- Apply locktite #241 to the spacer bolt (343) before tightening it.

2) Confirm that the piston (318) is in the arm bushing (341), insert the arm spool sub-spool (312) assembly in the arm spool (302) in the correct direction, and tighten the plug (359) to the specified torque.

- Confirm that the arm spool sub-spool (312) moves smoothly in the arm spool (302).

3) Clamp the plug (359) at the end of the arm spool (302) in a vise, set the spring seat (372), springs (371,378) and stopper (335) to the spool, and tighten the spacer bolt (336) to the specified torque.

- Apply locktite #241 to the spacer bolt (336) before tightening it.

4) Install the spool assembly reassembled in steps 1) and 2) above in casing A (102).

- Install the spool assembly in casing A (102) slowly and carefully. Never force the assembly in.

#### 3.4.12 TRAVEL SPOOL

1) Clamp the center of the travel spool (301H) in a soft-jaw vise, put the spring seat (331H), springs (328H,329H) and stopper (334H) in the spool, and tighten the spacer bolt (333H) to the specified torque.

- Apply locktite #241 to the spacer bolt (333H) before tightening it.
- Take care not to make the vise too tight as it might deform the travel spool (301H).

2) Install the spool assembly reassembled in step 1) above in travel block (101).

- Install the spool assembly in travel block (101) slowly and carefully. Never force the assembly in.

#### 3.4.13 COVERS

1) Install spool cover (203) on the opposite side of the boom, bucket, arm T2 spool springs and attach spool cover (202H) on the opposite side of the travel spool spring. Then tighten socket head cap screws (273) to a specified torque.

- Confirm that the O rings (263,266H) are installed.

2) Mount the spring covers (301) on the spring side of the bucket, arm and arm T2 spools, and tighten the socket bolts (273) to the specified torque.

- Confirm that the O ring (261) is installed.

3) Install the arm cover (205), piston (353) and spring (354) on the side of the arm spool opposite the spring side, and tighten the socket bolts (273) to the specified torque.

- Confirm that the piston (353) moves smoothly in the arm cover (205).
- Confirm that the O ring (253) is installed.

#### 3.4.14 MAIN RELIEF VALVE (SEE FIG. 6)

1) Fix piston (430) and spring seat (435) to adjust screw (422) and then attach adjust screw (437) and lock nut (438).

2) Fit spring (434) and poppet (433) to plug (421). Then install the assembly in para. 1) above and lock nut (438).

3) Attach plunger (427), spring (428) and seat (429) to body (420).

4) Force-fit the assemblies reassembled in steps 2) and 3) above.

- Confirm that the seat (429) and the poppet (433) are securely inserted.
- Use a bearing puller or the like to force-fit the assembly, as only a little force is required.

5) Fit O rings (423,424) and backup ring (165).

6) Pressure adjustment is performed by referring to "service standard and test procedure". Adjust screw (422) and adjust screw (437) may be in a temporarily assembled state for this operation.

#### 3.4.15 ASSEMBLING THE TRAVEL RELIEF VALVE (SEE FIG. 7)

1) Fit spring seat (612), spring (621) and poppet (611) to plug (201) and then fix adjust screw (651) and lock nut (671).

2) Fit plunger (511), spring (521) and seat (641) to body (107).

3) Tighten each of the assemblies under para. 1) and 2) above to specified torques.

- Make sure that seat (641) and poppet (611) are set in place.

#### 3.4.16 ASSEMBLING THE PORT RELIEF VALVE (SEE FIG. 8)

1) Fix plunger (406), spring seat (417), spring (407) and seat 2 (413) to body (401).

2) Fit O ring (405) to plug (404). Fit O ring (415) to spring seat (411) as well.

3) Put spring seat (411) assy, spring (412) and poppet (410) into plug (404). Then tighten adjust screw (414) and lock nut (410).

4) Tighten each of the assemblies under para. 1) and 3) to specified torques.

5) Fix seat (409) and spring (408). Then attach O rings (402,403).

6) Pressure adjustment is performed by referring to "service standard and test procedure". Adjust screw (414) may be in a temporarily assembled condition.

## 4. MAINTENANCE STANDARDS

### 4.1 INSPECTION OF COMPONENTS

Part name	Inspection item	Criterion and remedy
Casing	1) Look for scratches, rusting, corrosion.	1) If any of the following parts are damaged, replace the component as a unit. <ul style="list-style-type: none"> <li>• Sliding part of casing hole and spool, particularly the land, to which holding pressure is applied.</li> <li>• Part of sealing pocket through which spool is inserted.</li> <li>• Area of sealing part that is in contact with O ring.</li> <li>• Sealing part of main, travel, or port relief valve.</li> <li>• Defects of other parts that seem to prevent normal function.</li> </ul>
Spool	1) Look for scratches, galling, rusting, corrosion.  2) Inspect ends that are sealed with an O ring.  3) Insert the spool in the casing bore, and move it while turning it.	1) If a defect detectable with your fingernail is found on the sliding part of the outer circumference (particularly the part that comes into contact with a seal), replace the spool.  2) If the sliding part is damaged, replace the spool.  3) If the spool damages the O ring or does not move smoothly, repair or replace the spool.
Poppet	1) Look for damage on the poppet and the spring.  2) Insert the poppet in the casing, and move it.	1) If sealing is incomplete, replace the seal.  2) If the poppet moves lightly without catching, it is normal.
Spring and associated components	1) Look for rust, corrosion, deformation, and breakage of the spring, spring seat, plug and cover.	1) If damaged heavily, replace.
Spool seal and associated components	1) Look for external oil leak.  2) Look for rust, corrosion and deformation of sealing plate	1) Repair or replace.  2) Repair or replace.
Main relief valve Travel relief valve Port relief valve Low pressure relief valve	1) Look for rust and damage on outer surface.  2) Inspect the contact face of the valve seat.  3) Inspect the contact face of the poppet.  4) Look for spring abnormality.  5) Inspect the O ring, backup ring, and seal.	1) Replace.  2) If damaged, replace.  3) If damaged, replace.  4) Replace.  5) As a general rule, replace all parts with new ones.



## 5. TROUBLESHOOTING

1) If an abnormal condition is noticed, check to see if the problem is with the control valve itself, one of the main pumps, the No.3 pump, or a circuit. To this end, you will need to measure pilot pressure, pump delivery pressure, load pressure, etc. If any part of the system is to be disassembled for inspection, follow the disassembly and reassembly procedures in this booklet.

2) Dust is the enemy of hydraulic components. Pay strict attention to protection from dust.

If any part of the system is to be disassembled, take dust protection measures beforehand.

3) Moving parts must be handled with care. If they are damaged in any way, smooth the damage using an oil stone or the like.

4) Take care not to damage the gasket face of O rings. A damaged gasket face will certainly cause oil leaks.

### 5.1 CONTROL VALVE

Trouble	Cause	Remedy
1. Travel does not occur. Slow to start up (sluggish). Slow response	1) Malfunctioning travel relief valve. • Foreign matter between main poppet valve and seat. • Foreign matter between poppet and seat. • Sticking main poppet. • Broken or deformed spring. • Clogged main poppet throttle. • Loosened adjusting screw.	1) Measure travel relief valve pressure • Disassemble and clean. If damaged heavily, replace the assembly as a unit. • Same as above.  • Smooth sticking part with oil stone. • Replace spring • Remove foreign matter. • Readjust, and tighten lock nut to specified torque.
	2) Clogged orifice in pilot circuit.	2) Remove foreign matter.
2. Machine does not move straight during simultaneous travel and working attachment operation.	1) Malfunctioning travel straight control valve. • Sticking spool. • Broken or deformed spring. • Excessive clearance between travel block and spool. • Clogged small bore in spool.	1) Measure pilot pressure.  • Smooth sticking part with oil stone. • Replace spring. • Replace spool or travel block.  • Remove foreign matter.
	2) Malfunctioning shuttle valve. • Air in pilot circuit. • Foreign matter between ball and seat. • Damaged seat face	2) Measure pilot pressure. • Bleed air. • Disassemble and clean. • Smooth with oil stone. If heavily damaged, replace seat.
	3) Malfunctioning right or left neutral cut-off valve. • Sticking spool. • Broken or deformed spring. • Excessive clearance between right or left casing, and spool. • Clogged small bore in spool.	3) Measure pilot pressure.  • Smooth sticking part with oil stone. • Replace spring. • Replace spool, or right or left casing.  • Remove foreign matter.

Trouble	Cause	Remedy
	4) Malfunctioning logic valve <ul style="list-style-type: none"> <li>Foreign matter between poppet and seat.</li> <li>Damaged poppet or seat face.</li> <li>Broken or deformed spring.</li> </ul>	<ul style="list-style-type: none"> <li>Remove foreign matter.</li> <li>Smooth with oil stone. If heavily damaged, replace seat or poppet.</li> <li>Replace spring.</li> </ul>
	5) Malfunctioning travel relief valve. See item 1. 1) above.	5) Replace spool or casing.
3. Excessive retraction of cylinder under its own weight when spool is in neutral.	1) Excessive clearance between casing and spool.	1) Replace spool or casing.
	2) Spool is not completely in neutral position. <ul style="list-style-type: none"> <li>Foreign matter between casing and spool, or sticking spool</li> <li>Broken or deformed spring.</li> <li>Clogged pilot circuit.</li> </ul>	2) Measure secondary pilot pressure <ul style="list-style-type: none"> <li>Disassemble, clean, and smooth sticking part with oil stone.</li> <li>Replace spring.</li> <li>Remove foreign matter.</li> </ul>
	3) Malfunctioning main relief valve. Refer to item 1. 1) above.	3) Measure main relief valve pressure. Refer to item 1. 1) above.
	4) Malfunctioning port relief valve. Refer to item 1. 1) above.	4) Measure port relief valve pressure. Refer to item 1. 1) above.
	5) Malfunctioning anti-cavitation check valve. <ul style="list-style-type: none"> <li>Foreign matter between poppet and casing.</li> <li>Broken or deformed spring.</li> </ul>	5) <ul style="list-style-type: none"> <li>Disassemble and clean.</li> <li>Replace spring.</li> </ul>
4. When extending cylinder, at first it retracts.	1) Malfunctioning load check valve. <ul style="list-style-type: none"> <li>Foreign matter between poppet and casing.</li> <li>Sticking poppet.</li> <li>Broken or deformed spring.</li> </ul>	1) <ul style="list-style-type: none"> <li>Disassemble and clean. If heavily damaged, replace casing.</li> <li>Smooth sticking part with oil stone.</li> <li>Replace spring.</li> </ul>
5. Bucket, boom or arm alone does not operate. Slow to start up (sluggish). Slow response.	1) Malfunctioning main spool. <ul style="list-style-type: none"> <li>Excessive clearance between casing and spool</li> <li>Foreign matter between casing and spool.</li> <li>Sticking spool.</li> <li>Broken or deformed return spring.</li> <li>Clogged pilot circuit.</li> </ul>	1) Measure secondary pilot pressure. <ul style="list-style-type: none"> <li>Replace spool or casing.</li> <li>Disassemble and clean.</li> <li>Smooth sticking part with oil stone</li> <li>Replace spring.</li> <li>Remove foreign matter.</li> </ul>
	2) Malfunctioning main relief valve Refer to item 1. 1) above.	2) Measure main relief valve pressure. Refer to item 1. 1) above.
	3) Malfunctioning port relief valve. Refer to item 1. 1) above.	3) Measure port relief valve pressure. Refer to item 1. 1) above.
	4) Malfunctioning pilot valve. Refer to "Control System" manual.	4) Refer to "Control System" manual.

Trouble	Cause	Remedy
6. Swing priority function does not occur.	1) Malfunctioning logic valve. Refer to item 2. 4) above.	1) Refer to item 2. 4) above.
	2) Clogged orifice in pilot circuit.	2) Remove foreign matter.
7. Swing does not occur.	1) Malfunctioning neutral cut-off valve. Refer to item 2. 3) above.	1) Refer to item 2. 3) above.
	2) Malfunctioning shuttle valve. Refer to item 2. 2) above.	2) Refer to item 2. 2) above.
8. Boom or arm oil recirculation does not occur.	1) Malfunctioning conflux valve. Refer to item 2. 3) above.	1) Measure pilot pressure. Refer to item 2. 3) above.
9. Despite lever being in neutral, negative control does not occur, failing to minimize flow.	1) Malfunctioning low pressure relief valve. <ul style="list-style-type: none"> <li>● Foreign matter between poppet and seat.</li> <li>● Broken or deformed spring.</li> <li>● Clogged poppet throttle.</li> <li>● Damaged filter.</li> </ul>	1) Measure low pressure relief valve pressure. <ul style="list-style-type: none"> <li>● Disassemble and clean. If heavily damaged, replace the assembly as a unit.</li> <li>● Replace spring.</li> <li>● Disassemble and clean. Remove foreign matter.</li> <li>● Disassemble and clean. Replace filter.</li> </ul>

## 5.2 RELIEF VALVE

Trouble	Cause	Remedy
1. No pressure rise whatsoever.	Main or pilot poppet of relief valve is sticking and valve is open, or there is foreign matter on valve seat.	<ul style="list-style-type: none"> <li>● Check for foreign matter on each poppet.</li> <li>● Confirm that each component slides smoothly.</li> <li>● Clean all components thoroughly.</li> </ul>
2. Unstable relief pressure.	Damaged pilot poppet seat of relief valve Pilot piston sticks against main poppet.	<ul style="list-style-type: none"> <li>● Replace damaged component</li> <li>● Clean all components thoroughly.</li> <li>● Smooth surface damage.</li> </ul>
3. Irregular relief pressure.	1) Wear due to foreign matter.	1) Disassemble and clean.
	2) Loosened lock nut or adjusting screw.	2) Adjust pressure.
4. Oil leak.	1) Damaged seat. Worn out O ring.	1) Replace damaged or worn component. Confirm that each component operates smoothly before reassembling.
	2) Sticking component due to foreign matter.	2) Confirm that there are no scratches, nicks, or foreign matter present before reassembling.



# KOBELCO

## SHOP MANUAL

### PILOT VALVE (TRAVEL)

#### TABLE OF CONTENTS

**13**

1. SPECIFICATION	
1.1 General View .....	1
1.2 Specification .....	1
1.3 Performance Characteristics .....	1
2. CONSTRUCTION AND FUNCTION	
2.1 Construction .....	2
2.2 Function .....	3



## PREFACE

The pilot valve is used for remote control of the control valve. The pilot valve is of reducing valve type and contains multiple reducing valves that control the secondary proportionate pilot pressure actuated by manual lever action or pedal action. A check ball is provided on the discharge side of each reducing valve so as to select the higher of proportionate secondary pressure thus selected serves as an auto accel signal.

Models	Applicable Machines	Notes	Models	Applicable Machines	Notes
SK310M	LC03801~				
SK310LCW	YC01101~				
SK430W	LS00701~				
SK430LCW	YS00601~				

Revision	Date of Issue	Remarks
First edition	March, 1995	S5130777E K

# 1. SPECIFICATION

## 1.1 GENERAL VIEW





Fig. 1 Outside view of travel pilot valve

## 1.2 SPECIFICATION

Item	Specification
Dwg No.	2436U2368F1
Primary press	50kgf/cm <sup>2</sup> (711 psi)
Secondary press	$6 \pm 1 \sim 23 \pm 1.5 \text{ kgf/cm}^2$ $(85.3 \pm 14.) \sim (327 \pm 21.3 \text{ psi})$
Max. pressure of T-port	8kgf/cm <sup>2</sup> (42.7 psi)
Weight	Approx. 11kg (24 lbs)


## 1.3 PERFORMANCE CHARACTERISTICS



Part dia.	Tightening torque kgf·m (ft·lbs)	Part Name	Function
PF1/4	$2.5 \pm 0.2$ ( $18.1 \pm 1.4$ )	1	LH travel forward port
		2	LH travel backward port
		3	RH travel forward port
		4	RH travel backward port
		Pi	Auto accel signal port

## 2. CONSTRUCTION AND FUNCTION

### 2.1 CONSTRUCTION



T = TIGHTENING TORQUE kgf-m (ft-lbs)

Fig. 2 Construction of travel pilot valve

Tightening torque kgf-m (ft-lbs)	No.	NAME	QTY	Tightening torque kgf-m (ft-lbs)	No.	NAME	QTY
$1.5 \pm 0.1 (10.8 \pm 0.7)$	1	SHIM	4	$2.0 \pm 0.2 (14.6 \pm 1.45)$	18	COLLAR PLUG PP1/4	7
	2	SHIM	4	$7.9 \pm 0.5 (57.1 \pm 3.9)$	19	SOCKET HEAD CAPSCREW M12	2
	3	SEAT	2	$0.5 \pm 0.1 (3.62 \pm 0.72)$	20	FLANGE BOLT M4	4
	4	SPOOL	4	$2.2 \pm 0.2 (15.9 \pm 1.45)$	21	SOCKET HEAD CAPSCREW M10	4
	5	SLEEVE	4		22	PLAIN WASHER	4
	6	COVER	2		23	PLAIN WASHER	8
	7	PLUNGER	4		24	PIN	4
	8	PIN	2		26	SPLIT PIN	4
	9	BOOT	2		26	STEEL BALL	2
	10	SPRING	4		27	STEEL BALL	6
	11	PLATE	2		28	STEEL BALL	7
	12	BODY	1		29	O RING	4
	14	SPRING	4		30	O RING	7
	15	CAM	2		31	O RING	4
	16	SHIM	4				



## 2.2 FUNCTION

### (1) Lever neutral (See Fig. 3)

When the lever is neutral, the spool (4) is pushed up by the spring (14) and the output port 2,4 are through with the T port.




Fig. 3 Lever neutral

### (2) Lever tilted (See Fig. 4)

By the tilting operation of lever, plunger (7) is moved down and sleeve (5) is moved down. With the result spring (10) is compressed and spool (4) is pushed down. Thus the secondary pressure of pilot is decided by spring (10) force.




Fig. 4 Lever tilted

### (3) Lever held (See Fig. 5)

If the pressure at ports (2,4) rises to a level equal to the action of the spring (10) set as the lever is tilted, the hydraulic pressure balances with the action of the spring (10) and spool (4) is moved upwards. When the pressure at the ports (2,4) arrives at a set level, the port P closes to hold the secondary pressure constant.




Fig. 5 Lever held

### (4) High pressure selector valve

The valve body (12) has ports 1,2,3,4 and Pi in its side surface.

The port Pi is the high pressure select port that takes out the maximum pressure from among the ports 1,2,3 and 4.



# KOBELCO

## SHOP MANUAL

### SWIVEL JOINT

#### TABLE OF CONTENTS

1. SPECIFICATIONS	
1.1 General View .....	1
1.2 Specifications .....	1
2. CONSTRUCTION AND FUNCTION .....	2
3. DISASSEMBLY AND ASSEMBLY	
3.1 Preparation .....	3
3.2 Disassembly .....	4
3.3 Assembly .....	5
4. MAINTENANCE STANDARDS	
4.1 Inspection Procedure and Remedy .....	7
4.2 Usable Limit of the Parts .....	7
4.3 Inspection after Assembly .....	9
5. TROUBLESHOOTING .....	10



## PREFACE

The swivel joint is installed in the center part of the rotating body and continuously maintains the connection of the fluid circuit regardless of the swing angle.

Major parts of this swivel joint consist of body and stem which are able to rotate reciprocally and each is provided with ports for the number of fluid circuit on it.

Models	Applicable Machines	Notes	Models	Applicable Machines	Notes
SK150LCⅢ	YM00101~	Spec.1			
SK100V	YW06501~	Spec.1			
SK120V	LP11001~	Spec.1			
SK120LCV	YP02301~	Spec.1			
SK200V	YN18001~	Spec.1			
SK200LCV	YQ02301~	Spec.1			
SK220V	LQ03301~	Spec.1			
SK220LCV	LL02301~	Spec.1			
SK310Ⅲ	LC03801~	Spec.1			
SK310LCⅢ	YC01101~	Spec.1			

Revision	Date of Issue	Remarks
First edition	February, 1993	S5160122E K
First revision	April, 1994	S5160122E① K
Second revision	March, 1995	S5160122E② K

# 1. SPECIFICATION

## 1.1 GENERAL VIEW





Fig.1 Outside view of swivel joint

## 1.2 SPECIFICATIONS

Table 1

Item		Spec. 1
High pressure ports A , B , C , D	Working pressure	350kg/cm <sup>2</sup> (4980psi)
	Max. impact pressure (pressure tightness)	525kg/cm <sup>2</sup> (7470psi)
	Rated flow	255ℓ/min (67gal/min)
Low pressure ports E	Working pressure	5kg/cm <sup>2</sup> (71psi)
	Rated flow	50ℓ/min (13gal/min)
Low pressure ports F	Working pressure	50kg/cm <sup>2</sup> (710psi)
	Rated flow	30ℓ/min (8gal/min)
Revolution		15rpm
Port size	A , B , C , D	PF1
	E	PF1/2
	F	PF1/4
Total length L		320mm (1 ft 0.6 in)
Weight		27kg (60 lbs)

## 2. CONSTRUCTION AND FUNCTION



NO.	NAME	QTY	NO.	NAME	QTY
1	BODY	1	6	O RING	2
2	STEM	1	7	O RING	1
3	THRUST PLATE	1	8	CAPSCREW	2
4	COVER	1	9	CAPSCREW	4
5	SEAL ASS'Y	5	10	PLUG	1

Fig.2 Cross-sectional view of swivel joint

Main portion of the swivel joint consists of body (1) which rotates freely, swivel stem (2), thrust plate (3) which prevents disconnection of body and stem, cover (4) which closes one side of swivel body (1), slipper seal sets (5), which divide circuits, and Orings (6,7), which prevent external oil leakage.

Four ports for the main circuits are provided on body (1) and stem (2), four oil passage grooves are machined on the inner face of the body (1), and seal sets (5) are provided at top and bottom of circumferential grooves

Body (1) and stem (2) rotate freely. Oil from body (1) or stem (2) flows into stem (2) or body (1) through circumferential grooves between body (1) and stem (2) ; Oil flow is thus not obstructed by swiveling. Lubricating oil groove to drain port is also provided to prevent seizure of body (1) or stem (2) by swiveling.



With this construction, swivel joint assures circuit connection between the lower body and the revolving upper body.

### 3. DISASSEMBLY AND ASSEMBLY

#### 3.1 PREPARATION

##### 3.1.1 TOOLS

Table 2

Symbol	Tool Name	Used for	Remarks
a	Hammer	Disassembly	1. Steel hammer 2. Wooden or plastic hammer
b	Rubber mat		Not less than 500mm (19.7in) square
c	Wrench	Assembly	1. Allen wrench 2. Double-ended and single-ended wrench 3. Extension pipe
d	Torque wrench	Assembly	10kgf-m (72ft-lbs)
e	Pin	Disassembly	Grind the tip of "a nail" to shape as a screwdriver. 
f	Spatula	Disassembly Assembly	Made from a hack-saw blade  Approx. 120mm (4.72 in) Vinyl tape Remove the edge completely and make corner round smooth.
g	Vise	Disassembly Assembly	Vises movable over 150mm (5.91in)
h	Three-band		1360K
i	Lubricating oil		Hydraulic oil or vaseline
j	Cleaning oil		

##### 3.1.2 APPARATUS

- (1) Hoist or crane  
The lifting device should be capable of lifting the swivel joint assembly.
- (2) Work bench  
The work bench should have an area of 1.2m x 1.5m (3ft 11in x 4ft 11in).
- (3) Others  
Also prepare waste cloth, wooden block and oil pan.

##### 3.1.3 CLEANING OUTSIDE


Do not fail to put a plug to each port and clean the swivel joint so it is free from dust and other foreign matter, using steam, cleaning oil, etc.

### 3.2 DISASSEMBLY

The part numbers used in this disassembly procedure correspond to those of a construction drawing in Fig. 2.

#### 3.2.1 DISMANTLING COVER

- 1) Mark cover (4) and body (1) with matching marks for convenient re-assembly.
- 2) Place a V-block on a work bench, mount a swivel joint set on the side, fix it and loosen capscrew (9) by means of a pipe. Alternately, the swivel joint may be fixed by holding stem (2) in a vise.

 : 6mm

- 3) Remove cover (4) from body (1) and draw out O ring (7) from cover (4).






Fig. 3 Removing cover (4)

#### 3.2.2 DISMANTLING THRUST PLATE

Loosen capscrew (8) fastening thrust plate (3), in the same manner as the dismantling of the above-mentioned cover.

-  When dismantling thrust plate (3) by fixing body (1), support stem (2) so it may not fall down.

 : 6mm




Fig. 4 Removing thrust plate (3)

#### 3.2.3 EXTRACTION OF STEM

Place body (1) on a V-block. Put a wooden block against stem (2) via the body so about half of the stem is covered by the wooden block and knock it out, using a hammer.

By hitting out the stem over about 1/2 from the body, it can be easily pulled out.




Fig. 5 Drawing out stem (2)



### 3.2.4 REMOVING SEALS

- 1) Pull out O ring (6) from the O ring groove with the aid of a spatula.

**⚠** Use the tip of the spatula taking not to mar the body. Also do not strike the spatula.

- 2) Pierce pin (e) to seal (5) and extract slipper ring (5). Fig.7 shows the use of one pin, but by using two pins, this can be extracted with more sureness.

As the backup ring is of rubber substance, remove this in the same procedure as O ring (6).




Fig. 6 Taking out O ring (6)




Fig. 7 Taking out seal ass'y (5)

### 3.3 ASSEMBLY

Prior to assembly, clean each parts (excluding the O ring and slipper ring), and arrange in the sequence of assembly.

#### 3.3.1 ASSEMBLING SEALS TO BODY

- 1) Coat O ring (6) lightly with vaseline (or hydraulic oil) and install in the O ring groove. Also make sure that the O ring is not distorted after installation
- 2) Make sure that oiliness, such as vaseline, hydraulic oil and grease, has been completely removed.
- 3) Slipper ring is assembled, after first inserting the backup ring, by slightly-changing the shape as shown in Fig.8. Also after inserting all of the seals, be certain that these are installed in the seal groove by use of the spatula.




Fig. 8 Inserting seal ass'y (5)

### 3.3.2 ASSEMBLING STEM

Lightly coat the outer circumference of stem (2) and the inner surface of body (1) with grease or vaseline and slowly insert stem (2) into body (1).

- ⚠ It stem (2) is pressed in too fast, the seal may be damaged. Do it slowly. The clearance between body (1) and stem (2) is about 0.1mm (0.004in). Erect stem straight along the shaft center.

Press in by applying your weight by your both hands.




Fig. 9 Inserting stem (2)

### 3.3.3 ASSEMBLING THRUST PLATE

- 1) While holding stem (2) and body (1), match the hole of thrust plate (3) and the stem (2) hole.
- 2) Next, after removing any oil from the thread part of capscrew (8), coat it with three-hand 1360k and tighten to stem (2).

⌒ : 6mm,  
Tightening torque :  $3.1 \pm 0.3 \text{ kgf-m}$   
( $22 \pm 2 \text{ ft-lbs}$ )




Fig. 10 Tightening capscrew (8)

### 3.3.4 ASSEMBLING COVER

After installing O ring (7) to cover (4) and aligning the matching marks of the cover (4) and body (1), tighten capscrew (9) which will then complete assembly

⌒ : 6mm,  
Tightening torque :  $3.1 \pm 0.3 \text{ kgf-m}$   
( $22 \pm 2 \text{ ft-lbs}$ )




Fig. 11 Tightening capscrew (9)

## 4. MAINTENANCE STANDARDS

### 4.1 INSPECTION PROCEDURE AND REMEDY




Table 3

Interval	Check Item	Checking Procedure	Remedy
2,000Hrs.	Seal for oil leakage outside	Check oil leakage outside	Replace O ring, if any oil leakage can be found.
4,000Hrs. In principle, disassemble and check regardless of oil leakage or not.	All sealing parts		Replace all sealing parts such as slipper seal with square seal and O ring.
	All rubbing parts	Check abnormal wear, scoring or corrosion caused by foreign particles or burning.	Repair or replace referring to their limit of serviceability.
When disassembled for repair	All parts	Check them for burning, foreign particles, abnormal wear, and defect of seals.	Repair or replace referring to their limit of serviceability. O rings should be replaced.

### 4.2 USABLE LIMIT OF THE PARTS

Table 4

Parts		Maintenance Standards	Remedy
Body, Stem	Sliding surface with sealing sections	Plating worn or peeled due to seizure or contamination.	Replace
	Sliding surface between body and stem other than sealing sections	1) Worn abnormality or damaged more than 0.1mm (0.004in) in depth due to seizure contamination.	Replace
		2) Damaged more than 0.1mm (0.004in) in depth.	Smooth with oilstone.
	Sliding surface with thrust plate	1) Worn more than 0.5mm (0.02in) or abnormality.	Replace
		2) Worn less than 0.5mm (0.02in).	Smooth
		3) Damage due to seizure or contamination remediable within wear limit 0.5mm (0.02in).	Smooth
Cover	Sliding surface with thrust plate	1) Worn more than 0.5mm (0.02in) or abnormality.	Replace
		2) Worn less than 0.5mm (0.02in).	Smooth
		3) Damage due to seizure or contamination remediable within wear limit 0.5mm (0.02in).	Smooth

Parts	Maintenance Standards	Remedy
Slipper ring	<p>1) Extruded excessively from seal groove square ring.</p> 	Replace (With back-up ring)
	<p>2) Slipper ring 1.5mm (0.06in) narrower than seal groove, or narrower than back-up ring.</p> 	Replace (With back-up ring)
	<p>3) Worn more than 0.5mm (0.02in)</p> 	Replace (With back-up ring)

#### 4.3 INSPECTION AFTER ASSEMBLY

After completion of assembly, inspection for oil leakage, pressure resistance, etc., using a device as shown in the figure below.

##### (1) High pressure port

Install a changeover valve and pressure gauge to the stem side port and body side port respectively, and while watching the pressure gauges (for high pressure) installed on the body side and also by regulating high pressure relief valve (7), gradually increase the pressure and when the pressure has reached 1.5 times the maximum working pressure, close stop valve (3) and lock in the hydraulic oil in the swivel. Keep stop valve (6) on the low pressure relief valve side closed at this time.

##### (2) Low pressure port

(Drain port, return port, etc.)

Similar to the high pressure port, install a changeover valve and pressure gauge on each port of the stem side and body side.

Open stop valve (6) on the side of low pressure relief valve (5) and while watching the pressure gauge (for low pressure) connected to the body side and also by regulating low pressure relief valve (5), gradually increase the pressure and check for outside leakage with a color check at a pressure of  $5 \text{ kgf/cm}^2$  ( $71 \text{ lbs/in}^2$ ).




Fig. 12 Hydraulic circuit for inspection equipment

Table 5

Item	Description	Remarks
1	Pressure Gauge	(High and Low Pressures are required.)
2	Swivel Joint	
3	Stop Valve	
5	Relief Valve for low pressure	Setting Pressure : $5 \text{ kgf/cm}^2$ (71psi)
6	Stop Valve	
7	Relief Valve for high pressure	Setting Pressure : (Working pressure $\times$ 1.5 times)
8	Changeover Valve	
9	Piping, etc.	

## 5. TROUBLESHOOTING

Table 6

Trouble	Cause	Remedy
1. External leakage of hydraulic fluid	Defective O ring	Replace all seals.
2. Internal leakage of hydraulic fluid	1) Defective slipper seal 2) Sliding face worn excessively	1) Replace all seals. 2) Replace ass'y.
3. Swivel joint seized	1) Stem and body seized  2) Inappropriate swivel stopper bracket	1) Grind and hone. Replace assembly, if stem and body are too loose and causing oil leakage. 2) Reinstall Secure 2-3mm (0.08-0.12in.) allowance for bolt stopper.
4. Loose swivel stem and cover	capscrew tightened insufficiently.	Retighten.